CASE

PROFESSIONAL PARTNER

PARTS CATALOG

COMPACT CRAWLER EXCAVATOR

CX17B

ASN PU08-05001~

87519734 NA

Issued 01Mar07

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001	00	FILTER, FUEL - FILTER, OIL
01-001	00	FRAME ASSEMBLY, UPPER (PU52F00032F1) (PU24C00012F1 COVER)
01-002	00	BRACKET GROUP, SWING (PU02B00066F1, 76F1, 69F1, 65F1)
01-003	00	COUNTERWEIGHT INSTAL (PU60C00016F1, 15F1)
01-004	00	ENGINE ASSY (PU02P00013F1)
01-005	00	ENGINE INSTAL (PU02P00016F1)
01-006	00	RADIATOR INSTAL (PU05P00016F1, 17F1)
01-007	00	RADIATOR ASSY (PU05P00015F1)
01-008	00	AIR CLEANER ASSY (PU11P00006F1)
01-009	00	MUFFLER (PU12P00014F1)
01-010	00	FUEL LINES (PU21P00002F1)
01-010	01	FUEL LINES
01-011	00	TANK INSTAL, FUEL (PU20P00015F1, 14F1)
01-012	00	TANK INSTAL, HYDRAULIC (PU33H00016F1, 19F1)
01-013	00	CONTROL ASSY, ENGINE (PU11M00012F1)
01-014	00	POWER TAKE-OFF ASSY (PU30P00013F1)
01-015	00	MOTOR INSTAL, SWING (PU32W00012F1)
01-016	00	LUBRICATION LINES (PU71H00012F1)
01-017	00	CONTROL VALVE INSTAL (PU64H00019F1)
01-018	00	HYDRAULICS - PUMP TO CONTROL VALVE (PU30H00013F1)
01-019	00	HYDRAULICS - UPPER / SWING MOTOR TO CYLINDER (PU03H00016F1, PU19H00018F1, PU42H00024F1)
01-019	01	HYDRAULICS - UPPER / AT CONTROL VALVE
01-020	00	HYDRAULICS - UPPER / NIBBLER & BREAKER (PU03H00017F1)
01-021	00	HYDRAULICS - RETURN / NIBBLER & BREAKER (PU32H00018F1, 16F1)
01-021	01	HYDRAULICS - RETURN / NIBBLER & BREAKER / AT TANK & VALVE
01-022	00	CONTROLS, OPERATOR (PU03M00033F1)
01-023	00	COVER ASSY, OPERATOR CONTROLS (PU03M01396F1)
01-024	00	WRIST SUPPORT, OPERATOR CONTROLS (PU03M01368F1)
01-025	00	CONTROL BOX ASSY (LH) (PU03M00036F1)
01-026	00	LOCK ASSY (PU03M01122F1)
01-027	00	LEVER ASSY, CONTROL (CRAWLER) (PU50M00014F1)
01-028	00	LEVER ASSY, CONTROL (DOZER) (PU03M01308F1)
01-029	00	LEVER ASSY, CONTROL (PM50M00004F3) & PEDAL INSTAL (PU55M00003F1)
01-030	00	HYDRAULICS - REMOTE CONTROL LINES (PU64H00022F1, PU68H00033F1, 28F1, 34F1)
01-030	01	HYDRAULICS - REMOTE CONTROL LINES AT VALVE (PU06H00020F1, 15F1, 21F1)
01-031	00	HYDRAULICS - CONTROL LINES, VALVE INSTAL (PU64H00024F1, 25F1)
01-032	00	HYDRAULICS - CONTROL LINES, PROPEL (PU62H00003F1, 04F1, 05F1)
01-033	00	HYDRAULICS - CONTROL LINES, VALVE (AT TANK, PUMP, SOLENOID VALVE) (PU64H00023F1)
01-034	00	FLOORPLATE & FLOORMAT (PU03M00035F1)
01-035	00	CANOPY ASSY (PU06C00014F1)
01-036	00	WORK LAMP ASSY (PA80S00003F1)
01-037	00	SEAT ASSY INSTAL (PU25M00022F1)
01-038	00	GUARDS & COVERS (EXTERIOR, UPPER) (PU21C00017F1)
01-039	00	KEY ASSY (PW03M01870F1)
01-040	00	GAUGE ASSY, CLUSTER (PU59S00001F1)
01-041	00	BATTERY INSTAL (PU72E00012F1)
01-042	00	ELECTRICAL ASSY, UPPER (HARNESS) (PU03E00002F1)
01-042	01	ELECTRICAL ASSY, UPPER (HARDWARE)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-042	02	ELECTRICAL ASSY, UPPER (CABLE, FUSE, RELAY)
01-042	03	ELECTRICAL ASSY, UPPER (HORN)
01-043	00	HARNESS ASSY (AT AIR CLEANER) (PU11E00001F1)
01-044	00	RELAY ASSY (HARNESS) (PU24E00016F1)
02-001	00	LOWER FRAME GROUP (PU02F00034F1, PU53D00016F1, PU19H00016F1)
02-002	00	CYLINDER INSTAL (CRAWLER FRAME WIDTH) (PU01V00034F1)
02-003	00	SLEWING RING ASSEMBLY (PF40F00002F1)
02-004	00	IDLER ASSY (PU52D00017F1)
02-005	00	IDLER ASSEMBLY (PU52D00019F1)
02-006	00	IDLER ADJUSTER ASSY (PE54D00001F1)
02-007	00	TRACK ROLLER ASSY (PU64D00015F1)
02-008	00	SHOE ASSY, TRACK / BELT (PE61D00002F1, PE60D00003F1)
02-009	00	HYDRAULICS - LOWER / AT SWIVEL (PU02H00015F1, PU19H00017F1, PU13H00012F1)
02-009	01	HYDRAULICS - LOWER (PU12H00012F1, PU13H00013F1)
02-010	00	DOZER ASSY, FRAME (PU51B00023F1, 25F1, 26F1, 24F1)
03-001	00	BOOM ASSY, STANDARD 1.8M (6 FT) (PU02B00061F1, 64F1, 67F1)
03-002	00	HYDRAULIC LINES - BOOM 1.8M (6 FT) & CYLINDER (PU42H00026F1, 21F1, 23F1, 22F1)
03-003	00	HYDRAULIC LINES - BOOM 1.8M (6 FT) & ARM (NIBBLER & BREAKER) (PU42H00020F1, PU43H00017F1)
03-004	00	CYLINDER INSTAL (BOOM) (PU02B00077F1)
03-005	00	LAMP INSTAL & HARNESS (BOOM) (PU80S00012F1)
03-006	00	ARM ASSY, STANDARD 0.98M (3 FT 2 IN) (PU12B00049F1)
03-007	00	HYDRAULIC LINES - ARM, STANDARD 0.98M (3 FT 2 IN)(PU43H00018F1)
03-008	00	BUCKET INSTAL (PU61B00049F1)
04-001	00	TOOLS & ACCESSORIES (PM01T00002FE)
05-001	00	COUNTERWEIGHT INSTAL (PU60C00023F1)
05-002	00	PEDAL ASSY, OPERATOR CONTROL (PU14M00001F1)
05-003	00	ARM ASSY, LONG 1.20M (4 FT) (PU12B00052F1)
05-004	00	HYDRAULIC LINES - ARM, LONG 1.20M (4 FT) (PU43H00022F1)
05-005	00	HYDRAULIC LINES - BOOM & ARM 1.20M (4 FT) (NIBBLER & BREAKER) (PU42H00020F1)
07-001	00	DECALS / NAME PLATE INSTAL / LABEL LOCATION (PU22T00050F1 - F4)
07-002	00	DECALS / NAME PLATE (PU22T00050F1 - F4)
07-003	00	DECALS / NAME PLATES (PU22T00048F3 - F4)
08-001	00	VALVE ASSY, CONTROL (PU30V00017F1)
08-002	00	VALVE ASSY O-RINGS (PU30V00017F1)
08-003	00	VALVE SECTION, CONTROL VALVE - SLEWING/SWING (PU30V00019F1)
08-004	00	VALVE SECTION, CONTROL VALVE - DOZER (PU30V00020F1)
08-005	00	VALVE SECTION, CONTROL VALVE - SUPPLY, TRAVEL INDEPENDENCE (PU30V00021F1)
08-006	00	VALVE SECTION, CONTROL VALVE - SERVICE (PU30V00022F1)
08-007	00	VALVE SECTION, CONTROL VALVE - ARM (PU30V00023F1)
08-008	00	VALVE SECTION, CONTROL VALVE - BOOM SWING (PU30V00024F1)
08-009	00	VALVE SECTION, CONTROL VALVE - TRAVEL RIGHT (PU30V00025F1)
08-010	00	VALVE SECTION, CONTROL VALVE - SUPPLY, CONNECTING (PU30V00026F1)
08-011	00	VALVE SECTION, CONTROL VALVE - TRAVEL LEFT (PU30V00027F1)
08-012	00	VALVE SECTION, CONTROL VALVE - BOOM (PU30V00028F1)
08-013	00	VALVE SECTION, CONTROL VALVE - BUCKET (PU30V00029F1)
08-014	00	VALVE ASSY, OVERLOAD RELIEF (PM22V00005F1-FG)

MidWestTech | Case CX17B Compact Crawler Excavator Parts Catalog | Publication 8751... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08-015	00	VALVE ASSY, ANTI-CAVITATION (PH21V00001F1)
08-016	00	PLUG ASSY, SERVICE SECTION (PH50T00001F1)
08-017	00	VALVE ASSY, RELIEF (PR22V00004F1-FA)
08-018	00	MOTOR ASSY, SWING (PU15V00019F1)
08-019	00	VALVE ASSY, RELIEF (SWING MOTOR) (PU22V00001F1)
08-020	00	MOTOR ASSY, PROPELLING (PU15V00021F1)
08-020	01	MOTOR ASSY, PROPELLING (PU15V00021F1)
08-021	00	PUMP ASSY (PU10V00014F1)
08-022	00	CYLINDER ASSY, BOOM (CANOPY) (PU01V00024F1)
08-023	00	CYLINDER ASSY, ARM (PU01V00036F1)
08-024	00	CYLINDER ASSY, BUCKET (PU01V00035F1)
08-025	00	CYLINDER ASSY, DOZER (PU01V00029F1)
08-026	00	CYLINDER ASSY, SWING (PU01V00028F1)
08-027	00	CYLINDER ASSY, CRAWLER (PU01V00030F1)
08-028	00	VALVE ASSY, PILOT (PX30V00043F1)
08-029	00	VALVE ASSY, PILOT (PROPELLING) (PM30V00019F1)
08-030	00	VALVE ASSY, SOLENOID (PX35V00003F1)
08-031	00	VALVE ASSY, RELIEF (YR22V00001F1)
08-032	00	VALVE ASSY, SELECTOR (PX30V00060F1, F2)
08-033	00	JOINT ASSY, SWIVEL (PA55V00001F1 - F4)
09-001	00	CYLINDER HEAD
09-002	00	VALVE MECHANISM
09-003	00	ROCKER COVER
09-004	00	CAMSHAFT
09-005	00	CRANKCASE
09-006	00	CRANKSHAFT BEARING
09-007	00	GEAR COVER
09-008	00	FLYWHEEL PLATE
09-009	00	OIL PAN
09-010	00	PISTONS & CONNECTING RODS
09-011	00	CRANKSHAFT & FLYWHEEL
09-012	00	MANIFOLDS
09-013	00	OIL SCREEN & OIL FILTER
09-014	00	WATER PUMP
09-015	00	THERMOSTAT
09-016	00	FAN & BELT
09-017	00	FUEL INJECTION SYSTEM
09-018	00	FUEL INJECTION NOZZLE
09-019	00	FILTER ASSY, WATER SEDIMENT
09-020	00	FILTER ASSY, FUEL
09-021	00	GOVERNOR PARTS
09-022	00	FUEL INJECTION PUMP MOUNTING
09-023	00	FUEL INJECTION PUMP
09-024	00	FUEL INJECTION PUMP DRIVE
09-025	00	STARTER ASSY
09-026	00	STARTER MOUNTING & GLOW PLUG
09-027	00	GLOW LAMP
09-028	00	ALTERNATOR MOUNTING
09-029	00	ALTERNATOR ASSY
09-030	00	MAGNETIC SWITCH
09-031	00	SPEED CONTROL

MidWestTech | Case CX17B Compact Crawler Excavator Parts Catalog | Publication 8751... Order the manual at mid-west-tech.com >

ENGINE ASSY (PU02P00013F1)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{PU02P00013F1}			ENGINE ASSY (PU02P00013F1); See Figure 01-005
1		{PU12P01019P1}		1	Gasket
2		{PU02P01026P1}		1	Separator Assy, Water; See Figure 01-010
3		{PU05P01018F1}		1	Tank Assy, Water, Sub; See Figure 01-006
5		{PU22P00001P1}		1	Pump, Fuel; See Figure 01-010
8		{PU05P01016P1}		1	Radiator Hose; See Figure 01-006
9		{PU05P01017P1}		1	Radiator Hose; See Figure 01-006
19		{PU21P01010P1}		1	Filter, Fuel; See Figure 01-010
21		{PU05P01145P1}		1	Guide
					MITSUBISHI DIESEL PART NO.
1		{30A30-00200}		1	Gasket; See Figure 09-012
2		{MM130-552}		1	Separator Assy, Water; See Figure 09-019
5		{31A60-00600}		1	Pump, Fuel; See Figure 09-017
6		{30636-25901}		1	Packing; See Figure 09-015
10		{30L66-10500}		1	Starter Assy; See Figure 09-025
12		{30A68-00801}		1	Alternator; See Figure 09-029
13		{31A90-00600}		1	Pressure Switch, Oil; See Figure 09-013
14		{MM432104}		1	Switch, Thermo; See Figure 09-015
16		{30L48-01200}		1	Fan; See Figure 09-016
17		{MD079696}		1	V-Belt; See Figure 09-016
18		{MM433-54801}		1	Thermostat; See Figure 09-015
19		{MM437-020}		1	Filter, Fuel; See Figure 09-020
20		{30A40-00103}		1	Filter, Oil; See Figure 09-013

MidWestTech | Case CX17B Compact Crawler Excavator Parts Catalog | Publication 8751... Order the manual at mid-west-tech.com >

FILTER ASSY, FUEL

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
					FILTER ASSY, FUEL
1		(VAMM437020)		1	Filter Assy, Fuel
101		(VAMM437142)		1	Head, Filter
102		(VAMM437143)		1	Valve Assy, Air Vent
103		(VAMM437145)		1	Lever
104		(VAMM404873)		1	Spring, Valve
105		(VAMM404875)		1	Screw
106		(VAMM404874)		1	O-Ring, Valve
107		(VAMM320881)		1	Cup, Filter
108		(VAMM409868)		1	Nut, Ring
109		(VAMM409868)		1	O-Ring, Filter Cup
110		(VAMM32088601)		1	Element, Filter
111		(VAMM437151)		1	O-Ring
112		(VAMM437152)		1	Plug
113		(VAMM437153)		1	Piston
114		(VAMM437154)		1	O-Ring
115		(VAMM437155)		1	Spring

MidWestTech | Case CX17B Compact Crawler Excavator Parts Catalog | Publication 8751... Order the manual at mid-west-tech.com >

ALTERNATOR MOUNTING

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
					ALTERNATOR MOUNTING
1		{VA30L6800900}		1	Plate, Adjusting
2		{VA9152000700}		1	Washer
3		{VAMD001515}		1	
4		{VAMD001521}		2	Washer
5		{VAMF241224}		1	
6		{VAMF430005}		1	
7		VAMF450405		1	WASHER, Spring
8		{VAMS450035}		1	Washer, Flat
9		{VA30L6801100}		1	Block, Alternator
10		{VA3746304900}		1	Bolt Set
11		{VAF103508040}		1	Bolt
12		{VAF251508000}		1	

MidWestTech | Case CX17B Compact Crawler Excavator Parts Catalog | Publication 8751... Order the manual at mid-west-tech.com >