NEW HOLLAND

COMPACT CRAWLER EXCAVATOR

E18SR

PARTS CATALOG

ASN PU08-05001~

87519740 NA

Issued 01Mar07

NEW HOLLAND

www.newhollandconstruction.com

MidWestTech | New Holland E18SR Compact Crawler Excavator Parts Catalog | Publication 87519740

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001	00	FILTER, FUEL - FILTER, OIL
01-001	00	FRAME ASSEMBLY, UPPER (PU52F00032F1) (PU24C00012F1 COVER)
01-002	00	BRACKET GROUP, SWING (PU02B00066F1, 76F1, 69F1, 65F1)
01-003	00	COUNTERWEIGHT INSTAL (PU60C00016F1, 15F1)
01-004	00	ENGINE ASSY (PU02P00013F1)
01-005	00	ENGINE INSTAL (PU02P00016F1)
01-006	00	RADIATOR INSTAL (PU05P00016F1, 17F1)
01-007	00	RADIATOR ASSY (PU05P00015F1)
01-008	00	AIR CLEANER ASSY (PU11P00006F1)
01-009	00	MUFFLER (PU12P00014F1)
01-010	00	FUEL LINES (PU21P00002F1)
01-010	01	FUEL LINES
01-011	00	TANK INSTAL, FUEL (PU20P00015F1, 14F1)
01-012	00	TANK INSTAL, HYDRAULIC (PU33H00016F1, 19F1)
01-013	00	CONTROL ASSY, ENGINE (PU11M00012F1)
01-014	00	POWER TAKE-OFF ASSY (PU30P00013F1)
01-015	00	MOTOR INSTAL, SWING (PU32W00012F1)
01-016	00	LUBRICATION LINES (PU71H00012F1)
01-017	00	CONTROL VALVE INSTAL (PU64H00019F1)
01-018	00	HYDRAULICS - PUMP TO CONTROL VALVE (PU30H00013F1)
01-019	00	HYDRAULICS - UPPER / SWING MOTOR TO CYLINDER (PU03H00016F1, PU19H00018F1, PU42H00024F1)
01-019	01	HYDRAULICS - UPPER / AT CONTROL VALVE
01-020	00	HYDRAULICS - UPPER / NIBBLER & BREAKER (PU03H00017F1)
01-021	00	HYDRAULICS - RETURN / NIBBLER & BREAKER (PU32H00018F1, 16F1)
01-021	01	HYDRAULICS - RETURN / NIBBLER & BREAKER / AT TANK & VALVE
01-022	00	CONTROLS, OPERATOR (PU03M00033F1)
01-023	00	COVER ASSY, OPERATOR CONTROLS (PU03M01367F1)
01-024	00	WRIST SUPPORT, OPERATOR CONTROLS (PU03M01368F1)
01-025	00	CONTROL BOX ASSY (LH) (PU03M00036F1)
01-026	00	LOCK ASSY (PU03M01122F1)
01-027	00	LEVER ASSY, CONTROL (CRAWLER) (PU50M00014F1)
01-028	00	LEVER ASSY, CONTROL (DOZER) (PU03M01308F1)
01-029	00	LEVER ASSY, CONTROL (PM50M00004F3) & PEDAL INSTAL (PU55M00003F1)
01-030	00	HYDRAULICS - REMOTE CONTROL LINES (PU64H00022F1, PU68H00033F1, 28F1, 34F1)
01-030	01	HYDRAULICS - REMOTE CONTROL LINES AT VALVE (PU06H00020F1, 15F1, 21F1)
01-031	00	HYDRAULICS - CONTROL LINES, VALVE INSTAL (PU64H00024F1, 25F1)
01-032	00	HYDRAULICS - CONTROL LINES, PROPEL (PU62H00003F1, 04F1, 05F1)
01-033	00	HYDRAULICS - CONTROL LINES, VALVE (AT TANK, PUMP, SOLENOID VALVE) (PU64H00023F1)
01-034	00	FLOORPLATE & FLOORMAT (PU03M00035F1)
01-035	00	CANOPY ASSY (PU06C00014F1)
01-036	00	WORK LAMP ASSY (PA80S00003F1)
01-037	00	SEAT ASSY INSTAL (PU25M00022F1)
01-038	00	GUARDS & COVERS (EXTERIOR, UPPER) (PU21C00017F1)
01-039	00	KEY ASSY (PW03M01870F1)
01-040	00	GAUGE ASSY, CLUSTER (PU59S00001F1)
01-041	00	BATTERY INSTAL (PU72E00012F1)
01-042	00	ELECTRICAL ASSY, UPPER (HARNESS) (PU03E00002F1)
01-042	01	ELECTRICAL ASSY, UPPER (HARDWARE)

MidWestTech | New Holland E18SR Compact Crawler Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-042	02	ELECTRICAL ASSY, UPPER (CABLE, FUSE, RELAY)
01-042	03	ELECTRICAL ASSY, UPPER (HORN)
01-043	00	HARNESS ASSY (AT AIR CLEANER) (PU11E00001F1)
01-044	00	RELAY ASSY (HARNESS) (PU24E00016F1)
02-001	00	LOWER FRAME GROUP (PU02F00034F1, PU53D00016F1, PU19H00016F1)
02-002	00	CYLINDER INSTAL (CRAWLER FRAME WIDTH) (PU01V00034F1)
02-003	00	SLEWING RING ASSEMBLY (PF40F00002F1)
02-004	00	IDLER ASSY (PU52D00017F1)
02-005	00	IDLER ASSEMBLY (PU52D00019F1)
02-006	00	IDLER ADJUSTER ASSY (PE54D00001F1)
02-007	00	TRACK ROLLER ASSY (PU64D00015F1)
02-008	00	SHOE ASSY, TRACK / BELT (PE61D00002F1, PE60D00003F1)
02-009	00	HYDRAULICS - LOWER / AT SWIVEL (PU02H00015F1, PU19H00017F1, PU13H00012F1)
02-009	01	HYDRAULICS - LOWER (PU12H00012F1, PU13H00013F1)
02-010	00	DOZER ASSY, FRAME (PU51B00023F1, 25F1, 26F1, 24F1)
03-001	00	BOOM ASSY, STANDARD 1.8M (6 FT) (PU02B00061F1, 64F1, 67F1)
03-002	00	HYDRAULIC LINES - BOOM 1.8M (6 FT) & CYLINDER (PU42H00026F1, 21F1, 23F1, 22F1)
03-003	00	HYDRAULIC LINES - BOOM 1.8M (6 FT) & ARM (NIBBLER & BREAKER) (PU42H00020F1, PU43H00017F1)
03-004	00	CYLINDER INSTAL (BOOM) (PU02B00077F1)
03-005	00	LAMP INSTAL & HARNESS (BOOM) (PU80S00012F1)
03-006	00	ARM ASSY, STANDARD 0.98M (3 FT 2 IN) (PU12B00049F1)
03-007	00	HYDRAULIC LINES - ARM, STANDARD 0.98M (3 FT 2 IN)(PU43H00018F1)
03-008	00	BUCKET INSTAL (PU61B00049F1)
04-001	00	TOOLS & ACCESSORIES (PM01T00002FE)
05-001	00	COUNTERWEIGHT INSTAL (PU60C00023F1)
05-002	00	PEDAL ASSY, OPERATOR CONTROL (PU14M00001F1)
05-003	00	ARM ASSY, LONG 1.20M (4 FT) (PU12B00052F1)
05-004	00	HYDRAULIC LINES - ARM, LONG 1.20M (4 FT) (PU43H00022F1)
05-005	00	HYDRAULIC LINES - BOOM & ARM 1.20M (4 FT) (NIBBLER & BREAKER) (PU42H00020F1)
07-001	00	DECALS / NAME PLATE INSTAL / LABEL LOCATION (PU22T00054F1 - F4)
07-002	00	DECALS / NAME PLATE (PU22T00054F1 - F4)
07-003	00	DECALS / NAME PLATE INSTAL (PU22T00048F3, F4)
08-001	00	VALVE ASSY, CONTROL (PU30V00017F1)
08-002	00	VALVE ASSY O-RINGS (PU30V00017F1)
08-003	00	VALVE SECTION, CONTROL VALVE - SLEWING/SWING (PU30V00019F1)
08-004	00	VALVE SECTION, CONTROL VALVE - DOZER (PU30V00020F1)
08-005	00	VALVE SECTION, CONTROL VALVE - SUPPLY, TRAVEL INDEPENDENCE (PU30V00021F1)
08-006	00	VALVE SECTION, CONTROL VALVE - SERVICE (PU30V00022F1)
08-007	00	VALVE SECTION, CONTROL VALVE - ARM (PU30V00023F1)
08-008	00	VALVE SECTION, CONTROL VALVE - BOOM SWING (PU30V00024F1)
08-009	00	VALVE SECTION, CONTROL VALVE - TRAVEL RIGHT (PU30V00025F1)
08-010	00	VALVE SECTION, CONTROL VALVE - SUPPLY, CONNECTING (PU30V00026F1)
08-011	00	VALVE SECTION, CONTROL VALVE - TRAVEL LEFT (PU30V00027F1)
08-012	00	VALVE SECTION, CONTROL VALVE - BOOM (PU30V00028F1)
08-013	00	VALVE SECTION, CONTROL VALVE - BUCKET (PU30V00029F1)
08-014	00	VALVE ASSY, OVERLOAD RELIEF (PM22V00005F1-FG)

MidWestTech | New Holland E18SR Compact Crawler Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08-015	00	VALVE ASSY, ANTI-CAVITATION (PH21V00001F1)
08-016	00	PLUG ASSY, SERVICE SECTION (PH50T00001F1)
08-017	00	VALVE ASSY, RELIEF (PR22V00004F1-FA)
08-018	00	MOTOR ASSY, SWING (PU15V00019F1)
08-019	00	VALVE ASSY, RELIEF (SWING MOTOR) (PU22V00001F1)
08-020	00	MOTOR ASSY, PROPELLING (PU15V00021F1)
08-020	01	MOTOR ASSY, PROPELLING (PU15V00021F1)
08-021	00	PUMP ASSY (PU10V00014F1)
08-022	00	CYLINDER ASSY, BOOM (CANOPY) (PU01V00024F1)
08-023	00	CYLINDER ASSY, ARM (PU01V00036F1)
08-024	00	CYLINDER ASSY, BUCKET (PU01V00035F1)
08-025	00	CYLINDER ASSY, DOZER (PU01V00029F1)
08-026	00	CYLINDER ASSY, SWING (PU01V00028F1)
08-027	00	CYLINDER ASSY, CRAWLER (PU01V00030F1)
08-028	00	VALVE ASSY, PILOT (PX30V00043F1)
08-029	00	VALVE ASSY, PILOT (PROPELLING) (PM30V00019F1)
08-030	00	VALVE ASSY, SOLENOID (PX35V00003F1)
08-031	00	VALVE ASSY, RELIEF (YR22V00001F1)
08-032	00	VALVE ASSY, SELECTOR (PX30V00060F1, F2)
08-033	00	JOINT ASSY, SWIVEL (PA55V00001F1 - F4)
09-001	00	CYLINDER HEAD
09-002	00	VALVE MECHANISM
09-003	00	ROCKER COVER
09-004	00	CAMSHAFT
09-005	00	CRANKCASE
09-006	00	CRANKSHAFT BEARING
09-007	00	GEAR COVER
09-008	00	FLYWHEEL PLATE
09-009	00	OIL PAN
09-010	00	PISTONS & CONNECTING RODS
09-011	00	CRANKSHAFT & FLYWHEEL
09-012	00	MANIFOLDS
09-013	00	OIL SCREEN & OIL FILTER
09-014	00	WATER PUMP
09-015	00	THERMOSTAT
09-016	00	FAN & BELT
09-017	00	FUEL INJECTION SYSTEM
09-018	00	FUEL INJECTION NOZZLE
09-019	00	FILTER ASSY, WATER SEDIMENT
09-020	00	FILTER ASSY, FUEL
09-021	00	GOVERNOR PARTS
09-022	00	FUEL INJECTION PUMP MOUNTING
09-023	00	FUEL INJECTION PUMP
09-024	00	FUEL INJECTION PUMP DRIVE
09-025	00	STARTER ASSY
09-026	00	STARTER MOUNTING & GLOW PLUG
09-027	00	GLOW LAMP
09-028	00	ALTERNATOR MOUNTING
09-029	00	ALTERNATOR ASSY
09-030	00	MAGNETIC SWITCH
09-031	00	SPEED CONTROL

MidWestTech | New Holland E18SR Compact Crawler Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

VALVE SECTION, CONTROL VALVE - SLEWING/SWING (PU30V00019F1)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{PU30V00019F1}			VALVE ASSY, CONTROL; SLEWING/SWING SECTION (PU30V00019F1)
1		NSS		1	NOT SERVICED SEPARATELY, BODY
2		NSS		1	NOT SERVICED SEPARATELY, SPOOL
3		NSS		1	NOT SERVICED SEPARATELY, SPRING, SEAT
4		NSS		1	NOT SERVICED SEPARATELY, SPRING
5		NSS		1	NOT SERVICED SEPARATELY, SPRING, SEAT
6		NSS		1	NOT SERVICED SEPARATELY, END, SPOOL
7		PH30V00003S006		1	POPPET
8		PH30V00003S007		1	SPRING
9		ZD12P01100		1	O-RING
10		PH30V00003S009		1	PLUG
11		PW30V01008S011		2	O-RING
12		PM30V00021S012		1	COVER
13		PM30V00021S013		1	COVER
14		PM30V00021S014		4	SOCKET, SCREW
K		{PU30V00019R100}		1	REPAIR KIT, Consists of Item 2x1, 3x1, 4x1, 5x1, 6x1

MidWestTech | New Holland E18SR Compact Crawler Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

FUEL INJECTION PUMP MOUNTING

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
					FUEL INJECTION PUMP MOUNTING
1		{VA30L9893110}		1	Pump Assy, Fuel Injection; See Figure 09-023
2		{VAMF241228}		4	Bolt With Washer
3		{VAMM432222}		AR	Shim; T=0.5
3		{VAMM432219}		AR	Shim; T=0.2
3		{VAMM432220}		AR	Shim; T=0.3
3		{VAMM433164}		AR	Shim; T=0.4
3		{VAMM433165}		AR	Shim; T=0.6
3		{VAMM433166}		AR	Shim; T=0.7
3		{VAMM433167}		AR	Shim; T=0.8
3		{VAMM433168}		AR	Shim; T=0.9
3		{VAMM433169}		AR	Shim; T=1.0
4		{VAMM501982}		1	Nipple, Swivel

MidWestTech | New Holland E18SR Compact Crawler Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

SPEED CONTROL

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
					SPEED CONTROL
1		{VA31A8701050}		1	Solenoid & Nut Set
101		{VAMM409671}		1	Nut
102		{VA31A8701500}		1	Solenoid, Tubular

MidWestTech | New Holland E18SR Compact Crawler Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >