KOBELCO

PARTS CATALOG

EXCAVATOR

SK170-8

ACERA MARK 8
TIER 3

87578850 NA

Issued 01June07

APPLICABLE:
SK170-8. . . . . YM04-U1601~

MidWestTech | Kobelco SK170-8 Acera Mark 8 Tier 3 Excavator Parts Catalog | Publication 87578850

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-01	00	FUEL FILTER & OIL FILTER ELEMENTS
02-01	00	UPPER FRAME ASSEMBLY (YM52F00049P1)
02-02	00	COUNTERWEIGHT INSTALLATION (YN60CU0004F1)
02-03	00	ENGINE INSTALLATION (YM02P00010F1) PAGE 1 OF 2
02-03	01	ENGINE INSTALLATION (YM02P00010F1) PAGE 2 OF 2
02-04	00	CONTROL ASSEMBLY, ENGINE (YB11M00004F1)
02-05	00	RADIATOR INSTALLATION (YM5P00021F1)
02-06	00	RADIATOR ASSEMBLY (YM05P00020F1)
02-07	00	RADIATOR GROUP (YB05P00006F1)
02-08	00	AIR CLEANER ASSEMBLY (YM11P00008F1)
02-09	00	DRY AIR CLEANER - COMPONENTS (YM11P00009F1)
02-10	00	MUFFLER ASSEMBLY (YM12P00009F1)
02-11	00	CONTROL LINES, BLOCK (STD) (YM64H00048F1)
02-12	00	CONTROL LINES, PUMP (YM06H00015F1)
02-13	00	FUEL LINES (YM21P00005F1), PAGE 1 OF 2
02-13	01	FUEL LINES (YM21P00005F1), PAGE 2 OF 2
02-14	00	FUEL TANK INSTALLATION (YM20P00020F1)
02-15	00	POWER TAKE OFF ASSY (YM30P00007F1)
02-16	00	HYDRAULIC TANK ASSEMBLY (YM33H00023F1)
02-17	00	SWING MOTOR - INSTALLATION (YM32W00006F1)
02-18	00	VALVE INSTALLATION, MAIN (YM64H00045F1)
02-19	00	HYD LINES, PUMP (YM30H00015F1)
02-20	00	HYD LINES UPPER (STD) (YM03H00023F1)
02-21	00	HYD LINES UPPER (2 WAY) (YM03H00025F1)
02-22	00	HYD LINES UPPER (STD & 2 WAY) (YM03H00021F1)
02-23	00	HYD LINES RETURN (YB32H00025F1)
02-24	00	CONTROL LINES, MAIN (YB06H00040F1) 1 OF 2
02-24	01	CONTROL LINES, MAIN (YB06H00040F1) 2 OF 2
02-25	00	CONTROL, OPERATORS (STD) (YN03M00148F1)
02-26	00	CONTROL, OPERATORS (YN03M00137F1)
02-27	00	CONTROL BOX ASSY (YN03M00149F1)
02-28	00	GRIP ASSY (YN03M01870F1)
02-29	00	GRIP ASSY (YN03M01968F1)
02-30	00	LEVER ASSY, PROPEL (YN50M00015F1)
02-31	00	PEDAL ASSY (YN55M00004F1)
02-32	00	RAIDO INSTALLATION (YN54E00010F1)
02-33	00	CLAMP ASSY (YN12P01163F1)
02-34	00	ARM REST (YN25M01183F1)
02-35	00	CONTROL LINES, REMOTE (SENSOR) (YN68H00129F1)
02-36	00	CONTROL LINES, BLOCK (2 WAY) (YM64H00053F1)
02-37	00	CONTROL LINES, MAIN (STD) (YB06H00036F1)
02-40	00	CONTROL LINES, VALVE (YM64H00046F1) PAGE 1 OF 2
02-40	01	CONTROL LINES, VALVE (YM64H00046F1) PAGE 2 OF 2
02-41	00	CONTROL LINES, PROPEL (YN62H00029F1)
02-42	00	PLATE INSTALLATION, FLOOR (YN03M00162F1)
02-43	00	MIRROR INSTALLATION (YN52C00017F1)
02-44	00	CAB INSTALLATION (YN02C00151F1)
02-45	00	CAB ASSY (YN02C00156F1) PAGE 1 OF 3
02-45	01	CAB ASSY (YN02C00156F1) PAGE 2 OF 3
02-45	02	CAB ASSY (YN02C00156F1) PAGE 3 OF 3
02-46	00	WINDOW, ROOF (YN02C03654F1)
02-47	00	WINDOW ASSY, FRONT (YN50C00005F1)
02-48	00	CAB DOOR PAGE 1 OF 2 (YN51C00010F2)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-48	01	CAB DOOR PAGE 2 OF 2 (YN51C00010F2)
02-49	00	SEAT INSTALLATION (YN25M00071F1)
02-50	00	SEAT BELT ASSY (YN25M00053F1)
02-51-01	00	GUARD INSTALLATION, (STANDARD) (YM21C00012F1)
02-51-02	00	GUARD INSTALLATION, (PATTERN CHANGER) (YM21C00018F1)
02-52-01	00	GUARD INSTALLATION, (TOP COVER) (YM21C00007F1)
02-53-01	00	GUARD INSTALLATION, (PILLARS) (YM21C00013F1)
02-54-01	00	GUARD INSTALLATION, (PLATES) (YB21C00018F1)
02-55-01	00	GUARD INSTALLATION, (PARTITION) (YM21C00014F1)
02-55-02	00	GUARD INSTALLATION, (PATTERN CHANGER) (YM21C00019F1)
02-56-01	00	GUARD INSTALLATION, (INSIDE) (YB21C00020F1)
02-57-01	00	GUARD INSTALLATION, (COVERS) (YM21C00009F1)
02-58-01	00	GUARD INSTALLATION, (SIDE PANEL) (YM21C00010F1)
02-59-01	00	GUARD INSTALLATION, (TOOL BOX) (YB21C00026F1)
02-59-02	00	GUARD INSTALLATION, (TOOL BOX) (PATTERN CHANGER) (YB21C00015F1)
02-60	00	RELAY BOX ASSY (YN24E00016F2)
02-61	00	COVER ASSY, UNDER (YM24C00006F1)
02-62	00	INSTRUMENT PANEL ASSEMBLY N&B (YN17M00063F1 & YN17M00056F1) PAGE 1 OF 3
02-62	01	INSTRUMENT PANEL ASSEMBLY N&B (YN17M00063F1 & YN17M00056F1) PAGE 2 OF 3
02-62	02	INSTRUMENT PANEL ASSEMBLY N&B (YN17M00063F1 & YN17M00056F1) PAGE 3 OF 3
02-63	00	CONTROLLER INSTAL (YM22E00020F1)
02-64	00	RELAY ASSEMBLY (YN24E00017F1)
02-65	00	BATTERY INSTALLATION (YM72E00004F1)
02-66	00	CONDITIONER ASSY, AIR (YM20M00011F1) PAGE 1 OF 3
02-66	01	CONDITIONER ASSY, AIR (YM20M00011F1) PAGE 2 OF 3
02-66	02	CONDITIONER ASSY, AIR (YM20M00011F1) PAGE 3 OF 3
02-67	00	CONDITIONER ASSY, AIR (YN20M00113F1)
02-68	00	DRYER ASSY, AIR (YM96V00008F1)
02-69	00	COMPRESSOR ASSY (YX91V00001F1)
02-70	00	CONDITIONER, AIR (YN20M00107F2) PAGE 1 OF 2
02-70	01	CONDITIONER, AIR (YN20M00107F2) PAGE 2 OF 2
02-72	00	HARNESS ASSY, CAB (YN14E00056F1)
02-73	00	HARNESS ASSEMBLY, UPP PLATE, FLOOR (YN13E00103F1)
02-74	00	HARNESS ASSY, UPPER (YN13E00125F1)
02-76	00	HYD LINES, SWIVEL (YN19H00047F1)
02-77	00	CONTROL LINES, (MULTI) (YM64H00038F1)
02-78	00	ELECTRICAL ASSEMBLY, UPPER (YM03E00022F1)
02-80	00	HARNESS ASSEMBLY, UPPER (BATTERY CABLES) (YN13E00137F1)
02-81	00	HARNESS ASSEMBLY, UPPER (AIR FILTER) (YN13E00137F1)
02-82	00	HARNESS ASSEMBLY, UPPER (FRAME WORK LIGHT) (YN13E00137F1)
02-83	00	HARNESS ASSEMBLY, UPPER (DRIER & COOLENT SWITCH) (YN13E00137F1)
02-84	00	HARNESS ASSEMBLY, UPPER (WATER & FUEL HEATERS) (YN13E00137F1)
02-85	00	HARNESS ASSEMBLY, UPPER (FRAME MOUNTING) (YN13E00137F1)
02-86	00	HARNESS ASSEMBLY, UPPER (PUMP P1, P2) (YN13E00137F1)
02-87	00	HARNESS ASSEMBLY, UPPER (HORN) (YN13E00137F1)
02-88	00	HARNESS ASSEMBLY, UPPER (CONTROLLER) (YN13E00137F1)

MidWestTech | Kobelco SK170-8 Acera Mark 8 Tier 3 Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-89	00	HARNESS ASSEMBLY, UPPER (SOLENOID VALVE) (YN13E00137F1)
02-90	00	HARNESS ASSEMBLY, UPPER (ENGINE) (YN13E00137F1), PAGE 1 OF 2
02-90	01	HARNESS ASSEMBLY, UPPER (ENGINE) (YN13E00137F1), PAGE 2 OF 2
03-01	00	FRAME, LOWER (YM02FU0010P1)
03-02	00	SLEWING RING ASSEMBLY (YM40F00007F1)
03-03	00	IDLER ASSY (YM52D00003F2)
03-04	00	IDLER ASSY (YN52D00009F1)
03-05	00	IDLER ADJUSTMENT ASSEMBLY (YM54D00003F2)
03-06	00	TRACK ROLLER ASSEMBLY (YM64D00005F1)
03-07	00	UPPER ROLLER ASSEMBLY (YN64D00032F1)
03-08	00	HYD LINES, SWIVEL (YM19HU0008F1)
03-09	00	HYD LINES, PROPEL (YM12HU0002F1)
03-10	00	HYD LINES, LOW (YM02HU0005F1)
04-01	00	BOOM INSTAL (YM02B00007F1)
04-02	00	BOOM ASSY (YM02BU0004F1)
04-03	00	BOOM INSTAL (YM02B00015F1)
04-04	00	BOOM INSTAL (YB02B00072F1)
04-05	00	HYD LINES, BOOM (BASE + STD) (YM42HU0002F1)
04-06	00	HYD LINES, BOOM (NIBBLER & BREAKER) (YM42HU0005F1)
04-07	00	HYD LINES, BOOM (BASE + STD) (YM42HU0008F1)
04-08	00	CONTROL LINES, REMOTE (2 WAY - FOOT) (YM68H00025F1)
04-09	00	ARM INSTALLATION, (3.1M, STANDARD), (YM12BU0025F1) PAGE 1 OF 2
04-09	01	ARM INSTALLATION, (3.1M, STANDARD), (YM12BU0025F1) PAGE 2 OF 2
04-10	00	ARM 3.10M (YM12BU0018F1)
04-11	00	HYDRAULIC LINES - ARM (STD) (YM43H00012F1)
04-12	00	BUCKET INSTALLATION (YM61B00002F1)
05-01	00	TOOL & ACCESSORY (YM01T00002F1)
06-01	00	MIRROR INSTALLATION (YN52C00019F1)
06-03	00	ALARM ASSY (YN53E00016F1)
06-07	00	SHOE ASSY (YM60D00001F1, F2, F4, F5)
06-08	00	STEP INSTAL (YN41CU0002F1, F3, F5)
06-09	00	VANDALISM GUARD (YM25C00001F1) PAGE 1 OF 2
06-09	01	VANDALISM GUARD (YM25C00001F1) PAGE 2 OF 2
06-10	00	CYLINDER INSTALLATION, BOOM (YM02B00014F1)
06-11	00	HYDRAULIC LINES, ARM (NIBBLER & BREAKER) (YM43HU0003F1)
06-12	00	HYDRAULIC LINES, ARM STOP VALVE (NIBBLER & BREAKER) (24100P1006F1)
06-13	00	CONNECTOR ASSY (LP43H00004F1)
06-14	00	ARM INSTALLATION, (3.1M, NIBBLER & BREAKER), (YM12BU0025F2) PAGE 1 OF 2
06-14	01	ARM INSTALLATION, (3.1M, NIBBLER & BREAKER), (YM12BU0025F2) PAGE 2 OF 2
07-01	00	NAME PLATE INSTALLATION, (EXTERIOR) LOCATION (YM22TU0012F1)
07-01	01	NAME PLATE INSTALLATION, (EXTERIOR) (YM22TU0012F1)
07-02	00	NAME PLATE INSTALLATION, BOOM (LC22T00017F1)
07-03	00	NAME PLATE INSTALLATION, LOCATION (YN22T00340F1)
07-04	00	NAME PLATE INSTALLATION, LOCATION (YN22T00340F3)
07-05	00	NAME PLATE INSTALLATION, LOCATION (YN22T00340F4)

MidWestTech | Kobelco SK170-8 Acera Mark 8 Tier 3 Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

BOOM ASSY (YM02BU0004F1)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{}			BOOM ASSY,HOE YM02BU0005F1 Incl. Ref. 1 & 2
1		{YM02BU0008P1}		1	BOOM,HOE
2		YM02B01036P1		4	BUSHING
		{}			BOOM,HOE YM02BU0006P1 Incl. Ref. 3 - 8
3		2416T9878		2	BLOCK
4		2418T22409		1	PLATE
5		YN02B01619P1		6	BLOCK
6		YN02B01616P1		2	BLOCK
7		{YN02B01882P1}		4	BLOCK
8		{YN02BU1011P1}		2	BLOCK

MidWestTech | Kobelco SK170-8 Acera Mark 8 Tier 3 Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

CYLINDER HEAD COVERS (101570140003)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		4895360		4	ISOLATOR
2		2830281		4	SCREW, SELF TAPPING, M2.9 x 6.5mm Self Tapping
3		4895214		4	SCREW, M08x1.25x33mm
4		2852032		1	COVER
5		2830775		1	SLINGER
6		2852033		4	GASKET
7		2830784		1	COVER, VALVE, Incl. Ref. 2, 5, 8
8		2830769		1	COVER
9		4895202		1	CAP, FILLER
10		4895296		1	SEAL, Alternate Part to 4892808
10		4892808		1	SEAL, Alternate Part to 4895296
11		2852894		1	COVER

MidWestTech | Kobelco SK170-8 Acera Mark 8 Tier 3 Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

HEAT EXCHANGER - ENGINE (101570840002)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		4899019		15	SCREW, M08x1.25x35mm
2		2853782		1	Head, Filter, Incls. Refs. 3 - 8
3		2853781		1	PLUG
4		4896404		1	PLUNGER, PRESSURE REGULATOR
5		4895045		1	SPRING
6		4899035		1	O-RING
7		4896410		1	VALVE, PRESSURE RELIEF
		4899643		1	Head, Filter, Incls Refs. 8
8		4893391		1	ADAPTER
9		4896406		1	COOLER, OIL
10		2830559		1	GASKET, CORE
11		4896409		1	GASKET, HEAD
12		REF		1	INSTRUCTION, See Figure 09-26

MidWestTech | Kobelco SK170-8 Acera Mark 8 Tier 3 Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >