CASE

PROFESSIONAL PARTNER

OPERATOR'S MANUAL

CRAWLER DOZER

1850K SERIES 3

87611939NA

Issued 12-2006

MidWestTech | Case 1850K Series 3 Crawler Dozer Operator's Manual | Publication 87611... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SUBJECT	PAGE
SAFETY RULES	I-VIII
Decommissioning the machine	VIII
Dispose of wastes in an appropriate manner	VIII
FOREWORD	IX
IDENTIFICATION DATA	2
COMFORT LEVELS	4
GENERAL SPECIFICATIONS	5
Main dimensions 1850K BD	8
Main dimensions 1850K PAT	9
Stability	11
List and location of safety decals	12
Preliminary instructions and break-in period	25
OPERATION RULES	26
First operation decal	27
Installing Angledozer (HA) blade hoses	28
Bulldozer equipement installation (BD)	28
CONTROLS AND INSTRUMENTS	30
OPERATION INSTRUCTIONS	45
General information	45
Prior to starting	45
Engine starting	45
Stopping the machine	48
Stopping the engine	49
Driver's seat (depending upon the versions)	50
Fuel reservoir	51
Blade adjustment	51
Cab tilting	52
Lowering the cab	53
Oil refilling and bleeding of the cab tilting system	53
Brakes disengagement	54
Towing the machine	56
Moving the machine with outside means	57
Instructions for lowering the equipment to the ground with engine inoperative	58
Transporting the machine	58
Long storage of the machine	59
Cold climate precautions	59
Starting the machine at low temperatures	60
Starting the machine with booster batteries	61
MACHINE OPERATION	62
CAB	72

MidWestTech | Case 1850K Series 3 Crawler Dozer Operator's Manual | Publication 87611... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SUBJECT **PAGE**

MAINTENANCE 77
- Maintenance operations 78
- General maintenance and lubrication diagram 80
- List of programmed maintenance 81
- Every 10 hours work 83
- Every 100 hours work 85
- Every 250 hours work 88
- Every 500 hours work 89
- Every 1000 hours work 95
- Every 2000 hours work 102
- Every 3000 hours work 106
- As required 107

ELECTRICAL SYSTEM 112
- Electrical diagram of protection tree 117

TABLE OF FLUIDS USED 118

GENERAL ELECTRICAL DIAGRAM ..... Inside back cover

MidWestTech | Case 1850K Series 3 Crawler Dozer Operator's Manual | Publication 87611... Order the manual at mid-west-tech.com >