JX60, JX70 JX80, JX90 and JX95 Straddle Mount Tractors

Parts Catalog

Print No. 87635890PC
Issued 03/2019

CASE IH AGRICULTURE

MidWestTech | Case JX60, JX70 JX80, JX90, JX95 Straddle Mount Tractor Parts Catalog |...
Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

0.0042	01	SERVICE PARTS CATALOGUE AND BINDER
0.01.0		OPTIONAL EQUIPMENT
0.01.1		INITIAL STOCKING LIST (LIST A)
0.05.4	01	MAINTENANCE PARTS - FILTERS
0.05.4	02	MAINTENANCE PARTS - STARTER MOTOR, ALTERNATOR, BELTS
0.05.4	03	MAINTENANCE PARTS - FUSES
0.05.4	04	MAINTENANCE PARTS - BULBS
0.05.4	05	MAINTENANCE PARTS - PUMPS
D.I.A.		DEALER INSTALLED ACCESSORY KITS INDEX
MAIN		MAIN SECTIONS
SEC. 01	01	ENGINE
SEC. 01	02	ENGINE
SEC. 02		ENGINE EQUIP.
SEC. 03		TRANSMISSION
SEC. 04		FRONT AXLE
SEC. 05		REAR AXLE
SEC. 06		ELECTRICAL
SEC. 07		HYDRAULICS
SEC. 08		SHEET METAL
SEC. 09		LINKAGE
SEC. 10		DRIVER'S COMPARTMENT
SEC. 11	01	TRACTION
SEC. 11	02	TRACTION
SEC. 13		DECALS
0.02.0 SEC.	01	ENGINE
0.02.0 SEC.	02	ENGINE
0.02.1		FPT ENGINE - TIER 2 ENGINE
0.02.1/01		FPT ENGINE - TIER 2 ENGINE
0.02.1/02		FPT ENGINE - TIER 2 ENGINE
0.02.1/03		FPT ENGINE - TIER 2 ENGINE
0.02.1/04		TTF ENGINE - TIER 1 ENGINE
0.02.1/05		VAR - 747, 391102 - TTF ENGINE TIER 2 - ENGINE
0.04.0		BLOCK ASSEMBLY - TIER 2 ENGINE
0.04.0/01		BLOCK ASSEMBLY - TIER 2 ENGINE

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

0.04.0/02		CRANKCASE AND CYLINDERS - TIER 2 ENGINE
0.04.0/03		CRANKCASE AND CYLINDERS - TIER 2 ENGINE
0.04.0/04		CRANKCASE - TIER 1 ENGINE
0.04.0/05		VAR - 747, 391102 - TTF ENGINE TIER 2 - CRANKCASE AND CYLINDERS
0.04.2		OIL PAN - TIER 2 ENGINE
0.04.2/01	01	OIL SUMP - TIER 2 ENGINE
0.04.2/01	02	OIL SUMP - TIER 2 ENGINE
0.04.2/02	01	OIL SUMP - TIER 1 ENGINE
0.04.2/02	02	OIL SUMP - TIER 1 ENGINE
0.04.2/02	03	OIL SUMP - TIER 1 ENGINE
0.04.2/02	04	OIL SUMP - TIER 1 ENGINE
0.04.2/03	01	VAR - 747, 391102 - TTF ENGINE TIER 2 - OIL SUMP
0.04.2/03	02	VAR - 747, 391102 - TTF ENGINE TIER 2 - OIL SUMP
0.04.3	01	COVERS & GASKETS, FRONT - TIER 2 ENGINE
0.04.3	02	COVERS & GASKETS, REAR - TIER 2 ENGINE
0.04.3/01	01	CRANKCASE COVERS - TIER 1 ENGINE
0.04.3/01	02	CRANKCASE COVERS - TIER 1 ENGINE
0.04.3/02	01	VAR - 747, 391102 - TTF ENGINE TIER 2 - COVERS & GASKETS, FRONT
0.04.3/02	02	VAR - 747, 391102 - TTF ENGINE TIER 2 - COVERS & GASKETS
0.04.5		BREATHER - TIER 1 ENGINE
0.06.0	01	CYLINDER HEAD ASSEMBLY - TIER 2 ENGINE
0.06.0	02	VALVES - TIER 2 ENGINE
0.06.0/01	01	CYLINDER HEAD ASSEMBLY - TIER 2 ENGINE
0.06.0/01	02	VALVES - TIER 2 ENGINE
0.06.0/02	01	CYLINDER HEAD - TIER 2 ENGINE
0.06.0/02	02	VALVES - TIER 2 ENGINE
0.06.0/03	01	CYLINDER HEAD - TIER 2 ENGINE
0.06.0/03	02	VALVES - TIER 2 ENGINE
0.06.0/04	01	CYLINDER HEAD - TIER 1 ENGINE
0.06.0/04	02	CYLINDER HEAD - TIER 1 ENGINE
0.06.0/04	03	CYLINDER HEAD - TIER 1 ENGINE
0.06.0/05	01	VAR - 747, 391102 - TTF ENGINE TIER 2 - HEAD CYLINDER
0.06.0/05	02	VAR - 747, 391102 - TTF ENGINE TIER 2 - HEAD CYLINDER
0.06.0/05	03	VAR - 747, 391102 - TTF ENGINE TIER 2 - HEAD CYLINDER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

0.07.1		INTAKE MANIFOLD - TIER 2 ENGINE
0.07.1/01		INTAKE MANIFOLD - TIER 2 ENGINE
0.07.1/02		INTAKE MANIFOLD - TIER 2 ENGINE
0.07.1/03		INTAKE MANIFOLD - TIER 2 ENGINE
0.07.1/04	01	INTAKE MANIFOLD - TIER 1 ENGINE
0.07.1/04	02	INTAKE MANIFOLD - TIER 1 ENGINE
0.07.1/04	03	INTAKE MANIFOLD - TIER 1 ENGINE
0.07.1/04	04	INTAKE MANIFOLD - TIER 1 ENGINE
0.07.1/05	01	VAR - 747, 391102 - TTF ENGINE TIER 2 - INTAKE MANIFOLD
0.07.1/05	02	VAR - 747, 391102 - TTF ENGINE TIER 2 - INTAKE MANIFOLD
0.07.6		EXHAUST MANIFOLD - TIER 2 ENGINE
0.07.6/01		EXHAUST MANIFOLD - TIER 2 ENGINE
0.07.6/02		EXHAUST MANIFOLD - TIER 2 ENGINE
0.07.6/03		EXHAUST MANIFOLD - TIER 2 ENGINE
0.07.6/04	01	EXHAUST MANIFOLD - TIER 1 ENGINE
0.07.6/04	02	EXHAUST MANIFOLD - TIER 1 ENGINE
0.07.6/05	01	VAR - 747, 391102 - TTF ENGINE TIER 2 - EXHAUST MANIFOLD
0.07.6/05	02	VAR - 747, 391102 - TTF ENGINE TIER 2 - EXHAUST MANIFOLD
0.08.0		CRANKSHAFT - TIER 2 ENGINE
0.08.0/01		CRANKSHAFT - TIER 2 ENGINE
0.08.0/02		CRANKSHAFT - TIER 2 ENGINE
0.08.0/03	01	CRANKSHAFT - TIER 1 ENGINE
0.08.0/03	02	CRANKSHAFT - TIER 1 ENGINE
0.08.0/04	01	VAR - 747, 391102 - TTF ENGINE TIER 2 - CRANKSHAFT
0.08.0/04	02	VAR - 747, 391102 - TTF ENGINE TIER 2 - CRANKSHAFT
0.08.1	01	CONNECTING ROD - TIER 2 ENGINE
0.08.1/01		CONNECTING ROD - TIER 2 ENGINE
0.08.1/02		CONNECTING ROD - TIER 2 ENGINE
0.08.1/03		CONNECTING ROD - TIER 2 ENGINE
0.08.1/04		CONNECTING ROD - TIER 1 ENGINE
0.08.1/05		VAR - 747, 391102 - TTF ENGINE TIER 2 - CONNECTING ROD
0.08.2		PISTON ASSEMBLY - TIER 2 ENGINE
0.08.2/01	01	PISTON - TIER 1 ENGINE
0.08.2/01	02	PISTON - TIER 1 ENGINE

Order the manual at mid-west-tech.com >

BRAKE PEDALS - LEVERS, PEDALS AND SHAFT

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		5091657		1	PEDAL RH
2		5089697		1	PEDAL LH
3		5089699		1	PEDAL RH
4		5089700		1	PEDAL LH
5		87302109		1	BRACKET
6		5089912		2	GROMMET
7		5089915		2	SPRING
8		5085959		1	PLATE
9		5122339		2	BUSHING 25.05mm ID x 28mm OD x 15mm L
10		5118949		1	WASHER 30.5mm ID x 50mm OD x 2mm Thk
11		5118944		1	SHAFT
12		4968813		1	BOLT Hex, M16 x 1.5 x 32mm
13		11067376		1	SNAP RING M25, Ext
14		5117525		1	WASHER 25.5mm ID x 36mm OD x 2mm Thk
15		10571979		2	LOCK WASHER M12
16		15540421		2	SCREW Hex, M12 x 1.25 x 30mm, Cl 8.8, Full Thd
17		10571879		4	LOCK WASHER 10.2mm ID x 18.1mm OD x 2.2mm Thk
18		11306921		4	SCREW Hex, M10 x 1.25 x 30mm, Cl 8.8, Full Thd
19		14600970		1	LOCK PIN M5 x 22, Slotted
20		5094994		1	BELLOWS
21		5095083		1	PLUG
22		84343792		1	SHAFT Incl.23
23		13408411		2	LUBE NIPPLE 90 Degree , M10 x1
24	1	5097634		1	SUPPORT

(1) 12 x 4 Synchromesh Transmission, VAR.116, 335116

JX60-STRADDLE MOUNT TRACTOR JX70-STRADDLE MOUNT TRACTOR
JX80-STRADDLE MOUNT TRACTOR JX90-STRADDLE MOUNT TRACTOR
JX95-STRADDLE MOUNT TRACTOR

Order the manual at mid-west-tech.com >

ROLLBAR - FRAME AND COVERING - C5973

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		5096823		1	ROPS
2		5096976		1	ROPS RH
3		5096977		1	ROPS LH
4		5096975		1	ROPS
5		15985234		2	SCREW M18 x 1.5 x 100mm
6		12575021		2	NUT M18 x 1.5, Cl 10
7		10520321		2	WASHER 18.4mm ID x 32mm OD x 4mm Thk
8		12646701		2	WASHER 8.15mm ID x 20mm OD x 2mm Thk
9		16104111		2	NUT Prevailing Torque, M8, 1.25 Pitch, 10.6mm High, Cl 08, ZND
10		16233921		2	SCREW Hex, M8 x 1.25 x 90mm M8x90
11		5095361		2	PIN
12		5095193		2	CABLE
13		5091685		1	CABLE
14		5095192		2	PIN
15		5093311		2	PLATE
16		5093310		2	PLATE
17		5096971		1	SUPPORT RH
17		5096973		1	SUPPORT LH
18		5093308		8	WASHER 18.5mm ID x 60mm OD x 8mm Thk
19		5093307		8	PLUG
20		5093306		8	SPACER 18.5mm ID x 26.5mm OD x 46mm L
21		5187306		8	SCREW
22		10572279		8	WASHER M18
23		10721021		8	NUT M18 x 1.5, Cl 10
24		5095360		2	PIN 17.8mm OD x 103mm L

JX60-STRADDLE MOUNT TRACTOR JX70-STRADDLE MOUNT TRACTOR JX80-STRADDLE MOUNT TRACTOR JX90-STRADDLE MOUNT TRACTOR JX95-STRADDLE MOUNT TRACTOR

Order the manual at mid-west-tech.com >

VAR - 190, 335878 - DELUXE VINYL SEAT, SUPPORT AND COMPONENT PARTS

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		5080201		1	BASE
2		5080202		1	ADJUSTER
3		5080203		1	KNOB
4		5080204		1	PIN
5		5080205		1	ROD
6		5080206		1	ROLLER Assy
7		5080207		1	ROLLER
8		5080208		1	COVER
9		5080209		1	TAPE
10		5080210		1	SPRING
11		5080211		4	BUSHING
12		5080212		2	BUSHING
13		5080213		2	BUMPER
14		5080214		4	ROLLER
15		5080215		1	GAS STRUT
16		5080216		2	PIN
17		5080217		2	RING
18		5080218		1	PLATE
19		5080219		1	BOLT
20		5080220		1	SUPPORT
21		5080221		1	SUSPENSION
22		5080222		1	SUSPENSION
23		5080223		1	SUSPENSION
24		5080224		4	CLIP
25		5080225		4	BOLT
26		5080226		2	BOLT
27		5080227		2	BOLT
28		5080228		1	TENSIONER

JX60-STRADDLE MOUNT TRACTOR JX70-STRADDLE MOUNT TRACTOR JX80-STRADDLE MOUNT TRACTOR JX90-STRADDLE MOUNT TRACTOR JX95-STRADDLE MOUNT TRACTOR

MidWestTech | Case JX60, JX70 JX80, JX90, JX95 Straddle Mount Tractor Parts Catalog |... Order the manual at mid-west-tech.com >