KOBELCO

PARTS CATALOG

EXCAVATOR

SK295-8

ACERA MARK 8

TIER 3

87659315 NA
Replaces 87632269 NA

Issued 01Sept07

APPLICABLE:
SK295-8 . . . . . LB05-U0801~

MidWestTech | Kobelco SK295-8 Acera Mark 8 Tier 3 Hydraulic Excavator Parts Catalog | Publication 87659315

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-01	00	FUEL FILTER & OIL FILTER ELEMENTS
02-01	00	UPPER FRAME ASSEMBLY (LB52F00043F1)
02-02	00	COUNTERWEIGHT INSTALLATION (LQ60C00136F1)
02-03	00	ENGINE INSTALLATION (LB02P00014F1), PAGE 1 OF 2
02-03	01	ENGINE INSTALLATION (LB02P00014F1), PAGE 2 OF 2
02-04	00	HYDRAULIC LINES RETURN (LB32H00005F1)
02-05	00	RADIATOR INSTALLATION (LQ05P00042F1)
02-06	00	RADIATOR ASSEMBLY (LB05P00018F1)
02-07	00	RADIATOR GROUP (LQ05P00036F1)
02-08	00	AIR CLEANER ASSEMBLY (LQ11P00022F1)
02-09	00	DRY AIR CLEANER - COMPONENTS (LQ11P00023F1)
02-10	00	MUFFLER ASSEMBLY (LQ12P00022F1)
02-11	00	CONTROL LINES, BLOCK (PT-STD) (YN64H00183F1)
02-12	00	CONTROL LINES, PUMP (YN06H00077F1)
02-13	00	FUEL LINES (LQ21P00011F1)
02-14	00	FUEL TANK INSTALLATION (LQ20P00033F1)
02-15	00	POWER TAKE OFF ASSEMBLY (LB30P00005F1)
02-16	00	HYDRAULIC TANK ASSEMBLY (LQ33H00029F1)
02-17	00	SWING MOTOR - INSTALLATION (LB32W00011F1)
02-18	00	JOINT INSTALLATION, SWIVEL (YN19H00053F1)
02-19	00	VALVE INSTALLATION, (STANDARD) (LB64H00049F1)
02-20	00	HYDRAULIC LINES, PUMP (LQ30H00046F1)
02-21	00	HYDRAULIC LINES, SWIVEL (LB19H00005F1)
02-22	00	CONTROL LINES, MAIN (LB06H00022F1)
02-23	00	GUARD INSTALLATION, (STANDARD) (LQ21C00047F2)
02-24	00	GUARD INSTALLATION, (PATTERN CHANGER) (LQ21C00072F2)
02-25	00	GUARD INSTALLATION, (INSIDE) (LQ21C00048F1)
02-26	00	GUARD INSTALLATION, (HOOD) (LQ21C00049F1)
02-27	00	GUARD INSTALLATION, (SIDE PANEL) (LQ21C00050F1)
02-28	00	GUARD INSTALLATION, (PARTITION) (LQ21C00051F1)
02-29	00	GUARD INSTALLATION, (PILLARS) (LQ21C00048F2)
02-30	00	GUARD INSTALLATION, (TOOL BOX) (LQ21C00048F2)
02-30-01	00	TOOL BOX ASSEMBLY (LQ21C00065F1)
02-31	00	GUARD INSTALLATION, (COVERS) (LQ21C00048F2)
02-32	00	GUARD INSTALLATION, (COMMON) (LQ21C00048F2) & (LQ21C00073F2)
02-33	00	HYDRAULIC LINES UPPER (BASE) (LB03H00017F1)
02-34	00	HYDRAULIC LINES UPPER (STANDARD) (YN03H00126F1)
02-35	00	CONTROL LINES, REMOTE (SENSOR) (YN68H00129F1)
02-36	00	CONTROL LINES, PROPEL (LQ62H00010F1)
02-37	00	CONTROL LINES, (MULTI) (LB64H00028F1)
02-38	00	CONTROL LINES, BLOCK (2 WAY) (LQ64H00148F1)
02-40	00	ALARM ASSEMBLY (YN53E00016F1)
02-41	00	MIRROR INSTALLATION (YN52C00019F1)
02-42	00	MIRROR INSTALLATION, REAR (YN52C00017F1)
02-43	00	PLATE INSTALLATION, FLOOR (YN03M00162F1)
02-43-01	00	PLATE INSTAL, FLOOR (SINGLE PEDAL TRAVEL), (YN03MU0003F1)
02-44	00	CAB INSTALLATION (YN02C00151F1)
02-45	00	CAB ASSEMBLY (YN02C00156F1), PAGE 1 OF 3
02-45	01	CAB ASSEMBLY (YN02C00156F1), PAGE 2 OF 3
02-45	02	CAB ASSEMBLY (YN02C00156F1), PAGE 3 OF 3
02-46	00	WINDOW, ROOF (YN02C03654F1)

MidWestTech | Kobelco SK295-8 Acera Mark 8 Tier 3 Hydraulic Excavator Parts Catalog |... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-47	00	WINDOW ASSEMBLY, FRONT (YN50C00005F1)
02-48	00	CAB DOOR (YN51C00010F2), PAGE 1 OF 2
02-48	01	CAB DOOR (YN51C00010F2), PAGE 2 OF 2
02-49	00	SEAT INSTALLATION (YN25M00071F1)
02-50	00	SEAT BELT ASSEMBLY (YN25M00053F1)
02-51	00	CONTROLS, OPERATOR (YN03M00137F1)
02-51-00	00	CONTROLS, OPERATOR (STANDARD) (YN03M00148F1)
02-52	00	CONTROL BOX ASSEMBLY (YN03M00149F1)
02-53	00	GRIP ASSEMBLY (YN03M01968F1)
02-54	00	GRIP ASSEMBLY (YN03M01870F1)
02-55	00	LEVER ASSEMBLY, PROPEL (YN50M00015F1)
02-56	00	PEDAL ASSEMBLY (YN55M00004F1)
02-57	00	RADIO INSTALLATION (YN54E00010F1)
02-58	00	CLAMP ASSEMBLY (YN12P01163F1)
02-59	00	ARM REST (YN25M01183F1)
02-60	00	COVER ASSEMBLY, UNDER (LQ24C00023F1)
02-61	00	CONTROLLER INSTALLATION (LB22E00019F1)
02-62	00	INSTRUMENT PANEL ASSEMBLY NIBBLER & BREAKER (YN17M00059F1 & YN17M00056F1), PAGE 1 OF 3
02-62	01	INSTRUMENT PANEL ASSEMBLY NIBBLER & BREAKER (YN17M00059F1 & YN17M00056F1), PAGE 2 OF 3
02-62	02	INSTRUMENT PANEL ASSEMBLY NIBBLER & BREAKER (YN17M00059F1 & YN17M00056F1), PAGE 3 OF 3
02-62-00	00	GAUGE ASSEMBLY, CLUSTER (YN59S00021F2)
02-64	00	BATTERY INSTALLATION (LQ72E00005F1)
02-65	00	CONDITIONER ASSEMBLY, AIR (LQ20M00045F1), PAGE 1 OF 3
02-65	01	CONDITIONER ASSEMBLY, AIR (LQ20M00045F1), PAGE 2 OF 3
02-65	02	CONDITIONER ASSEMBLY, AIR (LQ20M00045F1), PAGE 3 OF 3
02-65-00	00	COMPRESSOR ASSEMBLY (YX91V00001F1)
02-65-01	00	DRIER ASSEMBLY, AIR (LQ20M00045F1)
02-66	00	CONDITIONER ASSEMBLY, AIR (YN20M00113F1)
02-67	00	CONTROL VALVE INSTALLATION - NIBBLER & BREAKER (YN64H00338F1)
02-68	00	CONTROL LINES, BLOCK (STANDARD) (LQ64H00137F1)
02-69	00	CONDITIONER, AIR (YN20M00107F2), PAGE 1 OF 2
02-69	01	CONDITIONER, AIR (YN20M00107F2), PAGE 2 OF 2
02-70	00	HARNESS ASSEMBLY, UPPER (VAR. OPT.RELIEF) (LB13E00010F1)
02-71	00	HARNESS ASSEMBLY, UPPER (PATT. CHNG.) (LQ13E00046F1)
02-72	00	HARNESS ASSEMBLY, CAB (YN14E00056F1)
02-73	00	HARNESS ASSEMBLY, UPPER PLATE, FLOOR (LQ13E00044F1)
02-74	00	HYDRAULIC LINES UPPER (2 WAY) (LB03H00021F1)
02-75	00	CONTROL LINES, VALVE (NIBBLER & BREAKER) (LB64H00034F1), PAGE 1 OF 2
02-75	01	CONTROL LINES, VALVE (NIBBLER & BREAKER) (LB64H00034F1), PAGE 2 OF 2
02-76	00	CONTROL LINES, VALVE (STANDARD) (LB64H00064F1)
02-78	00	ELECTRICAL ASSEMBLY, UPPER (LQ03E00013F1)
02-79	00	COUNTERWEIGHT INSTALLATION (X-HEAVY) (LQ60C00125F1)
02-80	00	HARNESS ASSEMBLY, UPPER (BATTERY CABLES) (LQ13E00067F1), PAGE 1 OF 12
02-80	01	HARNESS ASSEMBLY, UPPER (AIR FILTER) (LQ13E00067F1), PAGE 2 OF 12
02-80	02	HARNESS ASSEMBLY, UPPER (FRAME WORK LIGHT) (LQ13E00067F1), PAGE 3 OF 12
02-80	03	HARNESS ASSEMBLY, UPPER (DRIER & COOLENT SWITCH) (LQ13E00067F1), PAGE 4 OF 12

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-80	04	HARNESS ASSEMBLY, UPPER (WATER & FUEL HEATERS) (LQ13E00067F1), PAGE 5 OF 12
02-80	05	HARNESS ASSEMBLY, UPPER (FRAME MOUNTING) (LQ13E00067F1), PAGE 6 OF 12
02-80	06	HARNESS ASSEMBLY, UPPER (PUMP P1, P2) (LQ13E00067F1), PAGE 7 OF 12
02-80	07	HARNESS ASSEMBLY, UPPER (HORN) (LQ13E00067F1), PAGE 8 OF 12
02-80	08	HARNESS ASSEMBLY, UPPER (CONTROLLER) (LQ13E00067F1), PAGE 9 OF 12
02-80	09	HARNESS ASSEMBLY, UPPER (SOLENOID VALVE) (LQ13E00067F1), PAGE 10 OF 12
02-80	10	HARNESS ASSEMBLY, UPPER (ENGINE) (LQ13E00067F1), PAGE 11 OF 12
02-80	11	HARNESS ASSEMBLY, UPPER (ENGINE) (LQ13E00067F1), PAGE 12 OF 12
03-01	00	CAP ASSEMBLY (LB01F01018F1)
03-02	00	FRAME, LOWER (LB02F00020F1)
03-02-01	00	FRAME, LOWER (H&W) (LB02FU0006P1)
03-03	00	FRAME, LOWER ,GROUP (LB01F00009F1)
03-04	00	SLEWING RING ASSEMBLY (LB40F00009F1)
03-04-01	00	SLEWING RING ASSEMBLY (H&W) (LB40FU0003F1)
03-05	00	TRACK ROLLER ASSEMBLY (LB64D00002F1)
03-06	00	UPPER ROLLER ASSEMBLY (LB64D00001F1)
03-07	00	IDLER ASSEMBLY, CRAWLER (LB52D00006F2)
03-08	00	IDLER ASSEMBLY (LB52D00002F3)
03-09	00	IDLER ADJUSTMENT ASSEMBLY (LB54D00001F1)
03-10	00	HYDRAULIC LINES, LOWER (LB02H00009F1)
03-11	00	HYDRAULIC LINES, PROPEL (LQ12H00011F1)
03-12	00	HYDRAULIC LINES, SWIVEL (STANDARD & H+W) (LQ19H00006F1)
03-15	00	HYDRAULIC LINES, LOWER (H&W) (LC02HU0005F1)
03-16	00	HYDRAULIC LINES, PROPEL (H&W) (LC12H00005F1)
03-17	00	IDLER ASSEMBLY, CRAWLER (H&W) (LC52D00025F1)
03-18	00	IDLER ASSEMBLY (LC52D00032F1)
03-19	00	IDLER ADJUSTMENT ASSEMBLY (H&W) (LC54D00009F1)
03-20	00	TRACK ROLLER ASSEMBLY (H&W) (LC64D00004F3)
03-21	00	ROLLER ASSEMBLY, UPPER (H&W) (LC64DU0019F1)
04-01	00	BOOM GROUP (LB02B00035F1)
04-02	00	BOOM ASSEMBLY (LB02B00039F1)
04-03	00	CYLINDER INSTALLATION, ARM (LB02B00046F1)
04-04	00	BOOM INSTALLATION (LQ02B00244F1)
04-05	00	CYLINDER INSTALLATION, BOOM (LB02B00047F1)
04-06	00	ARM GROUP (STANDARD) (LB12B00076F1)
04-07	00	ARM INSTALLATION (LB12B00089F1)
04-08	00	ARM – 3.10M (10FT - 2IN) (LB12B00083F1)
04-08	01	ARM – 3.20M (10FT - 6IN) (LB12BU0021F1)
04-09	00	HYDRAULIC LINES - ARM (STANDARD) (LB43H00029F1)
04-10	00	HYDRAULIC LINES, BOOM (BASE & STANDARD) (LB42H00055F1)
04-11	00	HYDRAULIC LINES, CYLINDER (ARM) (LB42H00058F1)
04-12	00	HYDRAULIC LINES, CYLINDER (BOOM) (LB42H00060F1)
04-13	00	CONTROL LINES, REMOTE (2 WAY - FOOT) (LQ68H00037F1)
04-14	00	HYDRAULIC LINES (NIBBLER & BREAKER) (LB43H00034F1)
04-15	00	HYDRAULIC LINES, ARM (STANDARD W/ROT + N&B) (LB43H00037F1), PAGE 1 OF 2
04-15	01	HYDRAULIC LINES, ARM (STANDARD W/ROT + N&B) (LB43H00037F1), PAGE 2 OF 2
04-16	00	HYDRAULIC LINES, ARM (LOCK) (LB42H00066F1)
04-17	00	HYDRAULIC LINES, BOOM (EXTRA) (LB42H00050F1)
04-18	00	HYDRAULIC LINES, BOOM (NIBBLER & BREAKER) (LB42H00056F1)
04-19	00	HYDRAULIC LINES, CYLINDER (BOOM LOCK) (LB42H00063F1), PAGE 1 OF 2

MidWestTech | Kobelco SK295-8 Acera Mark 8 Tier 3 Hydraulic Excavator Parts Catalog |... Order the manual at mid-west-tech.com >

ARM -- 3.20M (10FT - 6IN) (LB12BU0021F1)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{}			Arm -- 3.20M (10ft - 6in), LB12BU0021F1
1		{LB12BU0022F1}		1	Arm, Incls. Refs. 2 - 7
2		LQ02B01481P1		4	BUSHING, (Part of Item 1)
3		LC12B01499P1		2	BUSHING, (Part of Item 1)
4		LQ12B01516P1		2	BUSHING, (Part of Item 1)
5		LQ12B01517P1		2	BUSHING, (Part of Item 1)
6		YN12B02417P1		2	BLOCK, (Part of Item 1)
7		YN02B01616P1		4	BLOCK, (Part of Item 1)
8		2445R220D6		2	SEAL, Dust -- ID 90 X OD 105mm
9		2445R220D4		2	SEAL, Dust -- ID 80 X OD 95mm
10		2445R138D24		2	SEAL, Dust

MidWestTech | Kobelco SK295-8 Acera Mark 8 Tier 3 Hydraulic Excavator Parts Catalog |... Order the manual at mid-west-tech.com >

ROCKER SHAFT (101670130001)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{}			Rocker Shaft, 101670130001
1		4895432		5	SCREW, M8x1.25x70mm
2		2856458		6	ROCKER ARM, Incls. Refs. 2A - 2E
2A		2830434		2	SCREW, Shoulder
2B		4893487		1	SUPPORT
2C		4894816		1	SHAFT, Shaft, Rocker Arm
2D		4897246		1	ROCKER ARM, Exhaust
2E		4897247		1	ROCKER ARM, Intake
3		4895031		12	ROD, PUSH
4		2854530		12	BRIDGE
5		2853788		1	GASKET
6		2852602		3	SCREW, M6x1.0x16mm
7		2852427		3	CABLE, ELECTRIC, Harness, Wiring
8		4899257		1	HOUSING, Incls. Refs. 8A
8A		4899245		5	DOWEL, Sleeve
9		2852428		6	CLIP, Wire Retainer
10		2852776		3	WASHER, ID 06 x OD 11 x Th 01.6mm
11		4899089		2	SCREW, M08x1.25x50mm

MidWestTech | Kobelco SK295-8 Acera Mark 8 Tier 3 Hydraulic Excavator Parts Catalog |... Order the manual at mid-west-tech.com >

OIL COOLER, (101670840002)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{}			Oil Cooler, 101670840002
1		4899019		15	SCREW, M08x1.25x35mm
2		2853780		1	Head, Filter, Assembly, Incls. Refs. 2A - 2G
2A		2853781		1	PLUG, Incls. Refs. 2B
2B		17916280		1	GASKET, (Part of 2853781)
2C		4895045		1	SPRING
2D		4896404		1	PLUNGER
2E		4899566		1	HEAT EXCHANGER, Incls. Refs. 2F
2F		4893391		1	ADAPTER, (Part of 4899566), M27x2x23.14mm x M24x2.0x11mm
2G		4896410		1	VALVE, PRESSURE RELIEF
3		4896407		1	RADIATOR, Alternative to 2853604
3		2853604		1	COOLER, OIL, Alternative to 4896407
4		2830559		1	GASKET
5		4896409		1	GASKET

MidWestTech | Kobelco SK295-8 Acera Mark 8 Tier 3 Hydraulic Excavator Parts Catalog |... Order the manual at mid-west-tech.com >