CASE

PROFESSIONAL PARTNER

PARTS CATALOG
CRAWLER DOZER

850L
TIER 3

87659316 NA

Issued 01Jan 08

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	ENGINE - MOUNTING
02-02	FAN - FAN BELT
02-03	RADIATOR - MOUNTING
02-03A	RADIATOR - FAN GUARDS
02-04	RADIATOR - COOLING
02-05	COOLANT RECOVERY SYSTEM
02-06	AIR CLEANER - MOUNTING
02-07	AIR CLEANER ASSY
02-08	MUFFLER - EXHAUST SYSTEM
02-09	ENGINE
02-10	CYLINDER BLOCK
02-11	CYLINDER BLOCK - PLUG ASSY
02-12	CYLINDER BLOCK - STIFFENER
02-13	OIL PUMP, PAN
02-14	GEAR COVER - REAR HOUSING
02-15	FRONT GEAR COVER
02-17	BREATHER - ENGINE
02-18	CYLINDER HEAD - ASSEMBLY
02-19	CYLINDER HEAD - COVERS
02-20	ROCKER ARMS - ASSEMBLY
02-21	INTAKE MANIFOLD
02-22	EXHAUST MANIFOLD
02-23	CRANKSHAFT
02-24	CONNECTING ROD
02-25	PISTONS
02-26	FLYWHEEL - ENGINE - HOUSING
02-27	CRANKSHAFT - PULLEY
02-28	CAMSHAFT
02-29	TURBOCHARGER
02-30	ENGINE, OIL
02-31	OIL PUMP - ENGINE
02-32	OIL FILTER - ENGINE
02-33	PIPING - ENGINE OIL
02-34	OIL FILTER AND COOLER
02-35	WATER PUMP
02-36	COOLING SYSTEM - ENGINE
02-37	THERMOSTAT - ENGINE COOLING SYSTEM
02-38	WATER PUMP - CONTROL
02-39	FAN DRIVE
02-40	POWER TAKE-OFF
02-41	ENGINE - LIFT HOOKS
03-04	FUEL TANK
03-05	FUEL LINES
03-06	FUEL INJECTION PUMP
03-07	FUEL INJECTION SYSTEM - INJECTOR
03-09	FUEL INJECTION SYSTEM
03-10	FILTER, FUEL
03-11	FUEL INJECTION SYSTEM - MODULE, ENGINE CONTROL
03-12	FUEL INJECTION SYSTEM - FUEL, SUPPLY
03-13	FUEL INJECTION SYSTEM - DRAIN LINE
03-14	FUEL INJECTION SYSTEM - HARNESS, ENGINE

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-01	STARTER
04-02	ALTERNATOR ASSY
04-03	THROTTLE, ELECTRIC
04-04	ALTERNATOR MOUNTING
04-05	BATTERY, SINGLE - CABLES
04-06	BATTERY, DUAL - CANOPY, ROPS AND CAB
04-09	HARNESS, ENGINE (RIGHT-HAND SIDE) - ALTERNATOR/STARTER
04-10	HARNESS, ENGINE (LEFT-HAND SIDE AND REAR)
04-11	HARNESS, ENGINE AND REAR WIRE HARNESS
04-12	HARNESS, FRONT CONSOLE AND SWITCHES - CANOPY, ROPS
04-13	HARNESS, FRONT CONSOLE AND SWITCHES - CAB
04-14	HARNESS, MICROCONTROLLER
04-14A	HARNESS, CAB/CANOPY
04-15	CONSOLE, FRONT - CANOPY, ROPS
04-16	CONSOLE, FRONT - CAB
04-18	LAMPS, ROPS CAB
04-19	LAMPS, ROPS CANOPY
04-20	ALARM, BACKUP - HORN
04-21	GRID HEATER
04-23	WIPER, FRONT - CAB
04-24	WIPER, REAR - CAB
05-01	FRAME, TRACK - ROLLER AND RECOIL HOUSING
05-02A	FRAME, TRACK - COVERS
05-03	SPROCKET, TRACK
05-04	TRACK ADJUSTER AND IDLER - MOUNTING
05-05	TRACK ADJUSTER
05-06	TRACK IDLER
05-07	TRACK ROLLER
05-08	TRACK GUARDS
05-09	TRACK CHAIN, SEALED
05-10	TRACK CHAIN, CASE LUBRICATED
05-11	TRACK CHAIN, EXTENDED LIFE
06-01	MOUNTING - PUMP, HYDROSTATIC TANDEM AND DRIVESHAFT
06-02	HYDROSTATICS - PUMP, TANDEM SUPPLY AND RETURN TO FILTER
06-03	HYDROSTATICS - MOTOR, DRIVE
06-04	DIAGNOSTIC LINES
06-05	MOUNTING - FINAL DRIVE
06-06	COVERS - FINAL DRIVE
06-07	FINAL DRIVE ASSY, DROP HOUSING
06-08	FINAL DRIVE ASSY, HUB
06-09	FILTER ASSY
06-10	CONTROLS, FORWARD AND REVERSE
06-11	HYDROSTATIC MOTOR
06-12	HYDROSTATIC MOTOR
06-13	PUMP ASSY - HYDROSTATIC
06-14	TANDEM PUMP ASSEMBLY
07-01	BRAKE PEDAL AND FOOTREST MOUNTING
07-02	PEDALS - BRAKE AND DECELERATOR
07-03	BRAKE LINES
07-04	BRAKE, PARKING/LOCKOUT LEVERS
08-01	RESERVOIR, HYDRAULIC - COVERS

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08-02	HYDRAULICS, EQUIPMENT - RESERVOIR TO PUMP AND CONTROL VALVE
08-02A	PUMP ASSY, HYDRAULIC - MODELS WITH PTO
08-03	HYDRAULICS, EQUIPMENT - CONTROL VALVE TO THERMAL BYPASS VALVE AND FILTER
08-04	VALVE ASSEMBLY, THERMAL BYPASS
08-05	HYDRAULICS - LIFT CIRCUIT
08-06	HYDRAULICS - TILT AND ANGLE CIRCUITS
08-07	HYDRAULICS - TILT CIRCUIT
08-08	HYDRAULICS - ANGLE CIRCUIT
08-09	HYDRAULICS - RIPPER, VALVE TO REAR OF TRACTOR
08-10	HYDRAULICS - RIPPER, REAR OF TRACTOR TO CYLINDERS
08-11	CYLINDER ASSY - LIFT
08-12	CYLINDER ASSY - TILT
08-13	CYLINDER ASSY - ANGLE
08-14	CYLINDER ASSY - RIPPER
08-15	VALVE, CONTROL - MOUNTING
08-16	CONTROLS - LEVER AND LINKAGE, THREE SPOOL VALVE
08-17	CONTROLS - LEVER AND LINKAGE, FOURTH SPOOL
08-18	VALVE, CONTROL
08-19	VALVE ASSY, RELIEF
08-20	SECTION ASSEMBLY - LIFT
08-21	SECTION ASSEMBLY - TILT, ANGLE, AND AUXILIARY
08-22	VALVE ASSY, CHECK - VALVE ASSY, ANTI-CAVITATION
08-23	VALVE ASSY, RELIEF
09-01	FRAME, LIFT - CYLINDERS, MOUNTING
09-02	DOZER BLADE - MOUNTING
09-03	BLADE, DOZER - EDGES, CUTTING
09-04	SHIELDS, DOZER HYDRAULICS
09-05	RIPPER
09-06	COUNTERWEIGHT, FRONT - HOOK, TOWING
09-07	DRAWBAR - HOOK, TOWING
09-08	FRAME, MAIN - COVERS
09-09	MOUNTING - FUEL TANK/HYDRAULIC RESERVOIR
09-10	DOOR, REAR - TANK, HYDRAULIC OIL
09-11	DOORS, REAR
09-12	HOOD AND SIDE PANELS
09-13	GUARD, RADIATOR BRUSH SCREEN - GRILLE, HOOD
09-14	SEAT ASSY, MECHANICAL SUSPENSION - MOUNTING
09-15	SEAT ASSY, MECHANICAL SUSPENSION
09-16	SEAT ASSY, AIR SUSPENSION - MOUNTING
09-17	SEAT ASSY, AIR SUSPENSION
09-18	CANOPY, ROPS - FRAME, MOUNTING AND GRAB HANDLES
09-19	CANOPY, ROPS - HEADLINER, FLOORMAT AND MIRROR
09-20	CANOPY, ROPS - ARMRESTS, TOOLBOX AND COVERS
09-21	CANOPY, ROPS - CONSOLES, SIDE
09-22	CANOPY, ROPS - GUARD, BRUSH
09-23	CANOPY, ROPS - SCREENS
09-24	CAB OR CANOPY - TILT COMPONENTS
09-25	CAB - FRAME, MOUNTING AND GRAB HANDLES
09-25A	CAB - MISCELLANEOUS COMPONENTS
09-26	CAB - DOORS

Order the manual at mid-west-tech.com >

TRACK CHAIN, SEALED

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		418614A1		2	TRACK ASSY, CRAWLER, 457 mm (18 inch); Chain; Incl. Shoes; Incl. 407015A1, Ref 1 - 8; 9, 10, 11
		418617A1		2	TRACK ASSY, CRAWLER, 508 mm (20 inch); Chain; Incl. Shoes; Incl. 407015A1, Ref 1 - 8; 9A, 10, 11
		418621A1		2	TRACK ASSY, CRAWLER, 610 mm (24 inch); Chain; Incl. Shoes; Incl. 407015A1, Ref 1 - 8; 9B, 10, 11
		418624A1		2	TRACK ASSY, CRAWLER, 711 mm (28 inch); Chain; Incl. Shoes; Incl. 407015A1, Ref 1 - 8; 9C, 10, 11
		407015A1		1	CHAIN, TRACK, Incl. Ref 1 - 8; Order 418497A1, Ref 25
1		295178A2		40	LINK, Right-Hand
2		295177A2		40	LINK, Left-Hand
3		R56517		39	BUSHING, 123,5 mm (4-7/8 in) OD; Link
4		R50211		160	WASHER
5		R49792		39	PIN, LARGE, 183 x 33 mm
6		R54349		1	PIN, Master Link
7		R56516		1	BUSHING, 108 mm (4-1/4 in) OD; Master Link
8		R50210		2	SPACER
9		295181A1		40	SHOE, TRACK, 457 mm (18 inch)
9A		300199A1		40	SHOE, 508 mm (20 inch)
9B		295182A1		40	SHOE, 610 mm (24 inch)
9C		295183A1		40	SHOE, 711 mm (28 inch)
10		295318A1		160	BOLT, 5/8 NF x 2-1/8
11		R25688		160	NUT, 5/8 NF
		REF			INSTRUCTION, CHAIN UNIT KIT
		300214A2		1	KIT, Incl. Ref 12 - 18, Instructions
12		295178A2		1	LINK, Right-Hand
13		295177A2		1	LINK, Left-Hand
14		R49792		2	PIN, LARGE, 183 x 33 mm
15		R50210		2	SPACER
16		R56516		1	BUSHING, 108 mm (4-1/4 in) OD; Master Link
17		R54349		1	PIN, Master Link
18		R50211		8	WASHER

MidWestTech | Case 850L Tier 3 Crawler Dozer Parts Catalog | Publication 87659316NA Order the manual at mid-west-tech.com >

CYLINDER ASSY - RIPPER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		86994129		1	CYLINDER ASSY., 83 ID x 206 mm strk; Ripper; Right-Hand; Incl. Ref 1, 2 - 19
		86994131		1	CYLINDER ASSY., 83 ID x 206 mm strk; Ripper; Left-Hand; Incl. Ref 1A - 19
1		G100608		1	CYLINDER, Tube; Right-Hand; Incl. Ref 2
1A		G100609		1	CYLINDER, Tube; Left-Hand; Incl. Ref 2
2		30634		2	BUSHING
3		86642312		1	SCREW, SELF TAP, Hex Hd, #8 x 3/8"
4		G100617		1	ROD, Incl. Ref 5
5		30634		2	BUSHING
6		G100642		1	PISTON
7		1542972C1		1	CAP CYLINDER END
8		D95143		1	SEAL
9		G102425		1	BUSHING
10		1542875C1		1	KIT, SEALS, Seal Kit; Order 1543265C1 Kit
11		238-5236		1	O-RING, -236, 70 Duro, 3.234" ID x .139" Thk
12		D38858		1	GASKET
13		G102287		1	SEAL
14		S109444		1	RING
15		S109445		2	RING
16		86982437		1	BOLT, SPECIAL, 1 x 2-1/2; With Washer
18		219-1		1	NIPPLE, LUBE, 1/8"-27 x .66 lg
19		219-55		1	NIPPLE, LUBE, 90°, 1/8" NPT x .84" lg

MidWestTech | Case 850L Tier 3 Crawler Dozer Parts Catalog | Publication 87659316NA Order the manual at mid-west-tech.com >

BLADE, DOZER - EDGES, CUTTING

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, 2642 mm (104 inch) DOZER BLADE
		87355520		1	BLADE, DOZER, 2642 mm (104 inch); Incl. Ref 1 - 6
1		NSS		1	NOT SERVICED SEPARATELY, Blade
2		R42490		2	END, 442 mm (17-7/16 in); Cutting Edge
3		115631A1		2	EDGE, 867 mm (34-1/8 in); Center Cutting Edge; 6 Bolt Holes
4		R56474		22	BOLT, 3/4 x 2-1/2; 8
5		92-11075		22	WASHER, LOCK, 3/4"
6		29-1012		22	NUT, 3/4"-10, G8
		REF			INSTRUCTION, 2794 mm (110 inch) DOZER BLADE
		87355522		1	BLADE, DOZER, 2794 mm (110 inch); Incl. Ref 7 - 12
7		NSS		1	NOT SERVICED SEPARATELY, Blade
8		R42490		2	END, 442 mm (17-7/16 in); Cutting Edge
9		430157A1		1	EDGE, CUTTING, 1908 mm (75-1/8 in); Center Cutting Edge; 13 Bolt Holes
10		R56474		23	BOLT, 3/4 x 2-1/2; 8
11		92-11075		23	WASHER, LOCK, 3/4"
12		29-1012		23	NUT, 3/4"-10, G8
		REF			INSTRUCTION, 3048 mm (120 inch) DOZER BLADE
		87355524		1	BLADE, DOZER, 3048 mm (120 in); Incl. Ref 13 - 18
13		NSS		1	NOT SERVICED SEPARATELY, Blade
14		R42490		2	END, 442 mm (17-7/16 in); Cutting Edge
15		327539A1		1	EDGE, 2158 mm (85 in); Center Cutting Edge; 14 Bolt Holes
16		R56474		24	BOLT, 3/4 x 2-1/2; 8
17		92-11075		24	WASHER, LOCK, 3/4"
18		29-1012		24	NUT, 3/4"-10, G8
		REF			INSTRUCTION, 3150 mm (124 inch) DOZER BLADE
		87355525		1	BLADE, DOZER, 3150 mm (124 in); Incl. Ref 19 - 24
19		NSS		1	NOT SERVICED SEPARATELY, Blade
20		R42490		2	END, 442 mm (17-7/16 in); Cutting Edge
21		126519A1		1	EDGE, 2258 mm (88-7/8 in); Center Cutting Edge; 15 Bolt Holes
22		R56474		25	BOLT, 3/4 x 2-1/2; 8
23		92-11075		25	WASHER, LOCK, 3/4"

MidWestTech | Case 850L Tier 3 Crawler Dozer Parts Catalog | Publication 87659316NA Order the manual at mid-west-tech.com >