CASE

PROFESSIONAL PARTNER

PARTS CATALOG
CRAWLER DOZER

750L
TIER 3

87659317 NA

Issued 01Jan 08

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	ENGINE - MOUNTING
02-02	FAN - FAN BELT
02-02A	FAN DRIVE
02-02B	PULLEY - FAN DRIVE
02-03	RADIATOR - MOUNTING
02-03A	RADIATOR - FAN GUARDS
02-04	RADIATOR - COOLING
02-05	COOLANT RECOVERY SYSTEM
02-06	AIR CLEANER - MOUNTING
02-07	AIR CLEANER ASSY
02-08	MUFFLER - EXHAUST SYSTEM
02-09	ENGINE
02-10	ENGINE OIL DIPSTICK
02-11	OIL FILTER AND COOLER
02-11A	OIL FILTER - ENGINE
02-12	OIL PUMP - ENGINE
02-13	OIL PUMP, PAN
02-15	BREATHER - ENGINE
02-16	TURBOCHARGER - DRAIN LINE
02-17	TURBOCHARGER
02-18	WATER PUMP
02-19	WATER PUMP - CONTROL
02-20	CYLINDER BLOCK
02-21	CYLINDER BLOCK - PLUG ASSY
02-23	CYLINDER HEAD
02-24	CYLINDER HEAD - ASSEMBLY
02-25	CYLINDER HEAD - COVERS
02-26	CRANKSHAFT
02-27	CRANKSHAFT - PULLEY
02-28	DYNAMIC BALANCER, GEARS & SHAFTS
02-28A	DYNAMIC BALANCER, GEARS & SHAFTS
02-29	FLYWHEEL HOUSING
02-29A	FLYWHEEL - ENGINE
02-30	GEAR COVER - REAR HOUSING
02-32	FRONT GEAR COVER
02-33	ROCKER ARMS
02-33A	ROCKER ARMS - ASSEMBLY
02-34	CAMSHAFT
02-35	PISTONS
02-36	PISTONS - CONNECTING ROD
02-37	INTAKE MANIFOLD
02-38	EXHAUST MANIFOLD
02-39	COOLING SYSTEM - ENGINE
02-40	THERMOSTAT - ENGINE COOLING SYSTEM
02-41	ENGINE - LIFT HOOKS
03-08	FUEL INJECTION SYSTEM - FUEL, SUPPLY
03-01	FUEL INJECTION PUMP
03-03	FILTER, FUEL
03-04	FUEL TANK
03-05	FUEL LINES
03-06	FUEL INJECTION SYSTEM

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-07	FUEL INJECTION SYSTEM - INJECTOR
03-09	FUEL INJECTION SYSTEM - MODULE, ENGINE CONTROL
03-10	FUEL INJECTION SYSTEM - HARNESS, ENGINE
03-11	FUEL INJECTION SYSTEM - DRAIN LINE
04-01	STARTER
04-02	ALTERNATOR ASSY
04-02A	ALTERNATOR - MOUNTING
04-03	THROTTLE, ELECTRIC
04-05	BATTERY, SINGLE - CABLES
04-06	BATTERY, DUAL - CANOPY, ROPS AND CAB
04-09	HARNESS, ENGINE (RIGHT-HAND SIDE) - ALTERNATOR/STARTER
04-10	HARNESS, ENGINE (LEFT-HAND SIDE AND REAR)
04-11	HARNESS, ENGINE AND REAR WIRE HARNESS
04-12	HARNESS, FRONT CONSOLE AND SWITCHES - CANOPY, ROPS
04-13	HARNESS, FRONT CONSOLE AND SWITCHES - CAB
04-14	HARNESS, MICROCONTROLLER
04-14A	HARNESS, CAB/CANOPY
04-15	CONSOLE, FRONT - CANOPY, ROPS
04-16	CONSOLE, FRONT - CAB
04-18	LAMPS, ROPS CAB
04-19	LAMPS, ROPS CANOPY
04-20	ALARM, BACKUP - HORN
04-21	GRID HEATER
04-23	WIPER, FRONT - CAB
04-24	WIPER, REAR - CAB
05-01	FRAME, TRACK - ROLLER AND RECOIL HOUSING
05-02A	FRAME, TRACK - COVERS
05-03	SPROCKET, TRACK
05-04	TRACK ADJUSTER AND IDLER - MOUNTING
05-05	TRACK ADJUSTER
05-06	TRACK IDLER
05-07	TRACK ROLLER
05-08	TRACK GUARDS
05-09	TRACK CHAIN, SEALED
05-10	TRACK CHAIN, CASE LUBRICATED
05-11	TRACK CHAIN, EXTENDED LIFE
06-01	MOUNTING - PUMP, HYDROSTATIC TANDEM AND DRIVESHAFT
06-02	HYDROSTATICS - PUMP, TANDEM SUPPLY AND RETURN TO FILTER
06-03	HYDROSTATICS - MOTOR, DRIVE
06-04	DIAGNOSTIC LINES
06-05	MOUNTING - FINAL DRIVE
06-06	COVERS - FINAL DRIVE
06-07	FINAL DRIVE ASSY, DROP HOUSING
06-08	FINAL DRIVE ASSY, HUB
06-09	FILTER ASSY
06-10	CONTROLS, FORWARD AND REVERSE
06-11	HYDROSTATIC MOTOR
06-12	HYDROSTATIC MOTOR
06-13	PUMP ASSY - HYDROSTATIC
06-14	TANDEM PUMP ASSEMBLY
07-01	BRAKE PEDAL AND FOOTREST MOUNTING

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

07-02	PEDALS - BRAKE AND DECELERATOR
07-03	BRAKE LINES
07-04	BRAKE, PARKING/LOCKOUT LEVERS
08-01	RESERVOIR, HYDRAULIC - COVERS
08-02	HYDRAULICS, EQUIPMENT - RESERVOIR TO PUMP AND CONTROL VALVE
08-02A	PUMP ASSY, HYDRAULIC - MODELS WITH PTO
08-03	HYDRAULICS, EQUIPMENT - CONTROL VALVE TO THERMAL BYPASS VALVE AND FILTER
08-04	VALVE ASSEMBLY, THERMAL BYPASS
08-05	HYDRAULICS - LIFT CIRCUIT
08-06	HYDRAULICS - TILT AND ANGLE CIRCUITS
08-07	HYDRAULICS - TILT CIRCUIT
08-08	HYDRAULICS - ANGLE CIRCUIT
08-09	HYDRAULICS - RIPPER, VALVE TO REAR OF TRACTOR
08-10	HYDRAULICS - RIPPER, REAR OF TRACTOR TO CYLINDERS
08-11	CYLINDER ASSY - LIFT
08-12	CYLINDER ASSY - TILT
08-13	CYLINDER ASSY - ANGLE
08-14	CYLINDER ASSY - RIPPER
08-15	VALVE, CONTROL - MOUNTING
08-16	CONTROLS - LEVER AND LINKAGE, THREE SPOOL VALVE
08-17	CONTROLS - LEVER AND LINKAGE, FOURTH SPOOL
08-18	VALVE, CONTROL
08-19	VALVE ASSY, RELIEF
08-20	SECTION ASSEMBLY - LIFT
08-21	SECTION ASSEMBLY - TILT, ANGLE, AND AUXILIARY
08-22	VALVE ASSY, CHECK - VALVE ASSY, ANTI-CAVITATION
08-23	VALVE ASSY, RELIEF
09-01	FRAME, LIFT - CYLINDERS, MOUNTING
09-02	DOZER BLADE - MOUNTING
09-03	BLADE, DOZER - EDGES, CUTTING
09-04	SHIELDS, DOZER HYDRAULICS
09-05	RIPPER
09-06	COUNTERWEIGHT, FRONT - HOOK, TOWING
09-07	DRAWBAR - HOOK, TOWING
09-08	FRAME, MAIN
09-09	MOUNTING - FUEL TANK/HYDRAULIC RESERVOIR
09-10	DOOR, REAR - TANK, HYDRAULIC OIL
09-11	DOORS, REAR
09-12	HOOD AND SIDE PANELS
09-13	GUARD, RADIATOR BRUSH SCREEN - GRILLE, HOOD
09-14	SEAT ASSY, MECHANICAL SUSPENSION - MOUNTING
09-15	SEAT ASSY, MECHANICAL SUSPENSION
09-16	SEAT ASSY, AIR SUSPENSION - MOUNTING
09-17	SEAT ASSY, AIR SUSPENSION
09-18	CANOPY, ROPS - FRAME, MOUNTING AND GRAB HANDLES
09-19	CANOPY, ROPS - HEADLINER, FLOORMAT AND MIRROR
09-20	CANOPY, ROPS - ARMRESTS, TOOLBOX AND COVERS
09-21	CANOPY, ROPS - CONSOLES, SIDE
09-22	CANOPY, ROPS - GUARD, BRUSH
09-23	CANOPY, ROPS - SCREENS

Order the manual at mid-west-tech.com >

FUEL INJECTION SYSTEM

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		2855427		1	PIPE, Incl. Ref. 2
2		4894095		2	O-RING
3		2855428		1	PIPE, Incl. Ref. 2
4		2855430		1	PIPE, Incl. Ref. 2
5		2855795		1	PIPE INJECTION, Incl. Ref. 2
6		4896996		1	CLAMP

MidWestTech | Case 750L Tier 3 Crawler Dozer Parts Catalog | Publication 87659317na Order the manual at mid-west-tech.com >

DOORS, REAR

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, LEFT-HAND AND RIGHT-HAND
		87355343		1	DOOR ASSY., Right-Hand; Incl. Ref 1, 2, 3 - 6A; Also Includes 87353954 Latch, (4) 151-567 1/4 x 5/8 Rivets
		87355342		1	DOOR ASSY., Left-Hand; Incl. Ref 1A, 2A - 6A; Also Includes 87353954 Latch, (4) 151-567 1/4 x 5/8 Rivets
		87353954		1	LATCH, Door
		151-567		4	RIVET, Pop, 1/4" x .625"
1		NSS		1	NOT SERVICED SEPARATELY, Door, Right-Hand
1A		NSS		1	NOT SERVICED SEPARATELY, Door, Left-Hand
2		414382A4		1	HINGE, Door, Right-Hand
2A		414384A4		1	HINGE, Door, Left-Hand
4		496-81028		4	WASHER, 13/32" x 1 1/4" x .134", HDN
5		122958A1		2	NUT, M10
6		336371A1		2	PIN, Nut Retainer
6A		832-10410		1	NUT, LOCK, M10 x 1.5, Cl 8
8		895-15008		6	WASHER, M8 x 20 x 1.6
9		87403799		2	SPRING, Gas, Includes Integral Spring Clip Retainer; Replaces 437171A1 Gas Spring and Ref 13, Clip
10		411339A1		2	MOUNTING PARTS
11		627-8020		8	BOLT, Hex, M8 x 20, 10.9
12		895-11008		8	WASHER, M8 x 16 x 1.6
13		F44883		4	CLIP, If Used
14		109498A1		4	STUD
15		231-1445		6	NUT, LOCK, 5/16"-18, GB
16		86990971		1	HANDLE, Hydraulic Pump, Cab/Canopy Tilt; Door, Left-Hand
17		413925A2		2	PLATE, Door Latch
18		614-12025		4	BOLT, Hex, M12 x 25, 8.8
19		896-11012		4	WASHER, M13.5 x 24.5 x 3, HT
20		87330642		2	BUMPER, 28 mm Stud Length; Replaces N7673 Bumper With 28 mm Stud Length
21		495-11034		2	WASHER, 5/16", SAE
22		231-1445		2	NUT, LOCK, 5/16"-18, GB

MidWestTech | Case 750L Tier 3 Crawler Dozer Parts Catalog | Publication 87659317na Order the manual at mid-west-tech.com >

CAB - DOORS

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, LEFT-HAND AND RIGHT-HAND CAB DOORS; LEFT-HAND DOOR NOT ILLUSTRATED
		(87550957)		1	ASSEMBLY; Right-Hand; Incl. Ref 1, 2, 3, 4 - 6, 7 - 27, 28, 29; Except Where Noted For Left-Hand Door
		(87550958)		1	ASSEMBLY;Left-Hand; Incl. Ref 1A, 2, 3A, 4, 5, 6A -26, 27A, 28, 29A; Except Where Noted For Right-Hand Door
1		(87517953)		1	FRAME, Right-Hand Door; Frame Not Available, Order 87517951 RH Door Assembly
1A		(87517952)		1	FRAME, Left-Hand Door; Frame Not Available, Order 87517950 LH Door Assembly; Not Illustrated
2		(87577745)		7	Bumper, Glues in Glass
3		87371775		1	GLASS, CAB, Right-Hand Door
3A		87371774		1	GLASS, CAB, Left-Hand Door
4		87400794		1	BUSHING, Nylon 12 dia
5		87400795		1	BUSHING, Nylon 25 dia
6		87371740		1	LATCH, Interior; Right-Hand Door
6A		87371737		1	LATCH, Interior; Left-Hand Door
7		87517859		2	GROMMET
8		87371994		1	PLATE, STRIKER, Hold Open
9		(87615084)		2	Washer, Flat
10		825-2408		2	NUT, M8 x 1.25, Flg, Cl 8
11		87517925		2	WASHER, Foam
12		87517940		1	GASKET, Door Handle
13		87517937		1	GASKET, Door Handle
14		87517921		1	GASKET, Door Latch
15		87517938		3	BUSHING, Door
16		60-7083T1		1	HANDLE
17		(87615095)		1	Nut, Hex
18		413-432		1	BOLT, Hex, 1/4"-20 x 2", G5
19		87517920		1	GASKET, Wiper
20		87517958		1	PLATE, MOUNTING, Wiper Mount
21		87517945		6	NUT, No. 10
22		87517941		6	SCREW, No. 10 x 5/8

MidWestTech | Case 750L Tier 3 Crawler Dozer Parts Catalog | Publication 87659317na Order the manual at mid-west-tech.com >