NEW HOLLAND

# BACKHOE LOADER

# B110B TIER 3

## PARTS CATALOG

87659792 NA

Issued 01 Feb 08

NEW HOLLAND CONSTRUCTION

www.newhollandconstruction.com

MidWestTech | New Holland B110B Tier 3 Backhoe Loader Parts Catalog | Publication 87659792

Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | | |
|---|---|---|
| MAIN | | SECTIONS |
| MPARTS | | MAINTENANCE PARTS |
| SEC. 02 | | FUEL TANK - MUFFLER - RADIATOR - AIR CLEANER - CHASSIS |
| SEC. 03 | 02 | TRANSMISSION |
| SEC. 04 | | FRONT AXLE |
| SEC. 05 | | REAR AXLE |
| SEC. 06 | | ELECTRICAL |
| SEC. 07 | | SLIDES VALVES |
| SEC. 08 | | BODY & HOOD |
| SEC. 09 | 01 | LOADER |
| SEC. 09 | 02 | BACKHOE |
| SEC. 09 | 03 | BACKHOE |
| SEC. 10 | 01 | BODY, HOOD & DRIVER'S POST |
| SEC. 10 | 02 | BODY, HOOD & DRIVER'S POST |
| SEC. 10 | 03 | BODY, HOOD & DRIVER'S POST |
| SEC. 11 | | WHEELS |
| SEC. 18 | | VARIATION |
| 0.0040 | 01 | OPTIONAL EQUIPMENT - EU |
| 0.0040 | 02 | OPTIONAL EQUIPMENT - EU |
| 0.0040 | 03 | OPTIONAL EQUIPMENT - EU |
| 0.0040/01 | 01 | OPTIONAL EQUIPMENT - NA |
| 0.0040/01 | 02 | OPTIONAL EQUIPMENT - NA |
| 0.0040/01 | 03 | OPTIONAL EQUIPMENT - NA |
| 0.02.1/02 | | ENGINE |
| 0.04.0/01 | | CRANKCASE |
| 0.04.2 | | ENGINE OIL SUMP |
| 0.04.3/01 | 01 | CRANKCASE COVERS |
| 0.04.3/01 | 02 | CRANKCASE COVERS |
| 0.04.3/01 | 03 | CRANKCASE COVERS |
| 0.06.0/01 | | CYLINDER HEAD |
| 0.06.3/01 | 01 | CYLINDER HEAD COVERS |
| 0.06.3/01 | 02 | CYLINDER HEAD COVERS |
| 0.06.6/01 | | ROCKER SHAFT |
| 0.07.1/01 | | MANIFOLD - INTAKE |
| 0.07.7/01 | | EXHAUST MANIFOLD |
| 0.08.0 | | CRANKSHAFT |
| 0.08.1/01 | | CONNECTING ROD |
| 0.08.2/01 | | PISTON - ENGINE |
| 0.08.3 | | FLYWHEEL - ENGINE |
| 0.08.4 | | PULLEY - CRANKSHAFT |
| 0.10.5 | 01 | DYNAMIC BALANCER, GEARS & SHAFTS |
| 0.10.5 | 02 | DYNAMIC BALANCER, GEARS & SHAFTS |
| 0.12.0/02 | | CAMSHAFT - TIMING CONTROL |
| 0.14.0/01 | 01 | INJECTION PUMP |
| 0.14.0/01 | 02 | INJECTION EQUIPMENT - INJECTOR |
| 0.14.0/01A | | INJECTION PUMP - COMPONENTS |
| 0.14.9/01 | | INJECTION EQUIPMENT - PIPING |
| 0.17.0 | | ELECTRONIC INJECTION |
| 0.17.3 | | MOTOR ELECTRIC INSTALLATION |
| 0.20.0/01 | | FUEL FILTER |
| 0.20.3/01 | | PIPING - FUEL |


MidWestTech | New Holland B110B Tier 3 Backhoe Loader Parts Catalog | Publication 876... Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | | |
|---|---|---|
| 0.20.4/01 | | INJECTION EQUIPMENT - PIPING |
| 0.24.0/02 | | TURBOCHARGER |
| 0.27.0/01 | | ENGINE OIL DIPSTICK |
| 0.30.0 | | OIL PUMP - ENGINE |
| 0.30.2 | | OIL FILTERS - ENGINE |
| 0.30.5/01 | | PIPING - ENGINE OIL |
| 0.31.5/01 | | HEAT EXCHANGER - ENGINE |
| 0.32.0 | | WATER PUMP |
| 0.32.3/01 | | COOLING SYSTEM - ENGINE |
| 0.32.6/01 | | THERMOSTAT - ENGINE COOLING SYSTEM |
| 0.34.0/01 | | WATER PUMP - CONTROL |
| 0.34.5 | | FAN DRIVE |
| 0.36.0 | | ACCESSORY ENGINE |
| 0.40.0/01 | | ALTERNATOR |
| 0.45.0/01 | | HOOKS - ENGINE |
| 1.14.0 | | FUEL TANK & RELATED PARTS |
| 1.14.6 | | FUEL PIPE |
| 1.14.6/ A | | FILTER FUEL - BREAKDOWN |
| 1.15.0 | 01 | MUFFLER & EXTENSIONS |
| 1.15.0 | 02 | EXHAUST TUBE |
| 1.19.1 | | AIR CLEANER & HOSES |
| 1.21.4 | | REAR SUPPORT (SIDE SHIFT) - EU |
| 1.21.5 | | FRAME (CENTER PIVOT) |
| 1.21.5/03 | | FRAME (SIDE SHIFT) - EU |
| 1.28.0 | | TRANSMISSION |
| 1.28.0/ A | 01 | TORQUE CONVERTER COMPONENTS (2WD POWER-SHUTTLE) |
| 1.28.0/ A | 02 | GEARSHIFT OUTER COMPONENTS (2WD POWER-SHUTTLE) |
| 1.28.0/ A | 03 | GEARSHIFT HYDRAULIC COMPONENTS (2WD POWER-SHUTTLE) |
| 1.28.0/ A | 04 | PARKING BRAKE (2WD POWER-SHUTTLE) |
| 1.28.0/ A | 05 | TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE) |
| 1.28.0/ A | 06 | FRONT TRANSMISSION SHAFT (2WD POWER-SHUTTLE) |
| 1.28.0/ A | 07 | GEARSHIFT GEAR DRIVES (2WD POWER-SHUTTLE) |
| 1.28.0/ B | 01 | TORQUE CONVERTER COMPONENTS AND GEARSHIFT GEAR DRIVES (4WD POWER-SHUTTLE) |
| 1.28.0/ B | 02 | GEARSHIFT OUTER COMPONENTS (4WD POWER-SHUTTLE) |
| 1.28.0/ B | 03 | GEARSHIFT HYDRAULIC COMPONENTS (4WD POWER-SHUTTLE) |
| 1.28.0/ B | 04 | PARKING BRAKE (4WD POWER-SHUTTLE) |
| 1.28.0/ B | 05 | TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE) |
| 1.28.0/ B | 06 | FRONT TRANSMISSION SHAFT (4WD POWER-SHUTTLE) |
| 1.28.0/ B | 07 | GEARSHIFT GEAR DRIVES (4WD POWER-SHUTTLE) |
| 1.28.0/ B | 08 | REAR DRIVE SHAFT GEARS (4WD POWER-SHUTTLE) |
| 1.28.0/ C | 01 | GEARSHIFT BOX SUPPORT (4WD POWER-SHIFT) |
| 1.28.0/ C | 02 | GEARSHIFT BOX COMPONENTS (4WD POWER-SHIFT) |
| 1.28.0/ C | 03 | GEARSHIFT BOX (4WD POWER-SHIFT) |
| 1.28.0/ C | 04 | HYDRAULIC PUMP SHAFT ASSY (4WD POWER-SHIFT) |
| 1.28.0/ C | 05 | TORQUE CONVERTER AND COMPONENTS (4WD POWER-SHIFT) |
| 1.28.0/ C | 06 | TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT) |
| 1.28.0/ C | 07 | TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT) |
| 1.28.0/ C | 08 | GEARSHIFT GEARS (4WD POWER-SHIFT) |
| 1.28.0/ C | 09 | TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT) |
| 1.28.0/ C | 10 | TRANSMISSIONGEARING 2ND SHAFT GROUP SPEED GEAR (4WD POWER-SHIFT) |


MidWestTech | New Holland B110B Tier 3 Backhoe Loader Parts Catalog | Publication 876... Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | | |
|---|---|---|
| 1.28.0/ C | 11 | GEARSHIFT FRONT DRIVE SHAFT GEARS (4WD, 2WS, POWER-SHIFT) |
| 1.28.0/ C | 12 | REAR DRIVE SHAFT GEARS (4WD POWER-SHIFT) |
| 1.28.0/ C | 13 | REAR DRIVE SHAFT GEARS (4WD, 2WS, POWER-SHIFT) |
| 1.28.0/ C | 14 | PARKING BRAKE ASSY (4WD: 2WS POWER-SHIFT) |
| 1.28.0/ C | 15 | GEARSHIFT CONTROL VALVE ASSY (4WD POWER-SHIFT) |
| 1.28.0/ C | 16 | GEARSHIFT CONTROL VALVE COMPONENTS (4WD POWER-SHIFT) |
| 1.28.6 | | OIL DIPSTICK / TOP UP (POWER-SHUTTLE) |
| 1.28.6/01 | | OIL DIPSTICK / TOP UP (POWER-SHIFT) |
| 1.29.1 | | TRANSMISSION ESTERNALSHIFTING CONTROLS (POWER-SHUTTLE) |
| 1.38.1 | | FRONT AND REAR TRANSMISSION SHAFT (POWER-SHUTTLE) |
| 1.38.3 | | FRONT AND REAR TRANSMISSION SHAFT (POWER-SHIFT) |
| 1.39.8 | | TRANSMISSION OIL COOLING PIPES (POWER-SHUTTLE) |
| 1.39.8/01 | | TRANSMISSION OIL COOLING PIPES (POWER-SHIFT) |
| 1.40.0 | 01 | FRONT AXLE (2WD) |
| 1.40.0 | 02 | STEERING ASSY AND FRONT HUBS (2WD) |
| 1.40.0/01 | 01 | FRONT AXLE - (4WD) - EU |
| 1.40.0/01 | 02 | FRONT AXLE STEERING ASSY: (4WD): EU |
| 1.40.0/01 | 03 | FRONT HUBS: (4WD): EU |
| 1.40.0/01 | 04 | FRONT AXLE BEVEL GEAR SET: (4WD): EU |
| 1.40.0/01 | 05 | FRONT AXLE DIFFERENTIAL: (4WD): EU |
| 1.40.0/01 | 06 | FRONT AXLE SHAFT JOINT: (4WD): EU |
| 1.42.0 | | POWER STEERING HYDRAULIC SYSTEM |
| 1.44.0 | 01 | REAR AXLE (POWER-SHIFT) |
| 1.44.0 | 02 | REAR AXLE DIFFERENTIAL LOCK ASSY (POWER SHIFT) |
| 1.44.0 | 03 | BEVEL GEAR SET AND REAR AXLE PARKING BRAKE (POWER SHIFT) |
| 1.44.0 | 04 | REAR AXLE DIFFERENTIAL LOCK ENGAGEMENT ASSY (POWER SHIFT) |
| 1.44.0/ A | 01 | REAR AXLE (POWER-SHUTTLE) (SIDE SHIFT) - EU |
| 1.44.0/ A | 02 | DIFFERENTIAL LOCK ASSY AND ENGAGEMENT (POWER SHUTTLE) (SIDE SHIFT): EU |
| 1.44.0/ A | 03 | REAR AXLE BEVEL GEAR SET ASSY (POWER SHUTTLE) (SIDE SHIFT): EU |
| 1.44.0/ B | 01 | REAR AXLE (POWER-SHUTTLE) (CENTER PIVOT) - NA |
| 1.44.0/ B | 02 | DIFFERENTIAL LOCK ASSY AND ENGAGEMENT (POWER SHUTTLE) (CENTER PIVOT): NA |
| 1.44.0/ B | 03 | REAR AXLE BEVEL GEAR SET ASSY (POWER SHUTTLE) (CENTER PIVOT): NA |
| 1.44.1 | | DIFFERENTIAL CONTROL (POWER-SHUTTLE) |
| 1.44.1/01 | | DIFFERENTIAL CONTROL (POWER-SHUTTLE) (CENTER PIVOT) - NA |
| 1.44.2 | | HYDRAULIC DIFFERENTIAL LOCK (POWER SHIFT) |
| 1.75.2 | 01 | FRAME REAR HARNESS AND GROUND CABLE (POWER SHUTTLE): NA |
| 1.75.2 | 02 | BATTERY LOCK-OUT SWITCH & GROUND WIRE (POWER SHUTTLE) - NA |
| 1.75.2 | 04 | ENGINE HARNESS (POWER SHUTTLE) - NA |
| 1.75.2/01 | 01 | FRAME REAR HARNESS AND GROUND CABLE (POWER SHIFT): NA |
| 1.75.2/01 | 03 | BATTERY LOCK-OUT SWITCH & GROUND WIRE (POWER SHIFT) - NA |
| 1.75.2/01 | 04 | ENGINE HARNESS (POWER SHIFT) - NA |
| 1.75.2/03 | 01 | CHASSIS HARNESS & GROUND WIRE (POWER SHUTTLE) - EU |
| 1.75.2/03 | 02 | BATTERY LOCK-OUT SWITCH & GROUND WIRE (POWER SHUTTLE) - EU |
| 1.75.2/03 | 03 | ENGINE HARNESS (POWER SHUTTLE) - EU |
| 1.75.2/04 | 01 | FRAME REAR HARNESS AND GROUND CABLE (POWER SHIFT): EU |
| 1.75.2/04 | 03 | BATTERY LOCK-OUT SWITCH & GROUND WIRE (POWER SHIFT) - EU |
| 1.75.2/04 | 04 | ENGINE HARNESS (POWER SHIFT) - EU |
| 1.81.9 | 01 | "TRANSPORT LOCK" ON/OFF SWITCH, VALVE & HOSES (POWER SHIFT - SIDE SHIFT) - EU |


MidWestTech | New Holland B110B Tier 3 Backhoe Loader Parts Catalog | Publication 876... Order the manual at mid-west-tech.com >