NEW HOLLAND

SKID STEER

L180

PIN N8M464426 & After

PARTS CATALOG

87659878

Issued 10-2009

NEW HOLLAND CONSTRUCTION

www.newhollandconstruction.com

MidWestTech | New Holland L180 Skid Steer Parts Catalog | Publication 87659878

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00.500.01		DIA
10.001.01	01	ENGINE - MOUNTING - NORTH AMERICA
10.001.01	02	ENGINE - MOUNTING - EUROPE
10.001.01	03	ENGINE
10.001.01	04	HOOKS - ENGINE
10.001.02		CYLINDER BLOCK
10.101.01	01	CYLINDER HEAD
10.101.01	02	CYLINDER HEAD COVERS
10.101.16		ENGINE BREATHERS
10.102.01	01	OIL SUMP
10.102.11		ENGINE BLOCK FRONT COVER
10.103.01	01	CRANKSHAFT
10.103.02	01	ENGINE - FLYWHEEL
10.103.02	02	FLYWHEEL CASE
10.103.04		PULLEY - CRANKSHAFT
10.105.02	01	PISTON - ENGINE
10.105.02	02	CONNECTING ROD
10.106.01		CAMSHAFT - TIMING CONTROL
10.106.05		ROCKER SHAFT
10.202.01	01	AIR CLEANER - ENGINE, OLD STYLE
10.202.01	02	AIR CLEANER - ENGINE, NEW STYLE
10.206.03	01	FUEL FILTER
10.206.03	02	KIT, FUEL SYSTEM - INLINE FUEL FILTER
10.206.07		PIPING - FUEL
10.210.01		FUEL PUMP
10.214.01		INJECTION PUMP
10.216.01	01	FUEL TANK
10.216.01	02	FUEL TANK - FUEL SHUT-OFF VALVE, IF USED
10.218.01	01	INJECTION EQUIPMENT - FUEL, RETURN
10.218.01	02	INJECTION EQUIPMENT - PIPING
10.218.01	03	INJECTION EQUIPMENT - PIPING
10.218.01	04	INJECTION EQUIPMENT - INJECTOR
10.220.02		CONTROLS - THROTTLE
10.220.02	02	FOOT THROTTLE
10.250.03		TURBOCHARGER
10.254.02	01	ENGINE - BLOCK HEATER
10.254.02	02	ENGINE - BLOCK HEATER
10.254.02	03	GRID HEATER
10.254.03	01	EXHAUST SYSTEM
10.254.03	02	KIT, ASPIRATOR
10.254.04		INTAKE MANIFOLD
10.254.05		EXHAUST MANIFOLD
10.304.01	01	OIL FILL, ENGINE
10.304.01	03	OIL PUMP PIPING
10.304.02	01	PUMP, ENGINE OIL & RELATED PARTS
10.304.02	02	ENGINE OIL OIL PRESSURE REGULATOR
10.304.04		FILTER ENGINE OIL
10.400.02		PIPING - ENGINE COOLING SYSTEM
10.402.01		TEMPERATURE CONTROL (THERMOSTAT)
10.402.06		WATER PUMP
10.406.01		RADIATOR/OIL COOLER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

10.406.01	02	HYDRAULICS - OIL COOLER BYPASS
10.408.06	01	HEAT EXCHANGER - ENGINE
10.408.06	02	HEAT EXCHANGER
10.414.01		COMPLETION PARTS
10.414.04		BELT PULLEY DRIVE & COVER
10.414.05	01	FAN, RADIATOR/OIL COOLER - COOLANT RECOVERY SYSTEM
10.414.05	02	FAN; HIGH FLOW
29.200.01	01	HAND CONTROL - LEVERS
29.200.01	02	FOOT CONTROL - LEVERS
29.200.03	01	HAND CONTROL - KICK PANEL
29.200.03	02	HAND CONTROL - KICK PANEL
29.200.03	03	FOOT CONTROL - KICK PANEL
29.200.03	04	FOOT CONTROL - KICK PANEL, RH
29.200.03	05	FOOT CONTROL - KICK PANEL, LH
29.200.04	01	HAND CONTROL - PEDALS
29.200.04	02	PEDAL
29.200.04	03	PEDALS - MODELS WITH PILOT CONTROL
29.200.04	04	PEDALS - MODELS WITH PILOT CONTROL, EH AUX CONTROL
29.200.04	05	KIT, FOOT CONTROL SHOCK ABSORBER
29.200.05	01	HAND CONTROL - TUNNEL
29.200.05	02	HAND CONTROL - TUNNEL, PILOT CONTROL
29.200.05	03	TUNNEL - MODELS WITH PILOT CONTROL, EH AUX CONTROL
29.200.07	01	HANDLES - CONTROL
29.200.07	02	HANDLES
29.200.07	03	HANDLE, CONTROL
29.200.07	04	HANDLE, CONTROL
29.200.07	05	HANDLES - CONTROL - MODELS WITH PILOT CONTROL
29.200.07	06	HANDLES - CONTROL - MODELS WITH PILOT CONTROL, EH AUX CONTROL
29.200.07	08	HANDLES, MODELS WITH PILOT CONTROL, AUX CONTROL
29.200.07	10	MULTI-FUNCTION HANDLE, LH
29.200.07	11	MULTI-FUNCTION HANDLE - CONTROL
29.212.01	02	HYDROSTATICS - TANDEM PUMP
29.212.01	03	HYDROSTATICS AND RESONATOR - TANDEM PUMP
29.212.01	05	HYDROSTATICS - PUMP TO MANIFOLD
29.212.02	01	HYDROSTATICS - PUMP TO MANIFOLD, MODELS WITH PILOT CONTROLS
29.212.02	02	HYDROSTATICS - TANDEM PUMP, MODELS WITH PILOT CONTROLS
29.212.02	03	HYDROSTATICS - PUMP TO MANIFOLD, MODELS WITH PILOT CONTROLS
29.212.02	08	HYDROSTATICS - PILOT CONTROL TO PUMP
29.212.03	01	HYDRAULICS - JOYSTICK VALVE KITS, ISO PATTERN, RIGHT HAND
29.212.03	02	HYDROSTATICS - JOYSTICK VALVE KITS, ISO PATTERN, LEFT HAND
29.212.03	03	HYDROSTATICS - JOYSTICK VALVE KITS, ISO PATTERN, LEFT HAND
29.212.03	05	HAND CONTROL - PILOT CONTROL, UPPER RH
29.212.03	06	HAND CONTROL - PILOT CONTROL, UPPER RH
29.212.03	07	HAND CONTROL - PILOT CONTROL, UPPER LH
29.212.03	08	HAND CONTROL - PILOT CONTROL, UPPER LH
29.212.04	03	HYDROSTATICS - TWO SPEED
29.212.05	01	PUMP, GEAR
29.212.06	01	VALVE - HAND CONTROL
29.212.06	02	VALVE - HAND CONTROL
29.212.06	03	HYDROSTATICS - TWO SPEED, VALVE ASSY
29.212.07	01	PUMP, TANDEM

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

29.212.07	02	PUMP, TANDEM
29.212.07	03	PUMP, TANDEM
29.212.07	04	PUMP, TANDEM
29.212.07	05	PUMP, TANDEM
29.212.07	06	PUMP, TANDEM
29.212.08	01	REXROTH PUMP AA22
29.212.08	02	PRESSURE RELIEF VALVE
29.212.08	03	PRESSURE RELIEF VALVE
29.212.08	04	INTERNAL GEAR PUMP
29.212.08	05	ROTARY GROUP, RH ROTATION
29.212.08	06	ROTARY GROUP, LH ROTATION
29.212.08	07	CONTROL, HYDRAULIC
29.212.08	08	CONTROL CARTRIDGE WITH ORIFICE
29.212.08	09	VALVE SECTION - LOCKING ELEMENTS
29.212.15	01	MOTOR - SINGLE SPEED
29.212.15	02	MOTOR - SINGLE SPEED
29.212.15	03	MOTOR - SINGLE SPEED
29.212.16	01	MOTOR - TWO SPEED
29.212.16	02	MOTOR - TWO SPEED
29.212.16	03	MOTOR - TWO SPEED
29.218.06		TRANSMISSION CENTERING
33.202.01	01	BRAKE SYSTEM - HYDRAULIC, MODELS WITH PILOT CONTROL
33.202.01	02	BRAKE SYSTEM - HYDRAULIC
33.202.01	03	BRAKE - ON ROAD, PILOT CONTROL
33.202.01	04	BRAKE - ON-ROAD, EUROPE
35.204.04	01	HYDRAULICS - CONTROL VALVE
35.204.04	03	HYDRAULICS - CONTROL VALVE, MODELS WITH PILOT CONTROL
35.204.04	04	HYDRAULICS - PILOT CONTROL TO CONTROL VALVE
35.204.04	05	HYDRAULICS - CONTROL VALVE, MOUNTING PLATE
35.204.05	01	BUCKET HYDRAULICS, STANDARD
35.204.05	02	HYDRAULICS - BUCKET, HIGH FLOW
35.204.05	03	HYDRAULICS - BOOM, STANDARD
35.204.05	04	HYDRAULICS - BOOM, HIGH FLOW
35.204.05	05	HYDRAULICS - HIGH FLOW, PILOT CONTROL
35.204.05	07	HYDRAULICS - HIGH FLOW
35.204.05	08	HYDRAULICS - HIGH FLOW KIT
35.204.05	09	HYDRAULICS - BOOM CONTROL KIT
35.204.11	01	HYDRAULICS - MOUNTING PLATE
35.204.11	02	HYDRAULIC MOUNT PLATE SHIELD KIT
35.204.11	03	HYDRAULICS - MOUNTING PLATE, WITHOUT HIGH FLOW (IF USED)
35.204.11	04	HYDRAULICS - MOUNTING PLATE CONVERSION, WITHOUT HIGH FLOW
35.204.11	05	HYDRAULICS - MOUNTING PLATE, STANDARD FLOW (IF USED)
35.204.11	06	HYDRAULICS - MOUNTING PLATE CONVERSION, HIGH FLOW
35.204.11	07	CYLINDER - MOUNTING PLATE
35.204.11	08	HYDRAULIC MOUNT PLATE KIT
35.204.11	09	HYDRAULIC MOUNT PLATE KIT
35.204.15	10	VALVE, HIGH FLOW
35.220.07	01	SECONDARY FRONT AUXILIARY
35.220.07	02	SECONDARY REAR AUXILIARY
35.300.06	01	FILTER & RESERVOIR
35.300.06	02	HYDRAULIC FILTER

Order the manual at mid-west-tech.com >