CASE

PROFESSIONAL PARTNER

# PARTS CATALOG
# WHEEL LOADER

## 621E
## TIER 3

**87659893 EN-US**

Replaces 87519729 NA

Issued 01Sep 07
Revised 01Feb 09



Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | |
|---|---|
| 01-01 | DIA |
| 02-01 | MOUNTING, ENGINE |
| 02-02 | RADIATOR - HOSES AND TUBES |
| 02-03 | COOLER, CHARGE AIR |
| 02-04 | COOLER, CHARGE AIR - HOSES AND TUBES |
| 02-05 | FAN DRIVE |
| 02-06 | AIR CLEANER - AIR INTAKE PARTS |
| 02-06A | AIR CLEANER ASSY |
| 02-06B | AIR CLEANER - AIR INTAKE PARTS - COMMODITY KING |
| 02-07 | AIR CLEANER ASSY - PRECLEANER ASSY |
| 02-08 | MUFFLER - EXHAUST SYSTEM |
| 02-09 | OIL FILL, ENGINE |
| 02-10 | OIL PUMP - ENGINE |
| 02-11 | OIL FILTER - ENGINE |
| 02-12 | OIL FILTER AND COOLER |
| 02-13 | OIL PUMP, PAN |
| 02-14 | OIL PUMP, PAN - DRAIN LINE - COVER |
| 02-15 | BREATHER - ENGINE |
| 02-16 | TURBOCHARGER - DRAIN LINE |
| 02-17 | TURBOCHARGER |
| 02-18 | WATER PUMP |
| 02-19 | WATER PUMP - TENSIONER ASSY |
| 02-20 | CYLINDER BLOCK |
| 02-21 | CYLINDER BLOCK - PLUG ASSY |
| 02-22 | CYLINDER BLOCK - STIFFENER |
| 02-23 | CYLINDER HEAD |
| 02-24 | CYLINDER HEAD - ASSEMBLY |
| 02-25 | CYLINDER HEAD - COVERS |
| 02-26 | CRANKSHAFT |
| 02-27 | CRANKSHAFT - PULLEY |
| 02-28 | FLYWHEEL - ENGINE |
| 02-29 | FLYWHEEL HOUSING |
| 02-30 | GEAR COVER - REAR HOUSING |
| 02-31 | GEAR COVER - PLATE |
| 02-32 | FRONT GEAR COVER |
| 02-33 | ROCKER ARMS |
| 02-33A | ROCKER ARMS - ASSEMBLY |
| 02-34 | CAMSHAFT |
| 02-35 | PISTONS |
| 02-36 | CONNECTING ROD |
| 02-37 | INTAKE MANIFOLD |
| 02-38 | EXHAUST MANIFOLD |
| 02-39 | COOLING SYSTEM - ENGINE |
| 02-40 | THERMOSTAT - ENGINE COOLING SYSTEM |
| 02-41 | ENGINE - LIFT HOOKS |
| 02-42 | ENGINE - BLOCK HEATER |
| 03-01 | FUEL LINES - COOLER, FUEL |
| 03-02 | FILTER, FUEL - WATER SEPARATOR |
| 03-03 | FILTER, FUEL |
| 03-04 | FUEL TANK FILLER - SENDER |
| 03-04A | FUEL TANK - BREATHER |



Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | |
|---|---|
| 03-05 | FUEL INJECTION PUMP |
| 03-06 | FUEL INJECTION SYSTEM |
| 03-07 | FUEL INJECTION SYSTEM - INJECTOR |
| 03-08 | FUEL INJECTION SYSTEM - FUEL, SUPPLY |
| 03-09 | FUEL INJECTION SYSTEM - MODULE, ENGINE CONTROL |
| 03-10 | FUEL INJECTION SYSTEM - HARNESS, ENGINE |
| 03-11 | FUEL INJECTION SYSTEM - DRAIN LINE |
| 04-01 | STARTER |
| 04-02 | ALTERNATOR ASSY |
| 04-02A | ALTERNATOR - MOUNTING WITH AIR CONDITIONING |
| 04-02B | ALTERNATOR - MOUNTING WITHOUT AIR CONDITIONING |
| 04-03 | HARNESS, FRONT - Z-BAR |
| 04-03A | HARNESS, FRONT - XT |
| 04-04 | HARNESS - PANEL, CONTROL |
| 04-05 | HARNESS, ENGINE |
| 04-06 | HARNESS, ENGINE - THROTTLE CONTROL |
| 04-07 | HARNESS, ENGINE - FUSES AND RELAYS |
| 04-08 | HARNESS - ROOF - CAB/CANOPY |
| 04-09 | HARNESS, HOOD - ALARM, BACKUP |
| 04-10 | HARNESS, TRANSMISSION |
| 04-11 | HARNESS - GRID HEATER |
| 04-11A | GRID HEATER |
| 04-12 | HARNESS - STEERING, AUXILIARY |
| 04-13 | HARNESS - JOYSTICK STEERING |
| 04-14 | CAB - PANEL, CONTROL - FUSE AND RELAY MOUNTING |
| 04-14A | CAB - FUSES AND RELAYS |
| 04-14B | CAB - PANEL, CONTROL - SWITCHES |
| 04-15 | ELECTRICAL - STEERING COLUMN / INSTRUMENT CLUSTER |
| 04-16 | ELECTRICAL - TRANSMISSION CONTROL |
| 04-17 | HORN, FRONT |
| 04-18 | MOUNTING - LAMPS, FRONT |
| 04-19 | LAMP ASSY - LAMPS, FRONT |
| 04-20 | MOUNTING - LAMPS, REAR COMBINATION |
| 04-21 | CAB/CANOPY - WORK LAMPS |
| 04-22 | BEACON ASSY, ROTATING - MOUNTING |
| 04-22A | ROTATING BEACON COMPONENTS |
| 04-23 | CAB - WIPER, FRONT |
| 04-23A | CAB - WIPER, REAR |
| 04-24 | RADIO - 12 VOLT |
| 04-24A | RADIO - 12 VOLT INSTALLATION |
| 04-25 | BATTERY MOUNTING |
| 04-25A | BATTERY MOUNTING - HEAVY DUTY |
| 04-26 | BATTERY - CABLES |
| 04-27 | LICENSE PLATE LIGHT |
| 04-28 | WINDSHIELD WASHER MOUNTING |
| 05-01 | CAB/CANOPY - STEERING WHEEL |
| 05-02 | CAB/CANOPY - STEERING COLUMN (76303625) |
| 05-02A | CAB/CANOPY - STEERING COLUMN (87497543) |
| 05-03 | CAB - STEERING COLUMN - ACCESSORY |
| 05-04 | CAB - STEERING COLUMN - COVERS, SWITCHES |
| 05-05 | CANOPY - STEERING COLUMN - ACCESSORY |



Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | |
|---|---|
| 05-06 | CANOPY - STEERING COLUMN - COVERS, SWITCHES |
| 05-07 | STEERING - HYDRAULICS |
| 05-08 | STEERING - HYDRAULICS - AUXILIARY |
| 05-09 | STEERING - HYDRAULICS - CYLINDER |
| 05-10 | JOYSTICK STEERING - JOYSTICK CONTROL AND HARNESS |
| 05-11 | JOYSTICK STEERING - ARMREST, JOYSTICK CONTROL |
| 05-12 | JOYSTICK STEERING - HYDRAULICS |
| 05-13 | JOYSTICK STEERING - HYDRAULICS - AUXILIARY |
| 05-14 | CYLINDER ASSY - STEERING |
| 05-15 | PUMP - STEERING, AUXILIARY |
| 05-16 | VALVE ASSY - JOYSTICK STEERING |
| 05-17 | VALVE ASSY - JOYSTICK STEERING, PVFC |
| 05-18 | VALVE ASSY - STEERING CONTROL |
| 05-19 | VALVE ASSY - STEERING, AUXILIARY |
| 06-01 | MOUNTING - TRANSMISSION - TRANSMISSION FILL TUBE |
| 06-02 | HYDRAULICS - TRANSMISSION |
| 06-03 | TRANSMISSION - FILTER, OIL AND FILLER COVER - PRIOR TO P.I.N. N8F203848 |
| 06-04 | TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT - PRIOR TO P.I.N. N8F203848 |
| 06-05 | TRANSMISSION - INPUT SHAFT - PRIOR TO P.I.N. N8F203848 |
| 06-06 | TRANSMISSION ASSY - HOUSING - PRIOR TO P.I.N. N8F203848 |
| 06-07 | TRANSMISSION ASSY - HOUSING TUBES - PRIOR TO P.I.N. N8F203848 |
| 06-08 | TRANSMISSION - CLUTCH ASSY, FIRST - PRIOR TO P.I.N. N8F203848 |
| 06-09 | TRANSMISSION - CLUTCH ASSY, SECOND - PRIOR TO P.I.N. N8F203848 |
| 06-10 | TRANSMISSION - CLUTCH ASSY, THIRD - PRIOR TO P.I.N. N8F203848 |
| 06-11 | TRANSMISSION - CLUTCH ASSY, FOURTH - PRIOR TO P.I.N. N8F203848 |
| 06-12 | TRANSMISSION - CLUTCH ASSY, FORWARD - PRIOR TO PIN N8F203848 |
| 06-13 | TRANSMISSION - CLUTCH ASSY, REVERSE - PRIOR TO P.I.N. N8F203848 |
| 06-14 | TRANSMISSION - SHAFT, OUTPUT - PRIOR TO P.I.N. N8F203848 |
| 06-15 | TRANSMISSION - POWER TAKE OFF - PRIOR TO P.I.N. N8F203848 |
| 06-16 | TRANSMISSION - VALVE PLATES - PRIOR TO P.I.N. N8F203848 |
| 06-17 | TRANSMISSION - VALVE, CONTROL - PRIOR TO P.I.N. N8F203848 |
| 06-18 | TRANSMISSION - VALVE, CONTROL - PRIOR TO P.I.N. N8F203848 |
| 06-19 | TRANSMISSION - VALVE, REGULATOR AND OIL PUMP - PRIOR TO P.I.N. N8F203848 |
| 06-20 | TRANSMISSION - SENSOR, SPEED AND PUMP COVER - PRIOR TO P.I.N. N8F203848 |
| 06-21 | TRANSMISSION - FILTER, OIL AND FILLER COVER - P.I.N. N8F203848 AND AFTER |
| 06-22 | TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT - P.I.N. N8F203848 AND AFTER |
| 06-23 | TRANSMISSION - INPUT SHAFT - P.I.N. N8F203848 AND AFTER |
| 06-24 | TRANSMISSION ASSY - HOUSING - P.I.N. N8F203848 AND AFTER |
| 06-25 | TRANSMISSION ASSY - HOUSING TUBES - P.I.N. N8F203848 AND AFTER |
| 06-26 | TRANSMISSION - CLUTCH ASSY, FIRST - P.I.N. N8F203848 AND AFTER |
| 06-27 | TRANSMISSION - CLUTCH ASSY, SECOND - P.I.N. N8F203848 AND AFTER |
| 06-28 | TRANSMISSION - CLUTCH ASSY, THIRD - P.I.N. N8F203848 AND AFTER |
| 06-29 | TRANSMISSION - CLUTCH ASSY, FOURTH - P.I.N. N8F203848 AND AFTER |
| 06-30 | TRANSMISSION - CLUTCH ASSY, FORWARD - P.I.N. N8F203848 AND AFTER |
| 06-31 | TRANSMISSION - CLUTCH ASSY, REVERSE - P.I.N. N8F203848 AND AFTER |
| 06-32 | TRANSMISSION - SHAFT, OUTPUT - P.I.N. N8F203848 AND AFTER |
| 06-33 | TRANSMISSION - POWER TAKE OFF - P.I.N. N8F203848 AND AFTER |
| 06-34 | TRANSMISSION - VALVE PLATES - P.I.N. N8F203848 AND AFTER |
| 06-35 | TRANSMISSION - VALVE, CONTROL - P.I.N. N8F203848 AND AFTER |



Order the manual at mid-west-tech.com >

AXLE, FRONT - BRAKE - PRIOR TO P.I.N. N8F203848

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| | | 87358580 | | 1 | AXLE, FRONT, Limited Slip; Incl. Figures 06-41 - 06-45; Incl. Refs. 1 - 15; Prior To P.I.N. N8F203848 |
| | | 87358680 | | 2 | END, Incl. Refs. 1 - 15; Incl. Figure 06-45 |
| | | 87363338 | | 2 | REMAN-AXLE, END ASSY. Remanufactured 87358680; Parts In Catalog Do Not Apply to Remanufactured Assy |
| | | 87363332 | | 2 | CORE-AXLE, END ASSY. Return Number, Core 87358680, Use This Part Number To Return Core For Credit When Using A Remanufactured Assy |
| 1 | | 8603166 | | 1 | PISTON |
| 2 | | 8605314 | | 1 | SEAL |
| 3 | | 8603577 | | 1 | RING |
| 4 | | 8605315 | | 1 | SEAL |
| 5 | | 8603579 | | 1 | RING |
| 6 | | 8603580 | | 1 | RING, SNAP |
| | | 87365251 | | 1 | KIT, REPAIR, Brake Pack Replacement, Incl. Parts For One Complete Axle (Two Wheel Ends); Incl. (2X) Refs. 7 - 8A |
| 7 | | 87341835 | | 3 | BRAKE DISC |
| 8 | | 8603582 | | 2 | PLATE, BRAKE |
| 8A | | 87441328 | | 2 | PLATE |
| 9 | | 8603163 | | 6 | PIN |
| 10 | | 8603583 | | 24 | RING, SNAP |
| 11 | | 8603584 | | 42 | WASHER |
| 12 | | 8603162 | | 1 | SHIM |
| 13 | | 8603788 | | 6 | RING, SNAP |
| 14 | | 8603585 | | 1 | RING, SNAP |
| 15 | | 8603796 | | 6 | PIN, ROLL, 6 x 20 mm |



MidWestTech | Case 621E Tier 3 Wheel Loader Parts Catalog | Publication 87659893 Order the manual at mid-west-tech.com >

## VALVE ASSY - PISTON AXIS - (Z-BAR/XR)

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| | | REF | | | INSTRUCTION, TWO, THREE, AND FOUR SPOOL VALVES FOR Z-BAR/XR MODELS |
| 15 | | 8604575 | | 1 | KIT, Incl. 15A, 15B; For REF 16, 17, 18 |
| 15A | | NSS | | 4 | NOT SERVICED SEPARATELY, O-Ring; 25.07 x 2.62 |
| 15B | | NSS | | 2 | NOT SERVICED SEPARATELY, Lock Nut; M8 x 1 |
| 16 | | 8604576 | | 2 | COVER |
| 17 | | 87311972 | | 1 | COVER |
| 18 | | 8605577 | | 1 | COVER |
| 19 | | 864-5060 | | 2 | SCREW, Hex Soc Hd, M5 x 60, 8.8, M5 X 60; 8.8 |
| 20 | | 87311974 | | 2 | SCREW, M5 x 85; 10.9 |
| 21 | | 87657975 | | 4 | SCREW, M5 x 55; 8.8 |
| 22 | | 8604578 | | 2 | VALVE, HYDRAULIC, Throttle Check Valve |
| 23 | | 87311975 | | 1 | SPOOL |
| 24 | | 87311976 | | 1 | SPOOL |
| 25 | | 8604579 | | 1 | PISTON |
| 26 | | 8604580 | | 2 | SPRING, Compression |
| 27 | | 8604581 | | 3 | SCREW, Plug; M22 x 1.5 |
| 28 | | 8604582 | | 2 | RETAINER, Spring |
| 29 | | 8604583 | | 4 | SPRING, Compression |
| 30 | | 87311984 | | 2 | SPRING, Retanier |
| 31 | | 87311985 | | 1 | SPRING |
| 32 | | 87311986 | | 1 | RING |
| 33 | | 8604584 | | 1 | PISTON |
| 34 | | 87311988 | | 1 | PLUG |
| 35 | | 8604586 | | 1 | SPRING, Compression |
| 36 | | 87311990 | | 2 | JET |
| 37 | | 87311991 | | 1 | SPOOL |



MidWestTech | Case 621E Tier 3 Wheel Loader Parts Catalog | Publication 87659893 Order the manual at mid-west-tech.com >

## COUPLER, HYDRAULIC - XT - ACS

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| | | REF | | 1 | INSTRUCTION, COUPLER, 87446140; ACS PRO 2000 Size 30; XT; Includes Jump Hoses; Not Illustrated |
| | | REF | | 1 | INSTRUCTION, PACKAGE, 87446143; Manual; ACS PRO 2000 Size 30; XT; Not Illustrated |
| | | REF | | 1 | INSTRUCTION, CYLINDER/PIN KIT; ACS; XT; Vendor Part Number; 65595535; Incl. 11 - 16 |
| 1 | | REF | | 2 | INSTRUCTION, FITTING, TEE; ACS; XT; Vendor Part Number; 52800540 |
| 2 | | REF | | 2 | INSTRUCTION, FITTING, 90DEG; ACS; XT; Vendor Part Number; 52801119 |
| 3 | | REF | | 2 | INSTRUCTION, HOSE; ACS; XT; Vendor Part Number; 54830114 |
| 4 | | REF | | 2 | INSTRUCTION, FITTING, BULKHEAD TEE; ACS; XT; Vendor Part Number; 52800803 |
| 5 | | REF | | 2 | INSTRUCTION, FITTING, CAP; ACS; XT; Vendor Part Number; 52800727 |
| 6 | | REF | | 1 | INSTRUCTION, HOSE; ACS; XT; Vendor Part Number; 54830358 |
| 7 | | REF | | 1 | INSTRUCTION, HOSE; ACS; XT; Vendor Part Number; 54001576 |
| 8 | | REF | | 2 | INSTRUCTION, HOSE; ACS; XT; Vendor Part Number; 54823250 |
| 9 | | REF | | 4 | INSTRUCTION, RETAINER; ACS; XT; Vendor Part Number; 62640051 |
| 10 | | REF | | 2 | INSTRUCTION, NUT; BULKHEAD; ACS; XT; Vendor Part Number; 52001444 |
| 11 | | REF | | 2 | INSTRUCTION, PIN, LOCKING; ACS; XT; Vendor Part Number; 40600850; 2 x 6-9/16 IN |
| 12 | | REF | | 4 | INSTRUCTION, HEX BOLT; ACS; XT; Vendor Part Number; 60660520; 1/2-13 X 2 in |
| 13 | | REF | | 2 | INSTRUCTION, PIN,ROLL; ACS; XT; Vendor Part Number; 40336700; 3/8 X 1-7/8 in |
| 14 | | REF | | 4 | INSTRUCTION, WASHER; ACS; XT; Vendor Part Number; 60680180; 1/2 Lock |



MidWestTech | Case 621E Tier 3 Wheel Loader Parts Catalog | Publication 87659893 Order the manual at mid-west-tech.com >