MC1150E
Tractor, Full Tracked
W/Multi-Purpose Bucket
NSN 3805-01-315-1091
MC1155E Crawler
DLA700-89-C-8140

Parts Catalog

Bur 8-7831

MidWestTech | Case MC1155E W/Multi Purpose Bucket Crawler Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Adjuster - track 5-9
Air Cleaner Assembly 2-47
Air Cleaner Mounting 2-45
Air Restriction Indicator 2-49
Alarm - backup 4-31
Alternator Assembly 4-7
Alternator Mounting Parts 2-37
Armrests 9-39

B

Backup Alarm 4-31
Batteries and Cables 4-15
Belt
- Alternator 2-37
- Fan 2-37
- Seat ..... 9-39 - 9-43

Block - cylinder, engine 2-25
Block Heater - engine 2-25
Blower - cab, inside cab roof ..... 9-61 - 9-63
Brake System
- Brake Assembly - transmission 7-3,7-5
- Parking - manual 7-9
- Power 7-7

Brush Screens - ROPS 9-29
Bucket and Teeth - loader 9-9

C

Cab
- Air Filter ..... 9-59 - 9-61
- Blower - inside cab roof ..... 9-61 - 9-63
- Control Panel 4-25,4-27
- Door ..... 9-51 - 9-53
- Electrical ..... 4-25 - 4-27
- Frame and Mounting 9-49
- Glass 9-55,9-57
- Headliner 9-59
- Heating System 9-65
- Screen - rear 9-53
- Window - door ..... 9-51 - 9-53
- Windshield Wipers 4-29

Camshaft - engine 2-23
Carrier Roller Assembly 5-13
Chain - track 5-19
Clutch - transmission ..... 6-17 - 6-21
Cold Start System 4-35
Connecting Rods - engine 2-31
Controls
- Brake - manual and power 7-9
- Cab Accessories 4-25,4-27
- Engine Throttle 3-3,3-5
- Equipment - levers and linkage ..... 8-33 - 8-35
- Forward, Reverse and Steering 6-61

C

Controls-Cont.
- Fuel Shutoff 4-13

Control Tower - transmission 9-25
Control Valve - equipment 8-37
Control Valve Mounting - equipment 8-31
Coolant Recovery System - radiator 2-41
Cooling System - transmission 6-53,6-55
Counterweights 9-11
Cover - rear, battery access 9-23
Crankshaft - engine 2-27
Cylinders - hydraulic
- Clam Bucket 8-29
- Loader Bucket Tilt 8-27
- Loader Lift 8-25

D

Decals 9-71,9-73
Dipstick
- Engine Oil 2-39
- Transmission Oil 6-13

Dome Lamp - cab 4-25
Door - cab 9-51,9-53
Door - rear access 9-23
Drawbar 9-11
Drive Shaft 6-9

E

Electrical System
- Cab ..... 4-25 - 4-27
- Instrument Panel - tractor ..... 4-9 - 4-13
- Tractor ..... 4-9 - 4-13

Engine Components
- Camshaft 2-23
- Connecting Rods 2-31
- Crankshaft 2-27
- Cylinder Block 2-25
- Cylinder Head Cover 2-21
- Flywheel and Housing 2-29
- Front Gear Cover 2-7
- Fuel Filter 3-13
- Fuel Injection System 3-11
- Gasket Kits 2-33
- Injection Pump and Drive 3-15
- Injector Nozzle 3-17
- Manifolds - intake and exhaust 2-9
- Oil Filter and Cooler 2-15
- Oil Pump and Pan 2-17
- Pistons 2-31
- Thermostat 2-19
- Turbocharger 2-11
- Valve Mechanism 2-21
- Water Pump 2-3

MidWestTech | Case MC1155E W/Multi Purpose Bucket Crawler Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

FAN CLUTCH 2-4
FAN DISCONNECT 2-51

ALPHABETICAL INDEX

E

Engine Mounting 2-37
Exhaust - stack and muffler 2-45

F

Fan - cab blowers 9-61,9-63
Fan - engine 2-37
Filter
  Air - cab 9-59,9-61
  Air Cleaner 2-47
  Fuel 3-13
  Oil - engine 2-15,2-17
  Oil - equipment, hydraulic reservoir 8-3
  Oil - transmission 6-57
Final Drive - transmission 6-25
Floor Plates 9-37
Floormat - cab 9-49
Fluid Recovery Bottle - transmission 6-47
Flywheel - engine 2-29
Flywheel Mounting to Flex Plate 6-7
Frame
  Loader Lift 9-3,9-5
  Main and Engine 9-17
  Rear - tank and seat 9-23
  Seat Mounting ..... 9-39 - 9-43
  Track 5-3
Fuel
  Filter 3-13
  Injection System 3-11
  Lines to Engine 3-9
  Pump 3-13
  Tank 3-7

G

Gauge - instrument 4-9,4-11
Glass - cab 9-55,9-57
Grille - radiator 9-29
Guards
  Hydraulic Lines - see Hydraulic Circuits
  Roll Over Protective Structure 9-45,9-49
  Side Shields - engine 9-35
  Track - covers and rock guards 5-17
  Transmission 9-19
  Undercarriage - belly pans 9-19

H

Harness - front wiring 4-19
Harness - rear wiring ..... 4-21 - 4-27
Head Lamp 4-25
Headliner - cab 9-59
Heater
  Cab 9-65

H

Heater-Cont.
  Engine Block 2-25
Hood 9-31
Horn 4-33
Hydraulic Circuits
  Clam Bucket 8-23
  Equipment - reservoir to pump and control valve 8-9,8-11
  Loader Bucket Tilt 8-19
  Loader Lift 8-15,8-17
  Torque Converter to Transmission 6-49
  Transmission - control valve 6-35,6-37
  Transmission Cooling 6-53,6-55
  Transmission to Charging Pump 6-51
Hydraulic Reservoir and Covers ..... 8-3 - 8-5

I

Idler Assembly - track 5-11
Idler Mounting 5-5
Instrument Panel
  Cab 4-25,4-27
  Cover - tractor instrument panel 9-33
  Tractor 4-9,4-11

L

Lamps - flood, and wiring ..... 4-25 - 4-37
Levers - see Controls
Loader
  Buckets and Teeth 9-9
  Lift Frame 9-3,9-5
  Return-to-Dig 9-7

M

Main Frame 9-17
Manifold - intake and exhaust 2-9
Muffler 2-45

N

Noise Reduction Pads 9-45,9-47
Nozzle - fuel injector 3-17

O

Oil Cooler - engine 2-15
Oil Pump and Pan - engine 2-17
Operators Compartment Closure Panels 9-25

P

Pads - cab roof 9-59
Pads - noise reduction 9-45,9-47
Parking Brake - manual 7-9
Pedal

MidWestTech | Case MC1155E W/Multi Purpose Bucket Crawler Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

P

Pedal-Cont.
- Brake ..... 7-7 - 7-9
- Throttle Control 3-3

Pistons - engine 2-31
Precleaner Assembly - engine 2-47
Pulley
- Alternator 4-7
- Crankshaft 2-27
- Fan and Water Pump 2-3,2-5

Pump
- Fuel 3-13
- Fuel Injection 3-11
- Oil - engine 2-17
- Oil - equipment 8-13
- Oil - transmission charging 6-59
- Water - engine 2-3

R

Radiator Assembly 2-43
Radiator Mounting 2-41
Recoil System - track 5-5,5-7
Reservoir - hydraulic 8-3
Restriction Indicator - air cleaner 2-49
Return-to-dig - loader 9-7
Rocker Arms - engine 2-21
Roll Over Protective Structure ..... 9-45 - 9-49
Roller - track and carrier ..... 5-9 - 5-13

S

Screen
- Radiator - grille 9-29

Seal Kits - transmission ..... 6-39 - 6-45
Seat Assembly ..... 9-39 - 9-43
Seat Belt and Seat Mounting ..... 9-39 - 9-43
Shoes - track 5-21
Shroud - radiator 9-27,9-29
Side Shields - engine 9-35
Sprocket - track drive 5-3
Starter Assembly 4-5
Starter Mounting 2-37
Strut - support, loader lift frame 9-3

T

Tank
- Fuel 3-7
- Hydraulic Oil 8-3

Teeth - bucket 9-9
Thermostat - water temp
Torque Converter ..... 6-3 - 6-7
Track
- Adjuster Assembly 5-9
- Carrier Roller Assembly 5-13

T

Track-Cont.
- Chain 5-19
- Frame 5-3
- Guards - rock 5-17
- Idler Assembly 5-11
- Recoil System and Covers 5-5,5-7
- Roller Assembly 5-15
- Shoes 5-21
- Sprocket 5-3

Transmission Components
- Bevel Pinion Shaft and Gear 6-23
- Brakes 7-3,7-5
- Clutches ..... 6-17 - 6-21
- Clutch Shafts - LH and RH 6-19
- Control Valve ..... 6-29 - 6-33
- Dipstick 6-13
- Final Drive 6-25
- Housing and Covers 6-11,6-13
- Hydraulic Circuits - control valve 6-37
- Input Shaft 6-15
- Planetary System 6-15
- Seal Kits ..... 6-39 - 6-45
- Transmission Fluid Recovery Bottle 6-47

Turbocharger System - engine 2-11

U

Undercarriage Guards - belly pans 9-19

V

Valve
- Anticavitation Assembly - equipment control valve 8-51
- Equipment Control Valve Assembly 8-37
- Mounting 8-31
- Relief Assembly - equipment control valve 8-49
- Section Assemblies - equipment control valve ..... 8-39 - 8-47
- Transmission Control ..... 6-27 - 6-33

Valve Mechanism - engine 2-21

W

Windshield Wipers 4-29
Wiring
- Cab ..... 4-25 - 4-27
- Instrument Panel - tractor 4-9,4-11
- Lamps 4-25,4-27
- Tractor ..... 4-25 - 4-27

MidWestTech | Case MC1155E W/Multi Purpose Bucket Crawler Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >