9310, 9330

Tractors

SERVICE MANUAL

8-83352

CASE IH AGRICULTURE

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

GENERAL TORQUE SPECIFACTION TABLE 3
SAE FASTENER TORQUE CHART 3
METRIC FASTENER (ISO) TORQUE CHART 3
STANDARD TORQUE DATA FOR HYDRAULIC TUBES AND FITTINGS 4

FLUID CAPACITIES AND TYPES 5

SPECIFICATIONS 6

DIESEL ENGINE 7

ELECTRICAL SPECIFICATIONS 7

WHEEL BOLT TORQUES 9

TRAVEL SPEEDS 9

GENERAL DIMENSIONS: 10

AUXILIARY POWER CONNECTIONS 11

TRANSMISSION CONTROLLER AND INSTRUMENT CLUSTER CALIBRATION 14
POWER SHIFT TRANSMISSION PROCEDURE 14
DYNAMIC ROLLING RADIUS 15

TIRE CODE NUMBERS 16

STEERING SYSTEM CALIBRATION 17
CALIBRATION PROCEDURE 17

TIRE INFLATION SPECIFICATIONS 22
RADIAL TIRES 22
CHECKING AIR PRESSURE 23
RADIAL TIRE PRESSURE AND LOAD CAPACITY CHART 24
U.S. STANDARD AT 25 MPH TRAVEL SPEED 24
METRIC AT 40 KPH TRAVEL SPEED 24
BIAS TIRE PRESSURE AND LOAD CAPACITY CHART 25
TIRE PRESSURE FOR MAXIMUM TIRE LOAD AT RATED INFLATION 25


BAR AXLE WHEEL ADJUSTMENT 26
SPLIT BUSHING HUB 26
BAR TYPE AXLE WHEEL DISC POSITIONS 27
WHEEL OFFSET DIRECTION CHANGE 27

TREAD SETTING - SLIDING HUB MOUNTED DUALS 28

ARTICULATION STOP SETTINGS 30
IMPLEMENTS WITH HEAVY VERTICAL DRAWBAR LOADS 32
Front End Weights 33
Rear End Weights (Drawbar Only) 34
Front End Weight Mounting 34

NOTE: Case Corporation reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

MidWestTech | Case 7100, 7200 Magnum Tractor Service Manual | Publication 8-83352 Order the manual at mid-west-tech.com >



MA95G021

MidWestTech | Case 7100, 7200 Magnum Tractor Service Manual | Publication 8-83352 Order the manual at mid-west-tech.com >