585
685
595
695
Tractors

SERVICE MANUAL

7-36892

CASE IH AGRICULTURE

MidWestTech | Case 585, 685, 595, 695 Tractor Service Manual | Publication 8-85063

Order the manual at mid-west-tech.com >

Schematic Circuit

TRAILER CONNECTOR
Connects the tractor electrical circuit to a trailer

SPLICE
Connects one or more circuits that do the same function

CHASSIS GROUND
Completes battery circuit

FLASHER RELAY
Electrical device which opens and closes a circuit continually when actuated

ROTARY SWITCH (LAMP SWITCH)
Directs electrical current to one or more circuits

LAMP
Produces heat that emits artificial light

FUSE
Protects the electrical system from high output or a ground in the electrical system

CONNECTOR E (YELLOW)
Connects the cab harness to the instrument cluster harness at the bulkhead

RELAY
A magnetic switch that directs electric current

CONNECTOR F (GRAY)
Connects the cab harness to the instrument cluster harness at the bulkhead


INSTRUMENT CLUSTER
Displays information from senders or switches


SOLENOID (ETHER START)
A magnetic coil that actuates a hydraulic valve

DIMMER SWITCH
Connects a single terminal to either of the other two terminals

CONNECTOR B (BLACK)
Connects the engine harness to the instrument cluster harness at the bulkhead

SINGLE POLE SINGLE THROW SWITCH
Connects one terminal to another





Order the manual at mid-west-tech.com >