5130 / 5230 / 5140 / 5240 And 5250 Tractors

Parts Catalog

Includes Supplement Pages

Don 8-9074

CASE IH AGRICULTURE

MidWestTech | Case 5130, 5230, 5140, 5240, 5250 Tractor Parts Catalog | Publication 8-9... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Adjustable Axle 2WD
- Axle Assembly 5-21
- Steering Cylinder 5-19
- Tie Rods 5-23

Air Cleaner 2-9
Air Cleaner And Connections 2-5, 2-7
Air Conditioning
- Compressor 2-31
- Compressor, Condenser And Drier 2-25

Alternator Assembly 4-51, 4-53
Alternator Mounting 4-49

B

Battery And Connections 4-39, 4-41
Brake Pedals And Master Cylinders 7-9
Brake Piping 7-11
Master Cylinder 7-13
Parking Brake 7-3
Parking Brake Controls 7-5
Service Brake 7-7

C

Cab
- Air Conditioning 9-107
- Air Filter And Inner Roof 9-101
- Blower Assembly 9-103
- Doors ..... 9-77 thru 9-87
- External Trim 9-65
- Electrical Access 9-63
- Heater 9-105
- Headlining 9-97
- Heating And Ventilation Controls 9-99
- Interior Mats 9-67
- Mirrors ..... 9-111 thru 9-115
- Mounting 9-41
- Radio Speakers And Antenna 9-109
- Rear Window Wiper 4-67
- Rear Window 9-91
- Roof 8-93, 9-95
- Steps 9-117, 9-119
- Windshield And Side Glass 9-89
- Windshield And Rear Window Washer 4-69
- Windshield Wiper Front 4-65

Camshaft 2-51
Control Console Right 9-69
Crankshaft 2-65
Cylinder Head And Covers 2-47
Cylinder Head And Valve Mechanism 2-49
Cylinder Block ..... 2-53 thru 2-59

D

Decals 9-163, 9-165

E

Electrical Harness
- Cab 4-13, 4-15
- Control Console 4-25, 4-27
- Engine 4-9, 4-11
- Instrument Panel ..... 4-17 thru 4-23
- Powershift 4-7
- Rear Fender 4-29, 4-31
- Transmission 4-3, 4-5

Engine Gasket Kits 2-71
Engine Side Rails And Front Bolsters 9-37
Engine Oil Filler 2-61, 2-63
Ether Start 2-21
Exhaust
- Downswept 2-15, 2-17
- Vertical 2-11, 2-13

F

Flywheel, Housing And Torque Limiter 2-19
Front End Weights 9-155, 9-157
Front Fenders 9-131, 9-133
Front Gear Cover 2-35
Front Grille 9-43, 9-45
Fuel
- Filler Neck 3-7
- Filter 3-15, 3-17
- Injection Nozzle ..... 3-23 thru 3-27
- Injection Pump And Drive 3-19, 3-21
- Injection System 3-11, 3-13
- Lift Pump 3-15, 3-17
- Tank And Fuel Lines 3-3, 3-5

H

Headlights 4-53
Heater Hoses 2-23
Hitch
- 3 Point Front 9-29, 9-31
- Controls 9-25, 9-27
- Lift Links Lower 9-11
- Lift Links Upper 9-5, 9-7
- Rockshaft And Arm 9-3
- Stabilizer, Drawbar ..... 9-13, thru 9-19
- Top Link Float Version 9-33, 9-35
- Top Links Support 9-9
- Trailer Hitch 9-21, 9-23

Hoodsheet ..... 9-47 thru 9-53
Hydraulics
- Auxiliary Valves Stack 8-45
- Auxiliary Valve End Cover 8-51, 8-53
- Auxiliary Valve Manifold Inlet/Outlet 8-55
- Compensator Valve 8-19
- Controls - Remote Valves ..... 8-35 thru 8-41

(Continued on Next Page)

MidWestTech | Case 5130, 5230, 5140, 5240, 5250 Tractor Parts Catalog | Publication 8-9... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

H

Hydraulics (Continued)
- Draft And Position Sensing Lines 8-73
- Draft Control Valve 8-15, 8-17
- External Lubrication Pipes And Dipstick ... 8-27
- Hitch Rockshaft Cylinder 8-77
- Input Control Lines 8-31
- Input Control Valve 8-33
- Interior Remote Flow Controls 8-43
- Manifold And Pipes 8-23
- MFD Valve And Pipe 8-29
- Motor Return Coupler 8-49
- Oil Cooler And Pipes 8-3, 8-5
- Oil Filter 8-21
- Piping Front Hitch 8-79
- PTO 8-25
- Pump And Control Valve 8-11
- Pump Assembly 8-13
- Pump, Filter And Pipes 8-7, 8-9
- Remote Auxiliary Pipes 8-47
- Remote Priority Valve 8-57, 8-59
- Remote Valve Assemblies ..... 8-61 thru 8-71
- Sensor Assembly 8-75

I

Instruments Gauges And Switches 4-33
Instrument Cluster 4-35, 4-37
Instrument Panel ..... 9-71 thru 9-75

L

Light - Warning 4-61
Lights - Flood 4-59
Lights - Rear 4-57

M

Manifolds 2-37
Mechanical Front Drive
- Axle Assembly 5-25
- Bevel Gear Pinion Set 5-31
- Differential 5-33
- Drive Shaft 5-35, 5-37
- Housing 5-27
- Planetaries And Hub 5-39
- Swivel Housings And Steering Cylinder ... 5-29

MFD Clutch And Drive Shafts 6-101
MFD Drive And Idler Gears 6-99

O

Oil Filter And Cooler 2-43
Oil Pump And Oil Pan 2-45

P

Pistons And Connecting Rods 2-67, 2-69
Platform 9-121
Protective Shields For Hydraulic Pump 9-39
Power Take Off
- Controls And Shield 6-95, 6-97
- Clutch And Drive Shaft 6-85
- Housing And Oil Baffle 6-83
- Oil Pump Drive 6-79
- Reversible 540/1000 RPM 6-87, 6-89
- Valve 6-93
- Valve And Linkage 6-91

R

Radiator And Connections 2-3
Rear Fenders 9-127, 9-129
Rear Wheels
- Adjustable ..... 6-103 thru 6-107
- Bar Axle 6-111
- Clamping Device (Bar Axle) 6-113
- Hub Dual Wheels (Bar Axle) 6-115
- Non-Adjustable 6-109
- Weights 6-117

R O P S 9-123, 9-125

S

Seat
- Assembly ..... 9-137 thru 141
- Belts 9-153
- Mounting 9-135
- Suspension ..... 9-143 thru 151

Side Panels ..... 9-55 thru 9-61
Slow Moving Vehicle Emblem 9-161
Speed Sensor 4-63
Starter Motor 4-47
Starter Motor And Mounting 4-43
Steering Column And Wheel
- Rigid Steering Post 5-9
- Tiltable Only 5-3
- Tiltable And Telescopic 5-5, 5-7

Steering Hand Pump 5-17
Steering Pipes
- Pump To Steering Cylinder 2WD 5-13
- Pump To Steering Cylinder MFD 5-15
- Pump To Steering Pump And Filter 5-11

T

Thermostat And Housing 2-47
Throttle- Hand Lever And Foot Pedal 3-9
Toolbox 9-159
Transmission
- Breather 6-77
- Creeper Control 6-51
- Creeper Control Internal 6-53

(Continued on Next Page)

MidWestTech | Case 5130, 5230, 5140, 5240, 5250 Tractor Parts Catalog | Publication 8-9... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

T

Transmission (Continued)
- Differential 6-35, 6-37
- Forward And Reverse 6-33
  - Shuttle Controls 6-59, 6-61
  - Shuttle Valve 6-65
- Forward Neutral Reverse
  - Shuttle Controls 6-63
  - Shuttle Valve 6-67, 6-69
- Gear Shift
  - Controls 6-41
  - Linkage (Internal) 6-43
- Housing And Front Carrier 6-3, 6-5
- Main Drive ..... 6-19 thru 6-23
- Transaxle Housing Rear Carrier 6-25, 6-27
- Oil Pump And Filter 6-75
- Pedal Inching Control 6-71, 6-73
- Power Shift Control 6-55
- Power Shift Manifold And Tubes 6-57
- Range Gears 6-29, 6-31
- Range Shift
  - Controls 6-45
  - Linkage (Internal) 6-47, 6-49
- Rear Axle Housing And Carriers 6-39
- Speed Gears
  - Drop Shaft 6-9, 6-15, 6-17
  - Input Shaft 6-7, 6-11, 6-13

Turbocharger 2-41

V

W

Water Pump System 2-33

Wheels Front
- Adjustable 5-41
- Non-Adjustable 5-43

MidWestTech | Case 5130, 5230, 5140, 5240, 5250 Tractor Parts Catalog | Publication 8-9... Order the manual at mid-west-tech.com >