
MODEL MP

Featuring Full Hydraulic Controls

SERVICE MANUAL



For Service Concerns Only:
Direct Phone Line to Service Department,
8:00 AM to 5:00 PM Central Time,
Monday thru Friday.

Phone (414) 355-3181

Part No. 89-100127 • Rev. "0.2" dated December, 1996 •

MidWestTech | Terex Simon MP Hydraulic Boom Lift Service Manual | Publication 89_100127

Order the manual at mid-west-tech.com >

Table of Contents

Introduction vi
Machine Specifications MP 40 viii
Machine Specifications MP 50 ix
Machine Specifications MP 60 x
Machine Specifications MP 60Z xi
Machine Specifications MP 70 xii
Machine Specifications MP 80 xiii
Machine Component Locator xv
Undercarriage Component Locator xvi
Superstructure Component Locator xvii
Boom Component Locator xviii
Platform Component Locator xix
Lubrication Chart xx

Section 1: Transportation and Emergency Procedures

Transport the Unit 1-3
Towing Procedures 1-3
Lifting Procedures 1-3
Truck or Trailer Transport 1-3
Unloading Procedures 1-5
Emergency System and Procedures 1-6
Emergency Pumps 1-6
Unpowered Emergency Movement 1-6
Emergency Lowering 1-7

Section 2: Hydraulic System

Hydraulic Fluid 2-5
Handling Precautions 2-5
Fluid Recommendations 2-5
Fluid Contamination Checks 2-5
System Flushing Procedure 2-6
Hydraulic System Components 2-9
Hydraulic Pumps 2-9
Main Hydraulic Pump (Type 1) 2-9
Type One (1) Pump Adjustment 2-10
Main Hydraulic Pump (Type 2) 2-11
Type Two (2) Pump Adjustment 2-13
Emergency Pump 2-13
Emergency Pump Adjustment 2-13
Drive valves 2-14
Drive Relief Valve 2-14
Drive Valve Assembly 2-14
Hi/ Low Speed Drive Valve 2-14
Flow Divider Valve Assembly 2-14
Motion Control Valve Assembly 2-14
Drive Pilot Valve (Later Versions) 2-15
Hydraulic Fluid Reservoir 2-15
Hydraulic Reservoir Maintenance 2-15
High Pressure Filter 2-15

MidWestTech | Terex Simon MP Hydraulic Boom Lift Service Manual | Publication 89_1001... Order the manual at mid-west-tech.com >

Table of Contents (Continued)

Section 2: Hydraulic System

Boom Lift System 2-15
Directional Control Valves 2-15
Platform 2-15
Ground 2-15
Lift Cylinder 2-16
Boom Telescope (Extend) System 2-16
Directional Control Valves 2-17
Platform 2-17
Ground 2-17
Pressure Reducing Valve 2-17
Telescope (Extend) Cylinder 2-17
Mechanical Extend Function 2-18
Superstructure Swing System 2-19
Directional Control Valve 2-19
Platform 2-19
Ground 2-19
Swing Drive Motor/ Reducer Assembly 2-19
Worm Gear Type 2-19
Swing Gear and Pinion Shaft Adjustment 2-20
Planetary Gear Type with Intregal Brake 2-20
Swing Reducer/ Motor Assembly
Adjustment (MP60, MP 70, Later MP 80) 2-20
Worm Gear Type with Intregal Brake
(MP80, Earlier) 2-21
Swing Drive/ Reducer Assembly Adjustment 2-21
Integral Brake Assembly 2-22
Swing System Maintenance 2-22
Platform Rotate System 2-23
Rotate Control Valve 2-23
Double Pilot Operated Check Valve 2-23
Rotary Actuator 2-23
Rotary Actuator Maintenance 2-23
Platform Rotator Manifold 2-23
Platform Level System 2-24
Level Control Valve 2-24
Double Pilot Operated Check Valve 2-24
Master Level Cylinder 2-25
Slave Level Cylinder 2-25
Relief Valves 2-25
Steer System 2-26
Drive/ Steer Manifold Assembly 2-26
Hydraulic Swivel 2-26
Steer Cylinder 2-26
Steer Disconnect Knob 2-26
Steer System Maintenance 2-26
Solenoid Valve Checks 2-27

MidWestTech | Terex Simon MP Hydraulic Boom Lift Service Manual | Publication 89_1001... Order the manual at mid-west-tech.com >

Table of Contents (Continued)

Section 3: Drive System

Drive System Components 3-3
- Drive Motor and Brake Assembly 3-3
- Hydraulic Manifold Valve Assembly 3-4
- Drive Valve Assembly 3-4
  - Selector Valve 3-4
  - Motion Control Valve Assembly 3-4
  - Motion Control Valve 3-4
  - Flow Control Valve 3-5
  - Flow Divider Valve Assembly 3-5
  - Flow Divider/ Combiner Valve 3-5
  - Gate (Globe) Valve 3-5
  - Drive Pilot Valve (Later Versions) 3-5
- Drive Relief Valve 3-5
- Toggle Switch on the Pendant Control 3-5
- Drive Enable Valve 3-5
- Platform Control Handle 3-5

Section 4: Electrical System

Electrical System 4-3
- Battery 4-3
  - Battery Maintenance (In Storage) 4-3
  - Battery Maintenance (In Use) 4-3
  - Battery Preventive Maintenance 4-4
  - Battery Replacement 4-4
- Movement Alarm 4-4
- Tilt Alarm 4-4
  - Tilt Alarm Test 4-4
  - Tilt Alarm Adjustment 4-5
- Relays 4-5
- Circuit Breakers 4-5
- Limit Switches 4-5
- Emergency Pump 4-5
- Emergency Stop Button 4-6
- Pendant Switch Removal 4-6
- Ground Control Cabinet Switch Removal 4-6
- Platform Console Switch Removal 4-6

MidWestTech | Terex Simon MP Hydraulic Boom Lift Service Manual | Publication 89_1001... Order the manual at mid-west-tech.com >

PRESSURE SETTINGS	MP-40 MP-60	MP-50	MP-70 MP-80	MPH-60 MP-60Z	MPH-40	MPH-42	MPH-60
MAIN PUMP COMPENSATOR	2500 PSI	2300 PSI	3000 PSI	3000 PSI	2300 PSI	2300 PSI	2500 PSI
EMERGENCY PUMP	2500 PSI	2500 PSI	2500 PSI	2500 PSI	2500 PSI	2500 PSI	2500 PSI
MASTER LEVEL CYLINDER RELIEFS	3250 PSI	3250 PSI	3250 PSI	3250 PSI	3250 PSI	3250 PSI	3250 PSI
BOOM CYLINDER COUNTER BALANCE	3000 PSI	5000 PSI	5000 PSI	5000 PSI	5000 PSI	5000 PSI	5000 PSI
BOOM TELESCOPE COUNTER BALANCE	3000 PSI	3000 PSI	3000 PSI	3000 PSI	3000 PSI	3000 PSI	3000 PSI
SLAVE LEVEL CYLINDER COUNTER BALANCE	3000 PSI	3000 PSI	3000 PSI	3000 PSI	3000 PSI	3000 PSI	3000 PSI
PLATFORM ROTATOR RELIEF	700 PSI	700 PSI	700 PSI	700 PSI	700 PSI	700 PSI	700 PSI

STEERING CYLINDER
COUNTER BALANCE VALVE
HYDRAULIC MOTOR BRAKE ASSEMBLY
FLOW CONTROL
FLOW DIVIDER
RELIEF VALVE SET AT 3000 PSI
HYDRAULIC RESERVOIR
MAIN PUMP
EMERGENCY PUMP
10u FILTER
10u FILTER
4 5 1 2 3 6
3000 PSI GAUGE
MASTER LEVEL CYLINDER
SWING DRIVE
C2 C1
6:1 PILOT
BOOM HOIST CYLINDER
BOOM EXTEND CYLINDER
SLAVE LEVEL CYLINDER
DRIVE CONTROL
CAB CONTROLS
ROTARY ACTUATOR
HOIST
SWING
EXTEND
LOW SPEED DRIVE
LOWER/UPPER SUPPLY
3 WAY VALVE 2 SPEED DRIVE
HIGH SPEED DRIVE
STEER
BOOM HOIST
SWING
BOOM EXTEND
LOWER CONTROL VALVE
1500 PSI
SHUTTLE VALVES
HOSES THRU CATRAC
PRESS
TANK
.021
CAB LEVEL
.021
CAB ROTATE
REFERENCE: MP FULL HYDRAULIC 60 THRU 80
2 WHEEL DRIVE 2 SPEED

SIMON-AERIALS INC.
MILWAUKEE, WI. 53224
TITLE
HYDRAULIC SCHEMATIC
REVISION
DWG. NO. SDS 2324950

Order the manual at mid-west-tech.com >