
FALCON 2034
VERTICAL LIFT
S/N EDA (or EDB) 00101 and up

SERVICE MANUAL

For Service Concerns Only:
Direct Phone Line to Service Department, 8:00 AM to 5:00 PM Central Time, Monday thru Friday.
Phone (414) 355-3181



Art # A00.00710E

Part No. 89-750017 • Revision "0.3", dated Jan. 1997 •

MidWestTech | Terex Genie Falcon 2034 Vertical Boom Lift Service Manual | Publication 89_750017

Order the manual at mid-west-tech.com >

Table of Contents

Introduction iii
Machine Specifications iv
Primary Machine Components v
Undercarriage Components vii
Lubrication Chart viii
Lubrication Diagram ix

Transportation and Emergency Procedures
Transporting the Unit 1-3
Moving of the 2034 Link 1-3
Fork Lifting of the 2034 Link 1-3
Truck Transport of the 2034 Link 1-3
Single Point Lifting Hook (option) 1-3
Unloading Procedures 1-4
Emergency System and Procedures 1-5
Emergency Lowering with Hand Pump 1-5
Emergency Drive 1-5
Emergency Procedures 1-6

Hydraulic System
Hydraulic Fluid 2-3
Handling Precautions 2-3
Fluid Recommendations 2-3
Hydraulic Fluid Analysis 2-3
System Flushing Procedure 2-4
Hydraulic System Components 2-5
Hydraulic Fluid Reservoir 2-5
Hydraulic Pump 2-5
Control Valve Assembly 2-5
Main Relief Valve 2-5
Sequence Valve 2-6
Steer Valve 2-6
Steer Bypass Valve 2-6
Drive Valve 2-6
Counterbalance Valves (Drive) 2-6
Lift Valve (Normally Closed) 2-6
Cylinder Lowering Valve 2-7
Brake Release Shuttle Valve 2-7
Hi Speed Valve 2-7
Check Valves 2-7
Velocity Fuse 2-7
Cylinders 2-7
Drive Motors 2-8
Limit Switch 2-8
Hydraulic System Functional Description 2-8

Electrical System
Battery 3-3
Battery Maintenance (In Storage) 3-3
Battery Maintenance (In Use) 3-3
Battery Preventive Maintenance 3-3

MidWestTech | Terex Genie Falcon 2034 Vertical Boom Lift Service Manual | Publication 8... Order the manual at mid-west-tech.com >

Battery Replacement 3-4
Battery Charger 3-4
Movement Alarm (Optional) 3-4
Tilt Alarm (Optional) 3-4
Descent Alarm (Optional) 3-5
Automatic Warning Beacon (Optional) 3-5
Relays 3-5

Mechanical Components
Undercarriage 4-3
Tires 4-3
Changing Tires 4-3
Wheels And Lug Nuts 4-4
Front Hub Assembly 4-4
Repacking Front Wheel Bearings 4-4
Drive Motors 4-4
Steer Cylinder Seal Replacement 4-4
Brake Cylinder Seal Replacement 4-5
Hoses and Cables 4-5
Boom 4-5
Boom Lift Cylinder 4-5
Boom Lift Cylinder Removal 4-6
Boom Lift Cylinder Replacement 4-6
Boom Lift Cylinder Seal Replacement 4-7
Boom And Parallel Arm Pivot Pin Replacement 4-7
Boom And Parallel Arm Pivot Pin Bushing Replacement 4-8
Lift Cylinder Holding Valve Replacement 4-8
Cushion Cylinder Replacement 4-8

Troubleshooting
General Troubleshooting Tips 5-3
Troubleshooting Chart 5-4

Maintenance
Maintenance Schedule 6-3
General Maintenance Tips 6-3
First Three Months of Operation 6-3
Routine Servicing 6-3
Daily Service 6-4
Monthly Service 6-4
Weekly Service 6-4
Semi-Annual Service 6-5
Annual Service 6-5
Four Year Interval Service 6-5
Shift Operational Checklist 6-6
Weekly Operational Checklist 6-8
Monthly Operational Checklist 6-9
Semi-Annual Operational Checklist 6-10

Index

Appendix

TABLE OF CONTENTS

MidWestTech | Terex Genie Falcon 2034 Vertical Boom Lift Service Manual | Publication 8... Order the manual at mid-west-tech.com >

INTRODUCTION

This Service Manual is designed to provide you with the instructions needed to properly maintain the SIMON AERIALS INC. 2034 Link. When used in conjunction with the Operators and Parts manuals (provided separately) this Service Manual will assist you in making necessary adjustments or repairs.

Simon Aerial Veritcal Lifts are designed and built to provide many years of safe, dependable service. To obtain full benefits from your 2034 Link, always follow the proper operating and maintenance procedures. Only trained, authorized personnel should be allowed to operate or service this machine. Service personnel should read and study the Operators, Service and Parts Manuals in order to gain a thorough understanding of the unit prior to making any repairs. Exercise all necessary safety precautions when performing maintenance not covered in this manual.

To help you recognize important safety information, we have identified warnings and instructions that directly impact on safety with the following signals:

⚠ DANGER

DANGER INDICATES AN IMMINENTLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, WILL RESULT IN DEATH OR SERIOUS INJURY.


⚠WARNING

WARNING INDICATES A POTENTIALLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY.

⚠ CAUTION

Caution indicates a potentially hazardous situation or alerts against unsafe practices. It is also used for "property damage only" hazards.

MidWestTech | Terex Genie Falcon 2034 Vertical Boom Lift Service Manual | Publication 8... Order the manual at mid-west-tech.com >



Order the manual at mid-west-tech.com >