
# SERVICE MANUAL

## J30-35-40XMT(C160/F160)




FORM 897666 Rev. 11/03

MidWestTech | Hyster J30-35-40XMT(C160/F160) Forklift Service Manual | Publication 897... Order the manual at mid-west-tech.com >

# J30-35-40XMT(C160/F160)
# SERVICE MANUAL CONTENTS


| Section | SRM Number | Rev Date |
|---|---|---|
| FRAME | 0100 SRM 0567 | 06/95 |
| DC MOTOR MAINTENANCE | 0620 SRM 0294 | 08/03 |
| TRANSAXLE ASSEMBLY | 1300 SRM 0568 | 08/03 |
| STEERING HOUSING AND CONTROL UNIT (C160) | 1600 SRM 0512 | 08/03 |
| STEERING SYSTEM (C160) | 1600 SRM 0569 | 06/95 |
| STEERING HOUSING AND CONTROL UNIT (F160) | 1600 SRM 0655 | 03/97 |
| STEERING SYSTEM (F160) | 1600 SRM 0688 | 04/97 |
| BRAKE SYSTEM | 1800 SRM 0570 | 08/03 |
| MAIN CONTROL VALVE | 2000 SRM 0576 | 08/03 |
| TILT CYLINDERS | 2100 SRM 0103 | 10/03 |
| EV-100/200LX MOTOR CONTROLLER and HANDSET | 2200 SRM 0460 | 07/99 |
| INSTRUMENT CLUSTER | 2200 SRM 0514 | 01/04 |
| ELECTRICAL SYSTEM | 2200 SRM 0577 | 04/97 |
| INDUSTRIAL BATTERY | 2240 SRM 0001 | 11/03 |
| MAST-DESCRIPTION | 4000 SRM 0521 | 11/03 |
| MAST-REPAIR | 4000 SRM 0522 | 11/03 |
| INCH (SAE) and METRIC FASTENERS | 8000 SRM 0231 | 03/03 |
| PERIODIC MAINTENANCE | 8000 SRM 0528 | 02/97 |
| DIAGRAMS (C160) | 8000 SRM 0529 | 12/97 |
| CAPACITIES and SPECIFICATIONS | 8000 SRM 0571 | 07/97 |
| DIAGRAMS (F160) | 8000 SRM 0693 | 06/97 |



**PART NO. 897666**
**Rev. 11/03**



MidWestTech | Hyster J30-35-40XMT(C160/F160) Forklift Service Manual | Publication 897... Order the manual at mid-west-tech.com >