
X-2032 SCISSORS

Genie®
A TEREX COMPANY

SERVICE MANUAL



For Service Concerns Only:
Direct Phone Line to Service Department, 8:00 AM to 5:00 PM Central Time, Monday thru Friday.

Phone (414) 355-3181

Part No. 89-994707 • Initial Issue dated Feb. 1995 •

MidWestTech | Terex Genie X-2032 Scissor Lift Service Manual | Publication 89_994707

Order the manual at mid-west-tech.com >

Table of Contents

Introduction v
Machine Specifications vii
Primary Machine Components viii
Undercarriage Components x
Scissors Arm Components xi
Platform Components xii
Lubrication Chart xiv
Lubrication Diagram xv

Section 1: Transportation and Emergency Procedures
Transporting the Unit
- Moving of the Scissors Lift 1-3
- Fork Lifting of the Scissors Lift 1-3
- Truck Transport of the Scissors Lift 1-3
- Unloading Procedures 1-4

Emergency System and Procedures
- Emergency Lowering 1-5
- Emergency Drive 1-5
- Emergency Procedures 1-6

Section 2: Hydraulic System
Hydraulic Fluid .....
- Handling Precautions 2-3
- Fluid Recommendations 2-3
- Hydraulic Fluid Analysis 2-3
- System Flushing Procedure 2-4

Hydraulic System Functional Description 2-5
Hydraulic System Components
- Hydraulic Fluid Reservoir 2-6
- Hydraulic Pump 2-6
- Control Valve Assembly 2-6
- System and Steer Relief Valves 2-7
- Lift Valve 2-7
- Lift Lockout Valve 2-7
- Steer Valve 2-7
- High Speed Valve 2-8
- Forward and Reverse Drive Valves 2-8
- Counterbalance Valves (Drive) 2-8
- Series/ Parallel Valve Manifold 2-8
- Series/ Parallel Valves 2-8
- Series/ Parallel Relief Valve 2-8
- Series/ Parallel Flow Divider 2-8
- Lift Cylinder Holding Valves 2-9
- Cylinders 2-9
- Drive Motors 2-9
- Solenoid Valve Checks 2-9

MidWestTech | Terex Genie X-2032 Scissor Lift Service Manual | Publication 89_994707 Order the manual at mid-west-tech.com >

Table of Contents (Continued)

Section 3: Electrical System
Batteries 3-3
Battery Charger 3-4
Battery Charger Troubleshooting 3-5
Movement Alarm 3-5
Tilt Alarm 3-5
Descent Alarm 3-6
Automatic Warning Beacon 3-6
Relays 3-6
Electric Motors 3-6
Emergency Stop Buttons 3-6

Section 4: Mechanical Components
Undercarriage 4-3
Tires 4-3
Changing Tires 4-3
Wheels And Lug Nuts 4-3
Front Hub Assembly
Repacking Front Wheel Bearings 4-3
Steer Cylinder Seal Replacement 4-4
Brake Cylinder Repair 4-4
Drive Motors 4-6
Hoses and Cables 4-6
Platform Removal 4-6
Platform Installation 4-6
Platform Assembly/ Disassembly 4-6
Lift Cylinder Removal 4-9
Lift Cylinder Installation 4-9
Lift Cylinder Seal Replacement 4-9
Lift Cylinder Holding Valve Replacement 4-9
Scissors
Scissors Arm Removal 4-10
Scissors Arm Installation 4-10
Scissors Arms Disassembly 4-10
Scissors Arms Assembly 4-12
Pivot Pin Bushing Replacement 4-14
Cushion Cylinder Repair 4-14

MidWestTech | Terex Genie X-2032 Scissor Lift Service Manual | Publication 89_994707 Order the manual at mid-west-tech.com >

Table of Contents (Continued)

Section 5: Troubleshooting
General Troubleshooting Tips 5-3
Troubleshooting Chart 5-4

Section 6: Maintenance
Maintenance Schedule 6-3
General Maintenance Tips 6-3
First Three Months of Operation 6-3
Routine Servicing
- Daily Service 6-4
- Monthly Service 6-4
- Weekly Service 6-4
- Semi-Annual Service 6-5
- Annual Service 6-5
- Four Year Interval Service 6-5


Shift Operational Checklist 6-6
Weekly Operational Checklist 6-8
Monthly Operational Checklist 6-9
Semi-Annual Operational Checklist 6-10

Index

Appendix
Hydraulic Schematic X-12032 Scissors Lift
D-2340980 ..... A-3
Electric Schematic X-2032 Scissors Lift
B-2340620 ..... A-5

MidWestTech | Terex Genie X-2032 Scissor Lift Service Manual | Publication 89_994707
Order the manual at mid-west-tech.com >

MidWestTech | Terex Genie X-2032 Scissor Lift Service Manual | Publication 89_994707



REF: X-2032 WITH LOW VOLTAGE CUTOUT, GERMAN SPEC.

SIMON-AERIALS INC.

ELECTRICAL SCHEMATIC

A

B-2290060

Order the manual at mid-west-tech.com >