621B - 721B Loader

Operators Manual

Rac 9-23916

Reprinted

CASE CONSTRUCTION

MidWestTech | Case 621B, 721B Loader Operator's Manual | Publication 9-23916

Order the manual at mid-west-tech.com >

GENERAL TABLE OF CONTENTS

TO THE OWNER 1
RIGHT, LEFT, FRONT AND REAR SIDES OF THE MACHINE 2

IDENTIFICATION NUMBERS 3

SAFETY/DECALS/HAND SIGNALS 5
SAFETY RULES 5
BEFORE OPERATION 6
MACHINE OPERATION 7
PARKING THE MACHINE 7
MAINTENANCE 8
BURN PREVENTION 9
FIRE OR EXPLOSION PREVENTION 9
HAZARDOUS CHEMICALS 10
SAFETY DECALS 11
HAND SIGNALS 16

INSTRUMENTS/CONTROLS 19
FRONT CONSOLE 19
LOADER CONTROL LEVERS 29
LOADER FUNCTION SWITCHES 35
FACT (FAST ATTACHMENT COUPLING TEAM) 39
LOW COOLANT INDICATOR (621B ONLY) 39
WRIST REST 39
BUCKET LEVEL INDICATOR 40
RIDE CONTROL (IF EQUIPPED) 41
INSTRUMENT PANEL 42
CAB CONTROLS AND LIGHTS 45
OPERATORS SEAT 49
GAUGES 51
WINDSHIELD WIPER CONTROLS
AND ROTATING BEACON SWITCH 53
WINDSHIELD WASHER RESERVOIR 54
RADIO (IF EQUIPPED) 54

OPERATING INSTRUCTIONS 55
RUN-IN PROCEDURE 55
ENGINE OPERATION 56
MACHINE OPERATION 65

JOB SITE OPERATIONS 70
LOADER OPERATING TIPS 70
OPERATING IN COLD WEATHER 72
OPERATING IN HOT WEATHER 74
TOWING THE MACHINE 74

TRIM THIS EDGE

MidWestTech | Case 621B, 721B Loader Operator's Manual | Publication 9-23916 Order the manual at mid-west-tech.com >

TRANSPORTING THE MACHINE 75

WHEELS/TIRES/BALLAST 76
WHEELS AND TIRES 76
BALLAST 79

LUBRICATION/FILTERS/FLUIDS 80
GENERAL SAFETY BEFORE YOU SERVICE 80
PLASTIC AND RESIN PARTS 80
ENVIRONMENT 80
ENGINE HOURMETER 81
TRANSPORT/SERVICE LINK 82
ACCESS DOORS 85
SYSTEMGARD™ LUBRICATION
ANALYSIS SYSTEM 86
Z-BAR LINKAGE 87
XT LINKAGE 90
ENGINE LUBRICATION 93
AIR FILTER SYSTEM 98
ENGINE COOLING SYSTEM 103
DIESEL FUEL SYSTEM 107
HYDRAULIC/BRAKE SYSTEM 113
TRANSMISSION 119
AXLES 124
CAB AIR FILTERS (IF EQUIPPED) 126

MAINTENANCE/ADJUSTMENTS 128
STARTING FLUID CAN 128
SECONDARY STEERING CHECK 129
CAB SERVICE 130
FIRE EXTINGUISHER 132
LOADER ADJUSTMENTS - Z-BAR LINKAGE 133
LOADER ADJUSTMENTS - XT LINKAGE 140
ROLL-OVER PROTECTIVE STRUCTURE 147
SPARK ARRESTING MUFFLER (IF EQUIPPED) 150

ELECTRICAL SYSTEM 151
BATTERIES 151
REPLACEMENT BULBS 154

MACHINE STORAGE 155

SPECIFICATIONS 157
OPERATING DATA AND DIMENSIONS - 621B 157
OPERATING DATA AND DIMENSIONS - 621B-XR 162
ENGINE DATA (621B) 170
TRAVEL SPEEDS (621B) 171

TRIM THIS EDGE

MidWestTech | Case 621B, 721B Loader Operator's Manual | Publication 9-23916 Order the manual at mid-west-tech.com >

WEIGHTS - 621B Z-BAR 172
WEIGHTS - 621B -XR 172
WEIGHTS - 621B XT 172
SPECIAL BOLT TORQUES (621B) 176
OPERATING DATA AND DIMENSIONS - 721B 177
OPERATING DATA AND DIMENSIONS - 721B -XR 182
ENGINE DATA (721B) 192
ENGINE DATA (721B) 193
TRAVEL SPEEDS - (721B) 193
WEIGHTS - 721B Z-BAR 194
WEIGHTS - 721B -XR 194
WEIGHTS - 721B XT 194
SPECIAL BOLT TORQUES - 721B 198
AFTER DELIVERY CHECK 199

DETAIL INDEX 204

TRIM THIS EDGE

MidWestTech | Case 621B, 721B Loader Operator's Manual | Publication 9-23916 Order the manual at mid-west-tech.com >