3200 - 4200 Series Tractors

Operators Manual

Don 9-24854

CASE IH AGRICULTURE

MidWestTech | Case 3200, 4200 Series Tractor Operator's Manual | Publication 9-24854

Order the manual at mid-west-tech.com >

GENERAL TABLE OF CONTENTS

TO THE OWNER 1

IDENTIFICATION NUMBERS 4

SAFETY/DECALS 7
- SAFETY RULES 7
- MOUNTING AND DISMOUNTING THE TRACTOR 11
- SAFETY DECALS 12
- ROLL OVER PROTECTIVE STRUCTURE (ROPS) 17

INSTRUMENTS/CONTROLS 19
- DIGITAL INSTRUMENT CLUSTER 21
- OPERATING CONTROLS (Tractors with Cab) 24
- REAR VIEW MIRRORS 35
- ROOF HATCH 35
- REAR WINDOW 36
- CAB DOOR LOCK 36
- OPERATING CONTROLS (Non-Cab Tractors) 37
- OPERATORS SEAT 45

OPERATING INSTRUCTIONS 46
- BEFORE STARTING THE ENGINE 46
- SERVICE INDICATOR LAMPS AND GAUGES 47
- RUN IN PROCEDURE 47
- SEAT BELT 49
- NORMAL STARTING PROCEDURE 50
- STOPPING THE ENGINE 52
- PARKING THE TRACTOR 53
- COLD TEMPERATURE OPERATION 54
- TOWING THE TRACTOR 61
- HOW TO TRANSPORT THE TRACTOR 62
- TRANSMISSION OPERATING INSTRUCTIONS 63
- DIFFERENTIAL LOCK 73
- MFD OPERATION 74
- CAB AIR FLOW ARRANGEMENTS (XL CAB) 75
- AIR CONDITIONER OPERATION 78
- POWER TAKEOFF (PTO) 79
- DRAWBAR OPERATION 85
- TRACTOR WARNING LAMPS AND DIRECTION TURN SIGNALS 86

TRIM THIS EDGE

MidWestTech | Case 3200, 4200 Series Tractor Operator's Manual | Publication 9-24854 Order the manual at mid-west-tech.com >

FIELD OPERATION **89**
DRAWBAR PREPARATION 89
THREE POINT HITCH SYSTEM PREPARATION 91
THREE POINT HITCH OPERATION 100
REMOTE HYDRAULICS OPERATION 105
AUXILIARY POWER CONNECTIONS 110
DIGITAL INSTRUMENT CLUSTER PROGRAMMING 111
HOURMETER 122
IMPLEMENT MONITOR 123
ROPS FRAME 124

TIRES/WHEELS/SPACING/BALLAST **125**
TIRE AND WHEEL EQUIPMENT 125
TIRE PRESSURES AND LOAD CAPACITIES 127
TIRE AND WHEEL SERVICE 131
FRONT TO REAR TIRE SIZE COMBINATIONS 132
FRONT WHEEL TREAD POSITIONS 134
REAR WHEEL TREAD POSITIONS 138
TOE-IN SETTING 144
WHEEL BOLT TORQUES 146
MFD AXLE STEERING STOP ADJUSTMENT 148
MFD AXLE OSCILLATION STOPS 149
FRONT WHEEL FENDERS 152
TRACTOR BALLAST 153

LUBRICATION/FILTERS/FLUIDS **162**
HOURMETER 162
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 163
LUBRICATION/MAINTENANCE CHART 164
HOOD AND SIDE COVERS 166
GREASE POINTS 168
CAPACITIES 170
ENGINE LUBRICATION 171
FUEL SYSTEM 175
COOLING SYSTEM 182
AIR INDUCTION SYSTEM 187
TRANSMISSION LUBRICATION 191
MECHANICAL FRONT DRIVE (MFD) AXLE 195
2WD FRONT WHEEL BEARINGS 197
OPERATORS CAB 198

TRIM THIS EDGE

MidWestTech | Case 3200, 4200 Series Tractor Operator's Manual | Publication 9-24854 Order the manual at mid-west-tech.com >