1840 Uni-Loader

Operators Manual

P.I.N. JAF0223014 and After

Bur 9-25053

Reprinted

CASE CONSTRUCTION

MidWestTech | Case 1840 Uni-Loader Operator's Manual | Publication 9-25053

Order the manual at mid-west-tech.com >

GENERAL TABLE OF CONTENTS

TO THE OWNER **1**
1840 UNI-LOADER 1
GENERAL INFORMATION 2
AFTER DELIVERY CHECK 2
RIGHT, LEFT, FRONT AND REAR OF MACHINE 3
PRODUCT IDENTIFICATION AND SERIAL NUMBERS 4
MACHINE COMPONENTS 6, 7
BACKHOE COMPONENTS 8

SAFETY/DECALS/HAND SIGNALS **9**
SAFETY FEATURES 9
SAFETY RULES 10
BEFORE OPERATION 11
BURN PREVENTION 12
HAZARDOUS CHEMICALS 12
FIRE OR EXPLOSION PREVENTION 13
MACHINE OPERATION 14
PARKING THE MACHINE 15
WHEELS AND TIRES SAFETY 15
CAST DUCTILE IRON 15
UTILITY SAFETY 16
MAINTENANCE 17
SAFETY DECALS 18
HAND SIGNALS 23

INSTRUMENTS/CONTROLS **27**
INSTRUMENT CLUSTER 27, 28, 29
INSTRUMENT PANEL 30
INSTRUMENT PANEL 31, 32, 33
ENGINE HAND THROTTLE 34
HORN BUTTON 34
BACK-UP ALARM (OPTIONAL) 34
OPERATORS SEAT 35, 36, 37
OPERATOR RESTRAINT SYSTEM 39
OPERATORS PRESENCE SYSTEM 39
SEAT BELT PROCEDURE 41
STEERING CONTROLS 43
LOADER CONTROLS 44, 45
AUXILIARY HYDRAULIC ATTACHMENT CONTROLS 46

TRIM THIS EDGE

MidWestTech | Case 1840 Uni-Loader Operator's Manual | Publication 9-25053 Order the manual at mid-west-tech.com >

OPERATING INSTRUCTIONS **49**
RUN-IN PERIOD OF A NEW MACHINE 49
ENGINE OPERATION 50
OPERATING IN COLD WEATHER 52
ETHER STARTING AID 53
THERMOSTART SYSTEM 54
OPERATING IN HOT WEATHER 57
MACHINE OPERATION 58
OPERATING THE LOADER 59
REAR WINDOW (IF EQUIPPED) 61
CASE MECHANICAL COUPLER 62
CASE PINNED COUPLER 63
BACKHOE OPERATION 65
HIGH FLOW HYDRAULIC SYSTEM 75
TRANSPORTING THE MACHINE 78
LIFTING THE MACHINE WITH A CRANE 79
MOVING A DISABLED MACHINE 80

WHEELS/TIRES **81**
WHEELS AND TIRES 81

LUBRICATION/MAINTENANCE CHARTS **85**
GENERAL SAFETY BEFORE YOU SERVICE 85
SUPPORT STRUT FOR LOADER LIFT ARMS 86
ENGINE HOURMETER 87
MAINTENANCE SCHEDULE 87
FLUIDS AND LUBRICANTS 88

LUBRICATION/FILTERS/FLUIDS **91**
REAR ACCESS DOOR 91
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 92
GREASE FITTINGS - 10 HOURS 93, 94, 95, 96
GREASE FITTINGS - 250 HOURS 97
GREASE FITTINGS - 10 AND 250 HOURS 98
ENGINE LUBRICATION 99
AIR FILTER SYSTEM 104
ENGINE COOLING SYSTEM 110
DIESEL FUEL SYSTEM 113
HYDRAULIC SYSTEM 118
DRIVE CHAIN COMPARTMENT 122

TRIM THIS EDGE

MidWestTech | Case 1840 Uni-Loader Operator's Manual | Publication 9-25053 Order the manual at mid-west-tech.com >

MAINTENANCE/ADJUSTMENTS **123**
MOVING THE OPERATORS COMPARTMENT FORWARD 123
MOVING THE OPERATORS COMPARTMENT INTO THE OPERATING POSITION 126
TESTING THE SEAT BAR 128
DRIVE CHAINS 129
STEERING LEVER ADJUSTMENT 133
SPARK ARRESTER MUFFLER 134
ROLL-OVER PROTECTIVE STRUCTURE 135
CASE MECHANICAL COUPLER 142
MAINTENANCE OF THE SEAT BELT 143
MACHINE CLEANING 143
PLASTIC AND RESIN PARTS 143
FAN BELT REPLACEMENT 143
THERMOSTART SYSTEM 144, 145

ELECTRICAL SYSTEM **147**
BATTERY SERVICE 147
WORK LAMPS 149
FUSES AND RELAYS 151

STORAGE **153**
STORAGE 153
REMOVAL FROM STORAGE 154

SPECIFICATIONS **155**
ENGINE 155
COOLING SYSTEM 155
HYDRAULIC SYSTEM 155
OPERATING WEIGHTS 156
POWER TRAIN 156
BACKHOE BUCKETS 157
MANURE FORK 157
PALLET FORK WITH BRICK GUARD 157
OPERATING DATA AND DIMENSIONS 158
D100 BACKHOE 160
D100XR BACKHOE 161

DETAIL INDEX **163**

AFTER DELIVERY CHECK **169, 171**

TRIM THIS EDGE

MidWestTech | Case 1840 Uni-Loader Operator's Manual | Publication 9-25053 Order the manual at mid-west-tech.com >