1845C Uni-Loader

Operators Manual

P.I.N. JAF0250483 and After

Bur 9-25063

Reprinted

CASE
CONSTRUCTION

MidWestTech | Case 1845C Uni-Loader Operator's Manual | Publication 9-25063

Order the manual at mid-west-tech.com >

GENERAL TABLE OF CONTENTS

TO THE OWNER **1**
1845C UNI-LOADER 1
GENERAL INFORMATION 2
AFTER DELIVERY CHECK 2
RIGHT, LEFT, FRONT AND REAR OF MACHINE 3
PRODUCT IDENTIFICATION AND SERIAL NUMBERS 4
MACHINE COMPONENTS 6, 7
BACKHOE COMPONENTS 8

SAFETY/DECALS/HAND SIGNALS **9**
SAFETY FEATURES 9
SAFETY RULES 10
BEFORE OPERATION 11
BURN PREVENTION 12
HAZARDOUS CHEMICALS 12
FIRE OR EXPLOSION PREVENTION 13
MACHINE OPERATION 14
PARKING THE MACHINE 15
WHEELS AND TIRES SAFETY 15
CAST DUCTILE IRON 15
UTILITY SAFETY 16
MAINTENANCE 17
SAFETY DECALS 18
HAND SIGNALS 25

INSTRUMENTS/CONTROLS **29**
INSTRUMENT CLUSTER 29, 30, 31
INSTRUMENT PANEL 32, 33, 34, 35
ENGINE HAND THROTTLE 36
HORN BUTTON 36
BACK-UP ALARM (OPTIONAL) 36
OPERATORS SEAT 37, 38, 39
OPERATOR RESTRAINT SYSTEM 41
OPERATORS PRESENCE SYSTEM 41
SEAT BELT PROCEDURE 43
STEERING CONTROLS 45
LOADER CONTROLS 46, 47
AUXILIARY HYDRAULIC ATTACHMENT CONTROLS 48

TRIM THIS EDGE

MidWestTech | Case 1845C Uni-Loader Operator's Manual | Publication 9-25063 Order the manual at mid-west-tech.com >

OPERATING INSTRUCTIONS **51**
RUN-IN PERIOD OF A NEW MACHINE 51
ENGINE OPERATION 52
OPERATING IN COLD WEATHER 54
ETHER STARTING AID 55
THERMOSTART SYSTEM 56
OPERATING IN HOT WEATHER 59
MACHINE OPERATION 60
OPERATING THE LOADER 61
REAR WINDOW (IF EQUIPPED) 63
CASE MECHANICAL COUPLER 64
CASE PINNED COUPLER 65
CASE HYDRAULIC COUPLER 67
BACKHOE OPERATION 68
HIGH FLOW HYDRAULIC SYSTEM 80
TRANSPORTING THE MACHINE 83
LIFTING THE MACHINE WITH A CRANE 84
MOVING A DISABLED MACHINE 85

WHEELS/TIRES **87**
WHEELS AND TIRES 87

LUBRICATION/MAINTENANCE CHARTS **91**
GENERAL SAFETY BEFORE YOU SERVICE 91
SUPPORT STRUT FOR LOADER LIFT ARMS 92
ENGINE HOURMETER 93
MAINTENANCE SCHEDULE 93
FLUIDS AND LUBRICANTS 94

LUBRICATION/FILTERS/FLUIDS **97**
REAR ACCESS DOOR 97
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 98
GREASE FITTINGS - 10 HOURS 99, 100, 101, 102
GREASE FITTINGS - 250 HOURS 103, 104
GREASE FITTINGS - 500 HOURS 104
ENGINE LUBRICATION 105
AIR FILTER SYSTEM 110
ENGINE COOLING SYSTEM 116
DIESEL FUEL SYSTEM 119
HYDRAULIC SYSTEM 124
DRIVE CHAIN COMPARTMENT 128

TRIM THIS EDGE

MidWestTech | Case 1845C Uni-Loader Operator's Manual | Publication 9-25063 Order the manual at mid-west-tech.com >

MAINTENANCE/ADJUSTMENTS **129**
MOVING THE OPERATORS COMPARTMENT FORWARD 129
MOVING THE OPERATORS COMPARTMENT INTO THE OPERATING POSITION 132
TESTING THE SEAT BAR 135
DRIVE CHAINS 136
STEERING LEVER ADJUSTMENT 141
SPARK ARRESTER MUFFLER 142
ROLL-OVER PROTECTIVE STRUCTURE 143
CASE MECHANICAL COUPLER 150
MAINTENANCE OF THE SEAT BELT 151
MACHINE CLEANING 151
PLASTIC AND RESIN PARTS 151
FAN BELT REPLACEMENT 151
THERMOSTART SYSTEM 152, 153

ELECTRICAL SYSTEM **155**
BATTERY SERVICE 155
WORK LAMPS 157
FUSES AND RELAYS 159

STORAGE **161**
MACHINE STORAGE 161
REMOVAL FROM STORAGE 162

SPECIFICATIONS **163**
ENGINE 163
COOLING SYSTEM 163
HYDRAULIC SYSTEM 163
OPERATING WEIGHTS 164
POWER TRAIN 164
MANURE FORK 164
BACKHOE BUCKETS 165
PALLET FORK WITH BRICK GUARD 165
OPERATING DATA AND DIMENSIONS 166
D100 BACKHOE 168
D100XR BACKHOE 169
D125 BACKHOE 170

DETAIL INDEX **171**

AFTER DELIVERY CHECK **177, 179**

TRIM THIS EDGE

MidWestTech | Case 1845C Uni-Loader Operator's Manual | Publication 9-25063 Order the manual at mid-west-tech.com >