# 1150G CRAWLER

## Operator's Manual

Bur 9-25682

CASE
CONSTRUCTION

MidWestTech | Case 1150G Crawler Operator's Manual | Publication 9-25682

Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


TO THE OWNER ..... 1
- AFTER DELIVERY CHECK ..... 2
- RIGHT, LEFT, FRONT, AND REAR SIDES OF THE MACHINE ..... 2
- IDENTIFICATION NUMBER ..... 3

SAFETY/DECALS/HAND SIGNALS ..... 7
- SAFETY RULES ..... 7
- BEFORE OPERATION ..... 8
- MACHINE OPERATION ..... 9
- PARKING THE MACHINE ..... 10
- FIRE EXTINGUISHER ..... 10
- BURN PREVENTION ..... 11
- CAST DUCTILE IRON ..... 11
- FIRE OR EXPLOSION PREVENTION ..... 12
- MAINTENANCE ..... 13, 14
- HAND SIGNALS ..... 17

INSTRUMENTS AND CONTROLS ..... 21
- FOOT THROTTLE, STEERING AND BRAKE PEDAL ..... 24
- DECELERATOR ..... 25
- TRANSMISSION CONTROLS, ENGINE HAND THROTTLE AND HORN BUTTON ..... 26
- BACK-UP ALARM ..... 28
- FUEL GAUGE ..... 28
- TRANSMISSION RANGE SWITCH ..... 29
- MASTER DISCONNECT SWITCH ..... 29
- DOZER BLADE CONTROL LEVER ..... 30
- RIPPER CONTROL LEVER ..... 32
- CAB CONTROLS ..... 33
- OPERATORS SEAT ..... 36
- OPERATORS SEAT BELT ..... 37

OPERATING INSTRUCTIONS ..... 39
- RUN-IN PERIOD OF A NEW MACHINE ..... 39
- ENGINE OPERATION ..... 40
- CRAWLER OPERATION ..... 43
- TOWING A DISABLED CRAWLER ..... 48
- TRANSPORTING THE MACHINE ..... 51
- OPERATING IN HOT WEATHER ..... 52
- OPERATING IN COLD WEATHER ..... 53
- DOZER OPERATION ..... 58
- RIPPER OPERATION ..... 63
- TRACK SYSTEMS ..... 64


TRIM THIS EDGE



MidWestTech | Case 1150G Crawler Operator's Manual | Publication 9-25682 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS


LUBRICATION/MAINTENANCE CHARTS ..... 77
- GENERAL SAFETY BEFORE YOU SERVICE ..... 77
- SYSTEMGARD LUBRICATION ANALYSIS PROGRAM ..... 78
- FLUIDS AND LUBRICANTS ..... 79
- ENGINE HOURMETER ..... 80
- LUBRICATION CHART ..... 81

LUBRICATION/FILTERS/FLUIDS ..... 83
- ACCESS DOORS ..... 83
- GREASE FITTINGS ..... 84
- POWER ANGLE-TILT DOZER GREASE FITTINGS ..... 85
- ENGINE LUBRICATION (PRIOR TO P.I.N. JJG0218023 AND P.I.N. JJG0218024 THROUGH JJG0218474) ..... 88
- ENGINE LUBRICATION (P.I.N. JJG0218023 AND P.I.N. JJG0218475 and AFTER) ..... 89
- ENGINE COOLING SYSTEM ..... 92
- AIR FILTER SYSTEM ..... 100
- AIR CLEANER (PRIOR TO P.I.N. JJG0218023 AND P.I.N. JJG0218024 THROUGH JJG0218474) ..... 101
- AIR CLEANER (P.I.N. JJG0218023 AND P.I.N. JJG0218475 AND AFTER) ..... 103
- HYDRAULIC SYSTEM ..... 107
- TRANSMISSION ..... 110
- FINAL DRIVES ..... 114
- CAB AIR FILTER ..... 115

MAINTENANCE/ADJUSTMENTS ..... 117
- ETHER STARTING FLUID CAN ..... 117
- REVERSIBLE FAN POSITIONS (If Equipped) ..... 118
- AIR CONDITIONER DRIVE BELT ..... 119
- SEAT BELT SERVICE ..... 119
- TRANSMISSION CONTROL LEVER ADJUSTMENT ..... 120
- BRAKE WEAR CHECK ..... 121
- ROLL-OVER PROTECTIVE STRUCTURE ..... 122
- MACHINE CLEANING ..... 125

ELECTRICAL SYSTEM ..... 127
- BATTERY SERVICE ..... 127
- WORK LAMPS ..... 128
- ALTERNATOR WARNING LAMP ..... 129
- INSTRUMENT PANEL LAMP ..... 129
- TRANSMISSION FILTER WARNING LAMP ..... 130
- FUSES ..... 130


TRIM THIS EDGE



MidWestTech | Case 1150G Crawler Operator's Manual | Publication 9-25682 Order the manual at mid-west-tech.com >

STORAGE ..... 131
MACHINE STORAGE ..... 131

SPECIFICATIONS ..... 133
TRAVEL SPEEDS ..... 133
RIPPER ..... 133
ENGINE (PRIOR TO P.I.N. JJG0218023 AND P.I.N. JJG0218024 THROUGH JJG0218474) ..... 134
ENGINE (P.I.N. JJG0218023 AND P.I.N. JJG0218475 AFTER) ..... 134
POWER ANGLE-TILT DOZER (LONG TRACK) ..... 135
WEIGHTS ..... 139

AFTER DELIVERY CHECK ..... 141, 143

ALPHABETICAL INDEX ..... 145

TRIM THIS EDGE



MidWestTech | Case 1150G Crawler Operator's Manual | Publication 9-25682 Order the manual at mid-west-tech.com >