955 Cyclo Air Planter

Operators Manual

Set-Up Manual

Mounted Rigid, Semi-Mounted Vertical Fold and 6/11 and 8/15 Solid Row Crop Mounted

Rac 9-27121

CASE IH AGRICULTURE

MidWestTech | Case 955 Cyclo Air Planter Operator's Manual | Publication 9-27121

Order the manual at mid-west-tech.com >

GENERAL TABLE OF CONTENTS

TO THE OWNER 1

IDENTIFICATION NUMBERS/MACHINE COMPONENTS 3
- IDENTIFICATION NUMBERS 3
- MACHINE COMPONENTS 4

SAFETY/DECALS 8
- SAFETY 8
- SAFETY DECALS 12

OPERATING INSTRUCTIONS 14
- TRANSPORTING ON PUBLIC ROADS 14
- TRACTOR/PLANTER CONNECTIONS 15
- THREE-POINT HITCH 17
- THREE-POINT HITCH SPREADER BAR (SEMI-MOUNTED ONLY) 17
- HYDRAULIC AND ELECTRICAL CONNECTIONS ... 19

FIELD OPERATION 22
- PLANTER RAISING AND LOWERING SEQUENCE .. 22
- VERTICAL FOLD PLANTER WINGS 23
- MARKER OPERATION 25
- TOOLBAR HEIGHT ADJUSTMENT 29
- EARLY RISER ROW UNIT OPERATION 30
- SPEED TRANSMISSION 38
- CYCLO AIR PLANTING SYSTEM 41
- CHANGING SEED DRUM 44
- SEED DRUM OPERATION AND ADJUSTMENT 45
- SEED HOPPER 49
- AIR PRESSURE AND BRUSH SETTING 52
- SEED DISTRIBUTION AND PLANTING DISTANCE . 64
- GRANULAR CHEMICAL ATTACHMENT 67
- 15 INCH TO 30 INCH ROW SPACING CONVERSION 76
- SEED DRUM BELTS 78
- SEED RELEASE WHEEL TIRE CHART 80
- PREPARATION FOR STARTING TO PLANT CHECK LIST 81
- PLANTING FACTORS AFFECTING SEED POPULATION AND YIELDS 81

PRESEASON ADJUSTMENT/MAINTENANCE 82
- PLANTER PRESEASON PREPARATION 82
- PRESEASON CHECKLIST 83
- SEED DRUM 93
- SEED MANIFOLD 96
- ASSIST WHEEL ADJUSTMENT 98
- SEED CUTOFF BRUSH 98
- SEED DRUM INSTALLATION 99
- CHECKING THE SEED DRUM SEAL 100
- REPLACING THE DRUM SEAL 100
- SEED DRUM ROUNDNESS 102
- SEED DRUM BELTS 103
- CHECKING THE SEED DRUM ALIGNMENT 104
- ADJUSTING THE SEED DRUM ALIGNMENT 105
- SEED RELEASE WHEEL ADJUSTMENT 106
- SEED DELIVERY TUBES AND AIR DIFFUSER 107
- SEED TUBE REPLACEMENT 112
- AIR DIFFUSER REMOVAL AND INSTALLATION ... 113
- HYDRAULIC PUMP - OIL CHANGE AND FILTER REPLACEMENT 115
- RESERVOIR AND FILTER SYSTEM FOR DUAL MODULE PLANTER 116
- HYDRAULIC OIL COOLER 117
- DRIVE CHAIN ADJUSTMENTS 118
- TURN SIGNAL/WARNING AND TAIL LAMP REPLACEMENT 119
- GRANULAR CHEMICAL HOPPER 120
- WING COUPLER 121

LUBRICATION 122
- ENVIRONMENT 122
- DRIVE WHEEL BEARINGS 122
- LUBRICATION POINTS 125

MACHINE STORAGE 126

TROUBLESHOOTING 129

SPECIFICATIONS 134

SET-UP INSTRUCTIONS 141
- ATTACHMENTS 141
- MAIN MACHINE 141
- IDENTIFICATION OF MACHINE COMPONENTS ... 142
- REQUIRED BUILDING AND EQUIPMENT 142
- SAFETY 143
- SPECIAL TORQUES 144
- SPECIAL TOOLS 144
- STANDARD TORQUE DATA 146
- HYDRAULICS 148
- ROW UNIT AND WHEEL SPACING 153
- MAIN MACHINE SETUP 158

SEED CHART 167
- SEED PLANTING TABLE (ALL ROW WIDTHS) 167

DETAIL INDEX 204

MidWestTech | Case 955 Cyclo Air Planter Operator's Manual | Publication 9-27121 Order the manual at mid-west-tech.com >