3950 Flex Wing Disk Harrow

Operators Manual

Rac 9-28373

CASE IH AGRICULTURE

MidWestTech | Case 3950 Flex Wing Disk Harrow Operator's Manual | Publication 9-28373

Order the manual at mid-west-tech.com >

GENERAL TABLE OF CONTENTS

TO THE OWNER 1

IDENTIFICATION NUMBERS 2
- PRODUCT IDENTIFICATION NUMBER 2

SAFETY/DECALS/REFLECTORS 3
- SAFETY 3
- DECALS 4
- REFLECTORS 5
- SAFETY LIGHTING 6
- SLOW MOVING VEHICLE (SMV) EMBLEM 7

OPERATING INSTRUCTIONS 8
- BEFORE OPERATING THE HARROW 8
- HYDRAULIC LIFT SYSTEM 8
- HITCH HEIGHT ADJUSTMENT 9
- TRACTOR/HARROW CONNECTION 11
- TRANSPORT POSITION 14
- CENTER TOOTH ASSEMBLY 16
- JACK STAND 17
- REAR JACK STAND ATTACHMENT 17
- WARNING LAMPS 18
- COIL TINE SOIL MULCHER 19
- WING GAUGE WHEEL 19
- HYDRAULIC LEVELING HITCH 20
- TRAILING HITCH 20

FIELD OPERATION 21
- GENERAL INFORMATION 21
- HITCH CRANK ADJUSTMENT 22
- DEPTH CONTROL ADJUSTMENT 23
- WING TRANSPORT WHEEL ADJUSTMENT 24
- WING GAUGE WHEEL ADJUSTMENT 24
- DISC SCRAPER ADJUSTMENT 25
- SCRAPER SUPPORT SHIM 26
- FIELD PERFORMANCE 27

LUBRICATION/FILTERS/FLUIDS 29
- LUBRICATION CHART 29
- GREASE FITTINGS 30
- WHEEL BEARINGS 33

MAINTENANCE/ADJUSTMENTS 34
- HITCH CRANK SERVICE 34
- DISC BLADES 36
- TIRE PRESSURE 37
- WHEEL BOLTS 37
- ARBOR BOLTS 38
- FRAME BOLTS 38
- WING STOP BRACKET 38
- DISC GANGS 39

STORAGE 56
- PREPARING THE HARROW FOR STORAGE 56
- REMOVING THE HARROW FROM STORAGE 56

SPECIFICATIONS 57
- MACHINE SPECIFICATIONS 57

SET-UP INSTRUCTIONS 60
- GENERAL INFORMATION 60
- REQUIRED BUILDING AND EQUIPMENT 63
- SET UP PREPARATION 63
- MAIN GANG ASSEMBLIES 66
- CENTER TOOTH ASSEMBLY 68
- WING FRAME ASSEMBLY 70
- SAFETY LIGHTING KIT 74
- HYDRAULIC INSTALLATION 75
- WING GAUGE WHEEL 83
- REAR JACK STAND 84
- BEARING WEAR GUARDS 85
- COIL TINE SOIL MULCHER ATTACHMENTS 86
- BEFORE OPERATING HARROW 87

DETAIL INDEX 89

MidWestTech | Case 3950 Flex Wing Disk Harrow Operator's Manual | Publication 9-28373 Order the manual at mid-west-tech.com >