1450
Dozer

Operators Manual

9-4484

REPRINTED

CASE
CONSTRUCTION

MidWestTech | Case 1450 Dozer Operator's Manual | Publication 9-4484

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Introduction 2
Right and Left Sides of Machine 3
To the Owner 3
Delivery of New Machine 3
After Delivery Checkup 3
Safety 4
Specifications 24
Crawler Operating Instructions 32
Instruments and Controls 32
Engine Operation 36
Run-In 36
Starting 37
Idling 38
Stopping 38
Starting Aids 38
Driving the Crawler 41
Seat Adjustment 41
Gear Selection 42
Steering 43
Inching the Crawler 45
Stopping the Crawler 45
Hillside Operation 46
Transporting the Crawler 46
Cold Weather Operation 46
Hot Weather Operation 47
Dozer Operating Instructions 48
Mechanical Angle Dozer 48
Lift Control Lever 48
Tilting the Blade 48
Angling the Blade 49
Power Tilt Dozer 50
Adjustable Strut 51
Dozer Operating Tips 52
Clearing 52
Basements 54
Trenching 55
Transporting Dirt 56
Sidehill Cuts 57
Winch Operating Instructions 59
Winch Controls 59
Winching 60
Cable 61
Winch Operating Tips 65
Multiple Pulls 66
Stuck Machines 68
Logging 69
Ripper Operating Instructions 70
Control 70
Ripper Teeth 70
Tooth Tip Replacement 71
Ripper Operating Tips 71
Fuels and Lubricants 72
Diesel Fuel 72
Lubricants 73
Fuel, Fluids and Lubricants Chart . . 74
Maintenance 75
Introduction 75
Run-In Period 75
Scheduled Maintenance 75
Run-In Maintenance Chart 76
Scheduled Maintenance Chart 76
Grease Fittings 79
Engine Lubrication System 82
Oil Level 82
Oil Change 82
Oil Filter 83
Air Cleaning System 85
Intake Screen 85
Rain Cap 86
Restriction Indicator 86
Air Cleaner Servicing 87
Cooling System 90
Radiator Cap 90
Coolant 91
Cleaning the System 91
Thermostat 93
Fuel System 94
Components 94
Cleaning the Fuel System 95
Replacing Fuel Filters 97
Bleeding the Fuel System 97
Electrical System 98
Instrument Panel Light 98
Head, Side and Taillight 99
Starter Motor 99
Master Disconnect Switch 99
Do's and Do Not's for an Alternator Charging System . . . 99
Battery Care and Maintenance . . 100
Specific Gravity Check 103
Booster Batteries 104
Equipment Hydraulic System 105
Oil Level 105
Return Line Filter 106
Suction Line Screen 107
Hydraulic Reservoir Breather . . 107
Oil Change 107
Transmission/Torque Converter Hydraulic System 108
Oil Level 108
Pressure Line Filter 108
Transmission Suction Screen . . . 109
Transmission Breathers 110
Oil Change 110
Recoil Housing 111
Final Drives 111
Oil Level 111
Oil Change 112
Track System 112
Track Tension 112
Track Shoe Bolts 114
Brake System 114
Parking Brake/Manual Brake Adjustment 114
Fan Belts 116
Checking Tension 116
Fan Belt Adjustment 117
Winch Maintenance 117
Servicing the Cable 117
Common Causes of Cable Failure . . . 117
Winch Hydraulic System 118
Oil Level 118
Oil Drain and Refill 119
Pressure Line Filter 119
Suction Line Screen 119
Seat Belt Inspection and Care 120
Machine Storage 121
Reactivating Machine 123
Angle-Tilt-Pitch Dozer 124
Specifications 124
Controls 125
Grease Fittings 127
After Delivery Checkup 129

MidWestTech | Case 1450 Dozer Operator's Manual | Publication 9-4484 Order the manual at mid-west-tech.com >