580F Loader Backhoe

Service Manual

9-66415

CASE

MidWestTech | Case 580F Loader Backhoe Service Manual | Publication 9-66415

Order the manual at mid-west-tech.com >




Figure 1 - Oil Flow, Right Turn, Engine Running




Figure 2 - Oil Flow, Left Turn, Engine Running

Order the manual at mid-west-tech.com >




Figure 5 - Axial Backhoe Hydraulic Diagram

Order the manual at mid-west-tech.com >




Figure 18 - Oil Flow, Dipper Cylinder Extending, Boom Section Relief Valve Open, Side Shift Backhoe

Order the manual at mid-west-tech.com >