1450B/1455B CRAWLERS

OPERATOR MANUAL

9-6901

CASE CONSTRUCTION

MidWestTech | Case 1450B, 1455B Crawler Operator's Manual | Publication 9-6901

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Introduction 2
Safety 4
Roll-Over Protective Structure 22
Location of Product Identification Number (PIN) and Serial Numbers ... 27
Specifications 30
Operating Instructions 40
Fast Reference for Instruments and Controls 40
Instrument Panel 44
Controls 46
Cab Controls 50
Seats 52
Operator's Seat Belt 54
Run-In Period 55
Engine Operation 56
Service and Checks Before Starting Engine 56
Starting the Engine 57
Stopping the Engine 58
Starting Aids 59
Crawler Operation 64
Adjusting the Seat 64
Starting 64
Transmission Controls 65
Steering 66
Stopping the Crawler 69
When Operating on a Hill 70
Procedure to Move a Disabled Machine 70
Procedure to Transport the Machine ... 71
Operating in Cold Temperatures ... 73
Operating in Hot Temperatures 73
Loader Operation 74
Safety When You Work 74
Loader Control Levers 75
Raising and Lowering the Bucket ... 75
Rolling Back or Dumping the Bucket 75
Filling the Bucket 76
Return-To-Dig 77
Bucket Level Indicator 77
Bucket Height Control 77
4-In-1 Bucket 78
Positioning the Bucket and Clam ... 79
Dozer Operation 82
Safety When You Work 82
Engine Speed and Transmission Range Control 83
Control Levers 83
Ripper Operating Instructions 89
Dual Pull-Behind Hydraulics Operations . 90
Winch Operating Instructions 91
Operating in Cold Temperatures 95
Fuels and Lubricants 96
Diesel Fuel Specifications 96
Fuel, Fluids and Lubricants Chart 97
Maintenance and Lubrication 98
Introduction 98
Run-In Maintenance Chart 99
Maintenance Chart for Regular Intervals . 99
Safety Before Servicing 102
Grease Fittings 105
Engine Lubrication System 113
Oil Level 113
Oil Change 113
Engine Oil Filters 114
Air Cleaner System 116
Restriction Indicator 116
Cap for the Air Cleaner 116
Precleaner 117
Air Cleaner (With Dust Cup) 117
Strata Air Cleaner (If Equipped) ... 119
Engine Cooling System 124
Coolant Level 124
Ethylene Glycol Coolant 124
Procedure to Clean the Cooling System 125
Fuel System 127
Fuel Tank 127
Checking and Servicing the Fuel System 128
Replacing Fuel Filters 130
Removing Air From the Fuel System . 132
Electrical System 133
Fluid Level of the Batteries 135
Lamps 137
Hydraulic System 139
Oil Level 139
Hydraulic Oil Filter 139
Hydraulic Oil Screen 139
Hydraulic Reservoir Breather 140
Oil Change 141
Transmission Hydraulic System 142
Oil Level 142
Transmission Oil Filter 142
Transmission Oil Screen 143
Transmission Breather 143
Transmission Oil Change 145
Final Drives 146
Oil Level 146
Oil Change 148
Track System 149
Parking Brake and Manual Brake ... 152
Drive Belts 153
Loader Service 155
Winch Service 158
Seat Belt and Suspension Seat 161
Procedure to Put the Machine in Storage 161
Procedure to Remove the Machine from Storage 163
After Delivery check of a New Machine 165

MidWestTech | Case 1450B, 1455B Crawler Operator's Manual | Publication 9-6901 Order the manual at mid-west-tech.com >