880C
Excavator

Service Manual

9-69762

CASE CONSTRUCTION

MidWestTech | Case 880C Excavator Service Manual | Publication 9-69762

Order the manual at mid-west-tech.com >









MidWestTech | Case 880C Excavator Service Manual | Publication 9-69762 Order the manual at mid-west-tech.com >

880C EXCAVATOR
TABLE OF CONTENTS

SERIES/SECTION		SECTION NO.	FORM NO.
10	SERIES - GENERAL		
	General Engine Specifications	1010	8-22970
	General Maintenance	1050	9-69760
	Torque Charts	1051	9-66015
	General Cleaning Instructions	1055	9-66735
	Safety Rules	1056	9-68141
	Specification Details - 504BD Engine	1420	8-20050
20	SERIES - ENGINE		
	Engine Tune-Up	2002	9-76379
	Cylinder Head, Valve Train and Camshaft	2015	8-22560
	Cylinder Block, Sleeves, Piston and Rods	2025	9-76176
	Crankshaft, Main Bearings, Flywheel and Oil Seals	2035	9-76187
	Lubrication System	2046	8-22780
	Air Cleaner	2051	9-69760
	Pump Drive Plate	2053	9-68141
	Cooling System	2055	9-76337
	Engine Troubleshooting	2201	8-20110
	Reconditioning Engine Cylinder Block	2290	8-21170
30	SERIES - FUEL SYSTEM		
	Fuel System and Filters	3010	9-75297
	Fuel Injection Pump	3012	9-74937
	Fuel Tank, Fuel Lines and Fuel Storage	3052	9-68141
	Fuel Injectors	3213	8-20240
40	SERIES - ELECTRICAL		
	Maintenance Service	4001	9-68141
	Diagnostic Tests and Checks	4002	9-69761
	Wiring Harness	4003	9-69761
	Starter and Starter Solenoid	4006	9-67890
	Alternator	4007	9-68141
50	SERIES - TRACK AND SUSPENSION		
	Maintenance Service	5501	9-68141
	Troubleshooting	5502	9-68141
	Track Chain and Shoes	5503	9-68141
	Track Rollers, Carrier Rollers, Idlers and Sprockets	5506	9-68141
60	SERIES - POWER TRAIN		
	Maintenance Service	6301	9-68141
	Troubleshooting	6302	9-68141
	Drive Motor Circuit and Lines	6311	9-68141
	Drive Motor	6312	9-68141
	Final Drive Transmission (Drive)	6317	9-68142

CASE CORPORATION

9-69761-R1


Printed in U.S.A.
Issued November 1980
Revised August 1981
Revised September 1983

MidWestTech | Case 880C Excavator Service Manual | Publication 9-69762

Order the manual at mid-west-tech.com >


CYLINDER HEAD ASSEMBLY AND INSTALLATION

STEP 65




Apply lubrication to the valves using clean engine oil and install the valves in the cylinder head.

STEP 66



Install the valve spring seat (flat side down).


STEP 67



Install the valve spring. Either end of the valve spring can be installed in the valve spring seat because both ends of the spring are closed and ground.

NOTE: *See specification details section in this Service Manual for spring specifications.*

STEP 68



Install the valve rotators (flat side up). Install the valve rotators with the original valves because these parts are worn as counterparts of each other.

IMPORTANT: *Always install new rotators and valve keepers when new valves are installed.*

MidWestTech | Case 880C Excavator Service Manual | Publication 9-69762

Order the manual at mid-west-tech.com >