210, 310
Wheel Tractor

Service Manual

9-70011A

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

SECTION I

310 AND 310C CRAWLER TRACTORS

TABLE OF CONTENTS

PAGE

GROUP A — GENERAL INFORMATION I-1
1. SPECIFICATIONS I-1
2. LUBRICATION I-2
3. TORQUE SPECIFICATIONS I-10

GROUP B — ENGINE I-11
1. SPECIFICATIONS I-11
2. SERVICE INFORMATION I-12

GROUP C — FUEL AND ELECTRICAL SYSTEMS I-13
1. ELECTRICAL SYSTEM I-13
2. FUEL SYSTEM I-16

GROUP D — CLUTCH I-16
1. REMOVING ENGINE AND ASSOCIATED PARTS I-16
2. REMOVING CLUTCH HOUSING I-18
3. SERVICING CLUTCH PRESSURE PLATE I-18
4. DISASSEMBLING CLUTCH HOUSING I-18
5. INSTALLING CLUTCH I-21

GROUP E — DRIVESHAFT I-22
1. REMOVING DRIVESHAFT I-22
2. REPLACING UNIVERSAL JOINT BEARINGS I-22
3. INSTALLING DRIVESHAFT I-23

GROUP F — TRANSMISSION, DIFFERENTIAL, FINAL DRIVE, AND P.T.O. BELT PULLEY I-24
1. LUBRICATION I-24
2. DIFFERENTIAL I-24
3. TRANSMISSION I-34
4. FINAL DRIVE I-39
5. P.T.O. AND BELT PULLEY (OPTIONAL) I-43

GROUP G — TRACK AND SUSPENSION I-48
1. REMOVING TRACK I-48
2. DISASSEMBLING TRACK SUSPENSION I-49
3. FRONT IDLER I-50
4. TRACK ROLLERS I-52
5. TRACK SUPPORT IDLER (OPTIONAL) I-54
6. ASSEMBLING TRACK SUSPENSION I-57
7. TRACK CHAIN I-57
8. INSTALLING TRACK I-57

OWATONNA TOOLS ARE SHOWN IN THE ILLUSTRATIONS IN THIS MANUAL, THEY ARE IDENTIFIED BY OTC PART NUMBER.

OTC TOOLS ARE AVAILABLE FROM OWATONNA TOOL COMPANY, OWATONNA, MINNESOTA, U.S.A.

MidWestTech | Case 210, 310 WheelTractor Service Manual | Publication 9-70011A Order the manual at mid-west-tech.com >