1700
Uni-Loader

Service Manual

9-72096

CASE CONSTRUCTION

MidWestTech | Case 1700 Uni Loader Service Manual | Publication 9-72096

Order the manual at mid-west-tech.com >

1700 UNI-LOADER

TABLE OF CONTENTS

SERIES/SECTION		FROM NO.	SECTION NO.
10	**SERIES - GENERAL**		
	General Engine Specifications	9-74216	11
	Detailed Specifications	9-80732	1020
	Maintenance and Lubrication	9-72095	13
20	**SERIES - ENGINE**		
	Engine Removal and Installation	9-72095	21
	Air Cleaner	9-72095	24
	Cylinder Head and Valves, Diesel	9-80512	2013
	Cylinder Head and Valves, Spark Ignition	9-80473	2014
	Engine Block Assemblies - Gasoline Engines	9-76995	2023
	Engine Block Assemblies - Diesel Engine	9-77005	2024
30	**SERIES - FUEL SYSTEM**		
	Carburetor	9-80581	35
	Fuel System & Filters - Diesel Engines	9-78785	3010
	Roosa Master Model DB Fuel Injection Pumps	9-78795	3012
	Roosa Master Fuel Injectors	9-78806	3013
	Fuel Filter - Gasoline Engines	9-79065	3110
40	**SERIES - HYDRAULICS**		
	Hydraulic System	9-72095	41
	Lift and Tilt Cylinders	9-74225	45
	Auxiliary Cylinders	9-74235	47
60	**SERIES - POWER TRAIN**		
	Power Train	9-72095	61
70	**SERIES - BRAKES**		
	Brakes (Foot and Parking)	9-72095	72
80	**SERIES - ELECTRICAL**		
	Electrical System	9-72095	82
	Ignition System	9-72095	83
	Capacitor Discharge Ignition System	9-74596	83
90	**SERIES - MOUNTED EQUIPMENT**		
	Loader	9-72095	92
	ROPS	9-72095	99

SAFETY PRECAUTIONS

1. **Never place any part of your body between the chassis and the loader frame and/or lift and tilt cylinders if service being performed prohibits the use of a safety stop.**
2. **Whenever the bucket must be raised to aid in servicing, block the bucket in position with lift cylinder stops or a suitable safety stand.**
3. **Operate controls from the operator's seat only.**
4. **When working in the area of the jackshaft or drive belt with the engine running, avoid wearing loose clothing if possible and use extreme caution.**
5. **When working at the rear with the engine running, use care not to be caught in the fan blades or drive belts.**
6. **Keep hands and fingers clear of drive chains if running with drive compartment cover removed.**

Reprinted

MidWestTech | Case 1700 Uni Loader Service Manual | Publication 9-72096 Order the manual at mid-west-tech.com >