750
Crawler

Service Manual

9-72152

CASE CONSTRUCTION

MidWestTech | Case 750 Crawler Service Manual | Publication 9-72152

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION PAGE

BASIC TRACTOR AND COMPONENTS

1. GENERAL DESCRIPTION 1

2. SPECIFICATIONS
- General Dimensions and Weights 4
- Engine 6
- Torque Converter 7
- Capacities 7
- Tractor Steering 8
- Tractor Speeds 8
- Illustrated Dimensions 9
- Fuel Specifications 11
- Fuel Storage 11
- Lubrication 13
- Serial Numbers 20

3. INSTRUMENTS 23

4. COOLING SYSTEM
- General Description 25
- General Maintenance 26
- Thermostat 26
- Draining and Filling 27
- Cleaning 27
- Radiator and Shroud 28
- Water Pump 31
- Fan and Fan Belts 33

5. ELECTRICAL SYSTEM
- General Description 34
- Circuits 35
- Batteries 36
- Starter 40
- Generator 45
- Voltage Regulator 49
- Lights 55

6. ENGINE AIR INTAKE SYSTEM
- Air Cleaner Cap 56
- Air Cleaner 56
- Air Pre-Cleaner 58

7. ENGINE, TRACK, AND EQUIPMENT CONTROLS
- Hand and Foot Throttle 59
- Control Levers and Linkage 62

8. TORSION BAR AND SUSPENSION SYSTEM
- General Description 64
- Disassembly 64
- Assembly 66

MidWestTech | Case 750 Crawler Service Manual | Publication 9-72152 Order the manual at mid-west-tech.com >

9. TRACK SYSTEM
Chains 68
Track Rollers 72
Support Rollers 74
Front Idler 77
Track Adjuster 78
Recoil Assembly 81
Frame 82

10. TORQUE CONVERTER
General Description 83
Removal 86
Disassembly 86
Assembly 91
Installation 92
Charging Pump 93

11. TRANSMISSION AND FINAL DRIVE
Specifications 99
Special Tools 99
Transmission 100
Forward-Reverse Shaft Assembly 102
High-Low Shaft Assembly 104
Pinion Shaft Assembly 106
Final Drive 108
Pinion Sleeve and Carrier 110
Control Valve 112
Installing Transmission Subassemblies 114
Setting the Pinion Shaft 116
Brakes 118
Master Cylinder 121

12. MISCELLANEOUS TRACTOR COMPONENTS
Rear Counterweight 122
Front Counterweight 122
Seat and Tank Assembly 123
Drawbar 124
Frame - Cowl - Hood 125
Mud Pans 126

13. HYDRAULIC SYSTEM
Description 127
Filters 128
Primary Circuit 129
Loader Circuit 131
Dozer Circuits 132
Ripper Circuit 134
Backhoe Circuit 135
Pump 137
Control Valves 143
Diverter Valve 160
Relief Valve Pressure Settings 161
Checking and Adjusting Relief Valves 161
Checking and Adjusting Secondary Relief Valves 163
Cylinders 168
Trouble Shooting Chart 175

MidWestTech | Case 750 Crawler Service Manual | Publication 9-72152 Order the manual at mid-west-tech.com >

14. ALLIED EQUIPMENT
Loader 181
Tilt-Crown Dozer 185
Angle Dozer 187
Ripper 189
Backhoe 190

15. GENERAL SERVICE INFORMATION
Bearings 197
Bushings 198
Oil Seals 198
Gears 198
Shafts and Splines 198
Shifting Forks 199
Gaskets - Wiring - Hoses 199
Batteries - Filters - Radiator 200

MODEL A-267D DIESEL ENGINE

C. ENGINE SPECIFICATIONS C-1

I. SERVICING FUEL INJECTORS, CASE POWRCEL, FUEL INJECTION PUMP
Fuel Injectors I-5
Case Powrcel I-26
Fuel Injection I-33

K. CYLINDER HEADS, VALVE SYSTEMS, ROCKER ARMS, DECOMPRESSOR .. K2-K15

M. ENGINE BLOCK
Lubricating System M-4
Pistons, Rods, Sleeves M-16
Crankshaft, Main Bearings, Flywheel M-30
Camshaft, Lifters M-38
Fuel Injection Pump Drive M-42

MidWestTech | Case 750 Crawler Service Manual | Publication 9-72152 Order the manual at mid-west-tech.com >




Figure 20 - Swing Cylinder Movement




Figure 21 - Oil "Cushion" Formed, Relief Valve Bypassing

MidWestTech | Case 750 Crawler Service Manual | Publication 9-72152 Order the manual at mid-west-tech.com >




Figure 4MM-34. Oil Flow With Plugged Filter Element




Figure 4MM-35. Oil Flow With Plugged Oil Cooler and Oil Filter Element

MidWestTech | Case 750 Crawler Service Manual | Publication 9-72152 Order the manual at mid-west-tech.com >