680CK C
Loader Backhoe

Service Manual

9-72595

MidWestTech | Case 680CK C Loader Backhoe Service Manual | Publication 9-72595

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SERIES/SECTION		SECTION NO.
10	SERIES - GENERAL	
	General Engine Specifications	11
	Maintenance and Lubrication	1050
	Torque Chart	1051
20	SERIES - ENGINES	
	Cylinder Head and Valves	22
	Engine Block Assembly	23
	Water Pump, Thermostats, Oil Cooler, and Filters	25
	Engine Removal and Stall Checks	2050
	Air Cleaner	2051
30	SERIES - FUEL SYSTEM	
	Fuel System and Filters	3010
	Fuel Injection Pumps	3012
	Roosa-Master Fuel Injectors	3013
	Electric Fuel Pump	3051
	Fuel Lines and Throttle Adjustment	3052
40	SERIES - HYDRAULICS	
	Hydraulic Diagrams, Trouble Shooting, Pressure Checks	4011
	Hydraulic Pump	4013
	Loader Control Valve	4021
	Case Backhoe Control Valve	4022
	Commercial-Shearing Backhoe Control Valve	4023
	Extendahoe Control Valve	4029
	Stabilizer Lock Valve	4030
	Hydra-Guide	4040
	Boom Lockout Valve and Relief Valve	4041
	Loader and Backhoe Cylinders	4057
50	SERIES - STEERING	
	Hydraulic Diagram, Trouble Shooting, Pressure Check	5011
	Steering Pump	5012
	Steering Valve and Column	5013
	Steering Cylinders	5015
	Front Axle	5017
60	SERIES - POWER TRAIN	
	Transmission/Converter Hydraulic Diagram, Operation and Description	6011
	Trouble Shooting and Testing	6012
	Forward-Reverse Transmission (Power Shuttle)	6014
	Four Speed Mechanical Transmission	6018
	Rear Axle	6020
	Drive Shaft	6022

NOTE: Also see Sections 9011 and 9012 for exploded views of hydraulic system.

CASE CORPORATION

Burl. Form 9-72595 Nov. 1980

PRINTED IN U.S.A.

Reprinted

MidWestTech | Case 680CK C Loader Backhoe Service Manual | Publication 9-72595 Order the manual at mid-west-tech.com >

SERIES/SECTION SECTION NO.

70 SERIES - BRAKES
Air System Diagrams, Operation, Pressurizing/Depressurizing the Air System, and Trouble Shooting 7011
Foot Brakes and Slack Adjuster 7013
Air Compressor, Governor, Reservoir, Moisture Ejection Valve 7014
Brake Valve 7015
Brake Actuator 7016
Parking Brake Control Valve and Quick Release Valve 7017
Pressure Reducing Valve, Pressure Protection Valve Double Check Valve, Clutch Cutout Valve, Stoplight Switch 7018
Alcohol Evaporator 7020

80 SERIES - ELECTRICAL
Wiring Diagrams 8011
Trouble Shooting and Adjustments 8012
Batteries 8014
Starter and Starter Solenoid 8015
Alternator 8016

90 SERIES - MOUNTED EQUIPMENT
Loader 9011
Backhoe 9012
ROPS Cab and Canopy 9019
Front Floor Plate Assembly 9028

MidWestTech | Case 680CK C Loader Backhoe Service Manual | Publication 9-72595 Order the manual at mid-west-tech.com >




Figure 2 - Air System With Foot Operated Clutch Cutout

731634

MidWestTech | Case 680CK C Loader Backhoe Service Manual | Publication 9-72595

Order the manual at mid-west-tech.com >