A TEREX BRAND

Parts Manual

	Serial Number Range
GS-1530	from GS3005A-76000 to GS3010A-109999
GS-1532	from GS3005B-76000 to GS3009B-98941
GS-1930	from GS3008C-101 to GS3011C-9999
GS-1932	from GS3205-75407 to GS3211A-109999
GS-2032	from GS3208C-101 to GS3212C-9999
GS-2632	from GS4605-75438 to GS4611A-109999
GS-3232	from GS4609C-101 to GS4612C-9999
GS-2046	
GS-2646	
GS-3246	

Part No. 97384
Rev J4
December 2018

MidWestTech | Terex Genie GS-1530, GS-1532, GS-1930, GS-1932, GS-2032, GS-2632, GS-3232, GS-2046, GS-2646, GS-3246 Scissor Lift Parts Manual | Publication 97384
Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

100 Decals

101.1 Decals with Words, GS-1530/1532/1930/1932 (North America and Australia) (from SN GS3005A-76000 to GS3007A-91731) and (from GS3005B-76000 to GS3007B-88079)....10
102.1 Decals with Symbols, GS-1530/1930 (Asia and South America) (from SN GS3005A-76000 to GS3007A-91731) and (from GS3005B-76000 to GS3007B-88079)....14
103.1 Decals with Words, GS-1530/1930 (North America) (from SN GS3007A-91732 to GS3010A-109999) and (from GS3007B-88080 to GS3009B-98941)....16
104.1 Decals with Symbols, GS-1530/1930 (Asia and South America) (from SN GS3007A-91732 to GS3010A-10999 and GS3007B-88080 to GS3009B-98941)....20
105.1 Decals with Words, GS-1530/1532/1930/1932 (Australia) (from SN GS3007A-91732 to GS3011A-102095) and (from GS3007B-88080 to GS3009B-98941)....22
106.1 Decals with Words, GS-1530/1532/1930/1932 (Australia) (from SN GS3011A-102096 to GS3010A-109999)....26
107.1 Decals with Symbols, GS-1530/1532/1930/1932 (Europe) CE Models (from SN GS3005A-76000 to GS3007A-91731) and (from GS3005B-76000 to GS3007B-88079)....30
108.1 Decals with Symbols, GS-1530/1532/1930/1932 (Europe) (from SN GS3007A-91732 to GS3010A-109999; from GS3007B-88080; and from GS3008C-101 to GS3011C-9999)....32
109.1 Decals with Words, GS-2032/2632 (North America and Australia) (from SN GS3205-75407 to GS3207-87723)....34
110.1 Decals with Symbols, GS-2032/2632 (Asia and South America) (from SN GS3205-75407 to GS3207-87723)....38
111.1 Decals with Words, 2032/2632 (North America) (from SN 07-87724 to 09-94602; and from 09A-94603 to 11A-109999) GS3232 (from SN 84867 to 11A-109999)....40
112.1 Decals with Symbols, GS-2032/2632/3232 (Asia and South America) (from SN GS3207-87724 to GS3211A-109999)....44
113.1 Decals with Words, GS-2032/2632/3232 (Australia) (from SN GS3207-87724 to GS3209-94602; and from GS3209A-94603 to GS3211A-96461)....46
114.1 Decals with Words, GS-2032/2632/3232 (Australia) (from SN GS3211A-96462 to GS3211A-109999)....50
115.1 Decals with Symbols, GS-2032/2632 (Europe) (from SN GS3205-75407 to GS3207-87723)....54
116.1 Decals with Symbols, GS-2032/2632/3232 (Europe) (from SN GS3207-87724 to GS3209-94602; from GS3209A-94603; and from GS3208C-101 TO GS3212C-9999)....56
117.1 Decals with Words, GS-2046/2646/3246 (North America and Australia) (from SN GS4605-75438 to GS4607-87508)....58
118.1 Decals with Symbols, GS-2046/2646/3246 (Asia and South America) (from SN GS4605-75438 to GS4607A-87508)....62
119.1 Decals with Words, GS-2046/2646/3246 (North America) (from SN GS4607-87509 to GS4611A-109999)....64
120.1 Decals with Symbols, GS-2046/2646/3246 (Asia and South America) (from SN GS4607-87509 to GS4611A-109999)....68
121.1 Decals with Words, GS-2046/2646/3246 (Australia) (from SN GS4607-87509 to GS4611A-96921)....70
122.1 Decals with Words, GS-2046/2646/3246 (Australia) (from SN GS4611A-96922 to GS4611A-109999)....72
123.1 Decals with Symbols, GS-2046/2646/3246 (Europe) (from SN GS4605-75438 to GS4607-87508)....74
124.1 Decals with Symbols, GS-2046/2646/3246 (Europe) (from SN GS4607-87509 to GS4611A-109999; and from GS4609C-101 to GS4612C-9999)....76

200 Drive Chassis Components

201.1 Steer Linkage and Wheels (GS-1530, GS-1532, GS-1930, GS-1932)....78
202.1 Steer Linkage and Wheels, GS-2032, GS-2632, GS-3232, GS-2046, GS-2646, GS-3246....80
203.1 Non-steer Axle Installation, All Models....82
204.1 Ground Controls and Level Sensor Installation, All Models....86
205.1 Pothole Protection Assembly, GS-1530, GS-1532, GS-1930, GS-1932....88
206.1 Pothole Protection Assembly, GS-2032, GS-2632, GS-3232, GS-2046, GS-2646, GS-3246....90
207.1 Battery Pack Module (to SN GS3007A-90292, GS3007B-85535, GS3207-85959, GS4607-85667)....92

MidWestTech | Terex Genie GS-1530, GS-1532, GS-1930, GS-1932, GS-2032, GS-2632, G... Order the manual at mid-west-tech.com >

207.2 Battery Pack Module (from SN GS3007A-90293 to GS3011A-110827, from GS3007B-85536, from GS3008C-101 to GS3012C-10009, from GS3207-85960 to GS3211A-97903 , from GS3208C-101 to GS3212C-1386, from GS4607-85668 to GS4611A-97982, and from GS4609C-101 to G.....94

207.3 Battery Pack Module (from SN GS3011A-110828, from GS3012C-10010, from SN GS3211A-97904 , from GS3212C-1387, from GS4611A-97983, and from GS4612C-1386).....96

208.1 Battery Charger.....98

209.1 Power Unit Module, All Models (to SN GS3007A-90292, GS3007B-85535, GS3207-85959, and GS4607-85667).....100

209.2 Power Unit Module (from SN GS3007A-90293, GS-3007B-85536, GS-3008C-101, GS3207-85960, GS3208C-101, GS4607-85668, and GS4609C-101).....102

210.1 Ground Controls, All Models.....104

211.1 Electrical Wiring and Power Cables (models without contactor).....106

211.2 Electrical Wiring and Power Cables (models with contactor).....110

212.1 Outrigger Components, GS-3232.....114

213.1 Outrigger Control Box, GS-3232.....116

214.1 Function Manifold and Accumulator Components, GS-1530, GS-1532, GS-1930, GS-1932.....118

214.2 Function Manifold and Accumulator Components, GS-2032, GS-2632, GS-2046, GS-2646, GS-3246.....120

214.3 Function Manifold and Accumulator Components, GS-3232.....122

300 Scissor Components

301.1 Scissor Assembly Installation.....124

302.1 Scissor Assembly, GS-1530, GS-1532 (to serial numbers GS3006A-84657 AND GS3006B-80108).....126

302.2 Scissor Assembly, GS-1530, GS-1532 (from SNs GS3006A-84658, GS3006B-80109, and GS3008C-101)...128

303.1 Scissor Assembly, GS-1930, GS-1932, (to serial numbers GS3006A-84657 and GS3006B-80108).....130

303.2 Scissor Assembly, GS-1930, GS-1932 (from SNs GS3006A-84658, GS3006B-80109 and GS3008C-101).....132

304.1 Scissor Assembly, GS-2032, GS-2046.....134

305.1 Scissor Assembly, GS-2632, GS-2646.....136

306.1 Scissor Assembly, GS-3232, GS-3246.....140

400 Platform Components

401.1 Platform Components, GS-1530, GS-1532, GS-1930, GS-1932.....144

402.1 Platform Components, GS-2032, GS-2632, GS-3232.....150

403.1 Platform Components, GS-2046, GS-2646, GS-3246.....154

404.1 Platform Gates, GS-1530, GS-1532, GS-1930, GS-1932.....158

405.1 Power to Platform.....160

406.1 Platform Control Box.....162

407.1 Joystick Controller.....164

500 Hydraulic Components

501.1 Hydraulic Components.....166

502.1 Function Manifold, GS-1530, GS-1532, GS-1930, GS-1932.....168

502.2 Check Valve Manifold, GS-1530, GS-1532, GS-1930, GS-1932.....170

503.1 Function Manifold, GS-2032, GS-2632, GS-2046, GS2646, GS-3232, GS-3246.....172

504.1 Brake Release Hand Pump Manifold.....174

505.1 Hydraulic Power Unit, All Models.....176

506.1 Lift Cylinder Assembly, All Models.....178

507.1 Hydraulic Hoses and Fittings, GS-1530, GS-1532, GS-1930, GS-1932.....180

508.1 Hydraulic Hoses and Fittings, GS-2032, GS-2632, GS-3232, GS-2046, GS-2646, GS-3246.....182

509.1 Outrigger Cylinders, Front and Rear, GS-3232.....186

510.1 Outrigger Function Manifold, GS-3232.....188

511.1 Hydraulic Hoses and Fittings, Outriggers, GS-3232.190

600 Accessories

601.1 Alarm, Horn and Flashing Beacons.....192

602.1 Air Line to Platform.....194

603.1 Platform Work Light.....196

604.1 Voltage Inverter, GS-1530, GS-1532, GS-1930.....198

605.1 Voltage Inverter, GS-2032, GS-2632, GS-2046, GS-2646, GS-3232, GS-3246.....200

606.1 Pipe Cradle Assembly, GS-2046, GS-2646, GS-3246.....202

700 Platform Overload Components

701.1 Platform Overload, GS-1530, GS-1532, GS-1930, GS-1932.....204

702.1 Platform Overload, GS-2032, GS-2632, GS-3232, GS-2046, GS-2646, GS-3246.....206

Indices

Part Number Index.....208

Part Description Index.....214

Cross References

Fittings Cross Reference.....224

MidWestTech | Terex Genie GS-1530, GS-1532, GS-1930, GS-1932, GS-2032, GS-2632, G... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
--	105214GT	CABLE TIE MOUNT, WINGED *not shown*	
--	56926GT	CLIP,TIE HARNESS MOUNT*** *not shown*	
--	96522GT	STD CONTROL HARNESS, SLAB *(ANSI, CSA and Australia models) (includes wire harnesses 96489, 96387, 96344 and 105321)*	
--	96440GT	CE CONTROL HARNESS, SLAB *(CE models) (includes wire harnesses 96489, 96819, 96520, 105320 and 47124)*	
--	96344GT	HARNESS ASSY, MAIN *ANSI, CSA and Australia Models*	
--	96520GT	ASSY,MAIN HARNESS,CE *CE Models*	
--	96308GT	ASSY,LEVEL SENS HARNESS *ANSI, CSA and Australia Models*	
--	96521GT	ASSY,LEVEL SENS HARNESS,CE *CE Models*	
--	96489GT	WIRE ASSY,ECU TO CHASSIS,GS30	
--	105328GT	KIT,FEMALE PLUG, DTM *repair kit*	
--	233439GT	ASSY,MOTOR CONTROL HARNESS *ANSI, CSA and Australia Models*	
--	233438GT	ASSY,MOTOR CONTROL HARNESS,CE *CE Models*	
--	96309GT	ASSY,POTHOLE HARNESS,GS *GS-30*	
--	96853GT	ASSY,POTHOLE HARNESS GS32/GS46 *GS-32, GS-46*	
--	105301GT	ASSY,UP LIMIT SW HARNESS,MINI *to SNs GS3005A-80887 and GS3005B-78124*	
--	105386GT	ASSY,UP LIMIT SW HARNESS,MINI *GS-30*	
--	105322GT	ASSY,UP-LIMIT SW HARNESS *GS-2032, GS-2632, GS-46*	
--	105576GT	ASSY,UP-LIMIT SW HARNESS *GS-2032, GS-2632, GS-3232, GS-2046, GS-2646, GS-3246; CE Models (from SNs GS3206-84825, GS3208C-101, GS4606-84403, and GS4609C-101)*	
--	47662GT	HARNESS,ALARM ACCESSORY *option*	
--	105992GT	HORN HARNESS *option*	
--	51075GT	HARNESS,BEACON OPTION,SLAB *GS-XX30*	
--	96459GT	HARNESS ASSEMBLY, INVERTER *GS-1932, GS-2032, GS-2046, GS-2646, GS-3246*	
--	105125GT	CABLE ASSY, INVERTER *option*	

Item	Part No.	Description	Qty.
--	96502GT	ASSY,PRESS SW HARNESS *CE Models*	
--	96820GT	ASSY,RELAY HARNESS *ANSI, CSA and Australia Models (to SNs GS3005A-79061, GS3005B-77035, GS3205-77044 and GS4605-76544)*	
--	105321GT	ASSY,RELAY HARNESS *ANSI, CSA and Australia Models (from SNs GS3005A-79062, GS3005B-77036, GS3008C-101, GS3205-77045, GS3208C-101, GS4605-76545, GS4609C-101)*	
--	78098GT	RELAY,24VDC,40/30A,SLD W/BRKT* *ANSI and CSA Models*	
--	96429GT	ASSY, RELAY HARNESS, CE *CE Models (to SNs GS3005A-79061, GS3005B-77035, GS3205-77044 and GS4605-76544)*	
--	105320GT	ASSY,RELAY HARNESS,CE *CE Models (from SNs GS3005A-79062, GS3005B-77036, GS3008C-101, GS3205-77045, GS3208C-101, GS4605-76545, GS4609C-101)*	
--	78098GT	RELAY,24VDC,40/30A,SLD W/BRKT* *CE Models*	
--	105664GT	ASSY,22 FT LIMIT SWITCH,GS3232	
--	109916GT	WIRE ASSY,OR SYS *GS-3232*	
--	99089GT	CAPACITOR,4700MFD 25V *CE Models*	
--	40833GT	FUSE,275 AMP,VERY FAST ACTING	
--	47124GT	INDUCTOR,47 MH,2.5AMP,.034OHM *CE models only) (ECU Harness*	
--	87745GT	CONN,RECEP 12 WAY BLK,1 BUSS *12-pin ground buss, wire harness*	
--	T110890GT	HARNESS, GS POWER CONTRL *(Grey connector)*	
--	228786GT	HARNESS, GS SENSORS, ANSI *(Green connector)*	
--	T110891GT	HARNESS, GS SENSORS, CE *(Green connector)*	
--	233440GT	O/R SYSTEM HARNESS, CE	
--	233711GT	HRNS ASSY,RESISTOR DIODE	
--	233785GT	HARNESS, BEACON RESISTOR KIT,	
--	233782GT	HRNS ASSY,RESISTOR,200 OHM	
--	T110890GT	HARNESS, GS POWER CONTRL *(Grey connector)*	
1A	96307GT	HRNS,LIFT CYL DOWN,MINI,CE.....1 *GS-30 (CE Models)*	
1B	96852GT	HRNS,LIFT CYL DOWN,20/26XX,CE *GS-32, GS-2046, GS-2646 (compatible with ANSI models, as well)*	

MidWestTech | Terex Genie GS-1530, GS-1532, GS-1930, GS-1932, GS-2032, GS-2632, G... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
1	105805GT	FORMING,COMPONENT BRKT,GS3232 *(from SN 92733) (shown)*	
1A	105643GT	FORMING,COMPONENT BRKT, GS3232 *(to SN 92732)*	
2		Ref. Outrigger Manifold *(refer to 511.1)*	
3	71484GT	SENSOR,LEVEL, ANALOG	
4	6889GT	NUT,LP NYLOCK,1/4-20	
5	80149GT	BOLT,CARRIAGE,1/4-20 X .5,G2	
6	6878GT	BOLT,CARRIAGE,1/4-20 X .75,G2	
7	6091GT	NUT,NYLOCK,1/4-20	
8	105211GT	FORMING, ACCUMULATOR CLAMP	
9	105210GT	FORMING, ACCUMULATOR BRACKET	
10	78422GT	ACCUMULATOR,180 PSI PRECHARGE*	
11		Ref. Function Manifold *(refer to 503.1)*	
12	105644GT	FORMING,MANIFOLD BRKT, GS3232	
13	5365GT	NUT,NYLOCK,10-24	
14	71874GT	BOLT,CARRIAGE,#10-24X.50,G2	
15	109954GT	ECU,O/R CONTROLS,GS3232	

MidWestTech | Terex Genie GS-1530, GS-1532, GS-1930, GS-1932, GS-2032, GS-2632, G... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
--	97266GT	CE POINTER REPL KIT, GS32/46	
1	96904GT	SPACER,1/4ID X 1/2OD X .313	
2	96933GT	WEAR PAD, PLATFORM POINTER	
3	96872GT	FORMING, POINTER	1
4	96903GT	BOLT,CARRIAGE,1/4-20 X 3.50,G2	
5	6091GT	NUT,NYLOCK,1/4-20	
6	105356GT	KIT,PRESS SWTH RPLMNT,GS32/46* *(CE models)*	1
--		Ref. Hose Assembly *(refer to 507.1)*	
--	105241GT	HARNESS, PRESS. SWITCH	
7		Ref. Lift Cylinder *(refer to 506.1)*	
8	41557-SGT	CABLE BRACKET,PAINTED	1
9	7339GT	SCREW,HHC,1/4-20 X .5	
10	6146GT	WASHER,FLAT,MS,#10,Y	
11	6178GT	NUT,NYLOCK,10-32	
12	51063GT	SCREW,PHILLIPS,RHM,10-32 X 1.5	
13		Ref. Wire Harness Assembly *(refer to 211.1)*	
--	19491GT	CONTACTOR,LIMIT SWITCH	
--	96948GT	SWITCH,LIMIT,W/ROLLER ARM***	
--	97128GT	ROLLER ARM,LIMIT SWITCH***	
14	6878GT	BOLT,CARRIAGE,1/4-20 X .75,G2	
15	6889GT	NUT,LP NYLOCK,1/4-20	
17	105139GT	FORMING, BRKT,UP LIMIT SW *(from SN GS3205-62351 to GS3207-87113 and from GS4605-65067 to GS4607-86895)*	
17A	105715GT	FORMING,UP LMT SW BRKT,32/46 *(from SN GS3207-87114, GS3208C-101, GS4607-86896 and GS4609C-101)*	
17B	105736GT	FRMING,LMT SWCH BRKT,3232 *GS-3232 (from SN GS3207-87652)*	

MidWestTech | Terex Genie GS-1530, GS-1532, GS-1930, GS-1932, GS-2032, GS-2632, G... Order the manual at mid-west-tech.com >