A TEREX BRAND

Parts Manual

Serial Number Range

GTH-1048 from SN GTH1006A-8418 to GTH1007A-11442

GTH-1056 from SN GTH1006A-8418 to GTH1007A-11442

Part No. 97500

Rev B2

November 2018

MidWestTech | Terex Genie GTH-1048, GTH-1056 Articulated Boom Lift Parts Manual | Publication 97500

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

100 Decals

101.1 Decals, View 1....10
102.1 Decals, View 2....12

200 Drive Chassis Components

201.1 Power Train Assembly, JD-4045 Tier II....14
202.1 Drive Shaft Assembly, Front and Rear....16
203.1 Fuel Tank Assembly....18
204.1 Battery Box Assembly....20
205.1 General Assembly....22
206.1 Engine Enclosure Assembly....26
207.1 Stabilizer Assembly....28
211.1 Converter Housing Assembly....30
212.1 Transmission Case and Cover Assembly....32
213.1 Turbine Shaft Assembly....34
214.1 Transmission Front Cover....36
215.1 Torque Converter Assembly....38
216.1 Transmission Gear Assembly....40
217.1 Transmission Auxilliary Pump Drive Assembly....42
218.1 Transmission Pump Drive Assembly....44
219.1 Transmission Forward Shaft Assembly....46
220.1 Transmission Reverse and Second Shaft Assembly....48
221.1 Transmission Reverse Idler Shaft Assembly....50
222.1 Transmission Low Speed Shaft Assembly....52
223.1 Transmission Third Shaft Assembly....54
224.1 Transmission Output Shaft Assembly....56
225.1 Charging Pump and Filter Assembly....58
226.1 Valve Assembly Mounting....60
227.1 Electronic Control Valve Assembly (from GTH06A-8793)....62
228.1 Modulator Valve Assembly....64
229.1 Input Flange....66

201 Drive Axle Components

201.1 Stabilizer Assembly....68
202.1 Front Axle View....70
203.1 Front Axle, Central Housing....72
204.1 Front Axle, Differential....74
205.1 Front Axle, Hub Reduction....76
206.1 Front Axle, Brakes....78
207.1 Front Axle, Steering....80
208.1 Front Axle, Trunnion....82
209.1 Rear Axle View....84
210.1 Rear Axle, Central Housing....86
211.1 Rear Axle, Differential....88
212.1 Rear Axle, Hub Reduction....90
213.1 Rear Axle, Brakes....92
214.1 Rear Axle, Steering....94
215.1 Rear Axle, Trunion....96

300 Engine Components

301.1 Engine and Pump Assembly, JD-4045 Tier II (GTH-1048)....98
302.1 Engine and Pump Assembly, JD-4045 Tier II (GTH-1056)....100
303.1 Exhaust Assembly, JD-4045 Tier II....102
304.1 Air Cleaner Assembly, JD-4045 Tier II....104
305.1 Air Cleaner Assembly, JD-4045 Tier II....106
306.1 Starter Relay/Sender Assembly, JD-4045 Tier II....108

400 Cab Components

401.1 Operators Compartment Assembly, View 1....110
402.1 Operators Compartment Assembly, View 2....112
403.1 Foot Brake Assembly....114
404.1 Accelerator Assembly....116
405.1 Instrument Panel Assembly....118
406.1 4-Way Controller Assembly....120

500 Boom Components

501.1 Boom Assembly, View 1....122
502.1 Boom Assembly, View 1....124
503.1 Boom Assembly, View 2....126
504.1 Boom Assembly, View 2....128
505.1 Boom Assembly, View 3....130
506.1 Boom Assembly, View 3....132
507.1 Boom Assembly, View 4....134
508.1 Boom Assembly, View 4....136
509.1 Boom Assembly, View 5....138
510.1 Boom Assembly, View 5....140

MidWestTech | Terex Genie GTH-1048, GTH-1056 Articulated Boom Lift Parts Manual | Pu... Order the manual at mid-west-tech.com >

511.1 Boom Assembly, View 6.....142
512.1 Boom Assembly, View 7.....144
513.1 Boom Assembly, View 7.....146
514.1 Boom Assembly, View 8.....148
515.1 Boom Assembly, View 8.....150
516.1 Boom Assembly, View 9.....152
517.1 Boom Assembly, View 9.....154
518.1 Boom Assembly, View 10.....156
519.1 Boom Assembly, View 10.....158
520.1 Boom Assembly, View 11.....160
521.1 Boom Assembly, View 11.....162
522.1 Boom Assembly, View 12.....164

600 Hydraulic Hoses and Fittings

601.1 Circuit, Pump, Oil Reservoir, GTH-1048.....166
602.1 Circuit, Pump, Oil Reservoir, GTH-1056.....168
603.1 Circuit, Lift-tilt, GTH-1048.....170
604.1 Circuit, Lift-tilt, GTH-1056.....172
605.1 Circuit, Boom, GTH-1048.....174
606.1 Circuit, Boom, GTH-1056.....176
607.1 Circuit, 4-Way Controller, GTH-1048.....178
608.1 Circuit, 4-Way Controller, GTH-1056.....180
609.1 Circuit, Steering, GTH-1048.....182
610.1 Circuit, Steering, GTH-1056.....184
611.1 Circuit, Sway.....186
612.1 Circuit, Front Stabilizer.....188
613.1 Circuit, Rear Axle Lock-up, GTH-1048.....190
614.1 Circuit, Rear Axle Lock-up, GTH-1056.....192
615.1 Circuit, Parking Brake.....194
616.1 Circuit, Pressure Checks.....196
617.1 Circuit, Brake.....198
618.1 Circuit, Oil Cooler, GTH-1048.....200
619.1 Circuit, Oil Cooler, GTH-1056.....202
620.1 Circuit, Fuel.....204

700 Hydraulic Components

701.1 Lift Cylinder.....206
701.2 Lift Cylinder.....208
702.1 Tilt Cylinder.....210
703.1 Boom Cylinder.....212
703.2 Boom Cylinder.....214
704.1 Sway-Rear Lock Cylinder.....216
705.1 Stabilizer cylinder.....218
706.1 Motion Valve, Base of Tilt Cylinder.....220
707.1 Motion Valve, Head of Tilt Cylinder.....222
708.1 Motion Vavle, Head/Base of Boom Cyl. Head of Boom Cyl.....224
709.1 Motion Valve, Base of Lift Cylinder, Base of Boom Cylinder.....226
710.1 Dual Pilot check Valve.....228
711.1 Orbitral Assembly.....230
712.1 Selector Valve, Steering.....232
713.1 Return Filter Assembly.....234
714.1 Control Block Assembly.....236
715.1 Main Valve Assembly.....238
716.1 Hydraulic Pump Assembly, View 1.....240
717.1 Hydraulic Pump Assembly, View 2.....242
718.1 Electric Valve, 4-Way.....244
719.1 Electric Valve, 4-Way.....246
720.1 Valve, Boom Activated Rear-Lock.....248
721.1 Valve, Differential Lock.....250

800 Accessories

801.1 Fully Enclosed Cab Assembly, View 1.....252
802.1 Fully Enclosed Cab Assembly, View 2.....254
803.1 Fork Frame Rotate Assembly.....256
804.1 Rotate Cylinder Assembly.....258
805.1 Dual Pilot Check Valve.....260
806.1 Circuit, Fork Rotate.....262
807.1 Circuit, Fork Rotate.....264
808.1 Hose Roller Assembly.....266

Indices


Part Number Index.....268
Part Description Index.....274

Cross References

Fittings Cross Reference.....282


MidWestTech | Terex Genie GTH-1048, GTH-1056 Articulated Boom Lift Parts Manual | Pu... Order the manual at mid-west-tech.com >

717.1 Hydraulic Pump Assembly, View 2




MidWestTech | Terex Genie GTH-1048, GTH-1056 Articulated Boom Lift Parts Manual | Pu... Order the manual at mid-west-tech.com >

802.1 Fully Enclosed Cab Assembly, View 2



MidWestTech | Terex Genie GTH-1048, GTH-1056 Articulated Boom Lift Parts Manual | Pu... Order the manual at mid-west-tech.com >



MidWestTech | Terex Genie GTH-1048, GTH-1056 Articulated Boom Lift Parts Manual | Pu... Order the manual at mid-west-tech.com >