1690 Tractor

Operators Manual

9-7523

Reprinted

CASE IH AGRICULTURE

MidWestTech | Case 1690 Tractor Operator's Manual | Publication 9-7523

Order the manual at mid-west-tech.com >

Electrical System

Type of System	12 Volt, Negative Ground
Battery	One 12 Volt, 128 Amp/hr
Alternator	Low Profile 28 Amp, High Platform 65 Amp
Voltage Regulator	Inside Component of the Alternator
Starter Motor	Engaged by solenoid
Head Lights	12v 40/60W Sealed Beam
Side Lights	12V 5W
Side Direction Turn Signals	12V 21W
Rear and Stop Light	12V 5/21W
Rear Direction Turn Signals	12V 21W
Instrument Warning Lights	No. 168
Instrument Illumination Lights	No. 194
Fuses (4)	two 35A, one 25A, one 15A

Power Steering

Type	Hydrostatic, Metering Actuated by Steering Wheel
Pump	Rotor, Engine Driven
Steering Cylinder	Equal Displacement
Oil Capacity	1½ U.S. quart (1·4 litre)

Power Take Off

Type	Reversible Shaft Dual Speed 540 r/min 6 Spline 1000 r/min 21 Spline
Shaft Diameter	1⅜in (35mm)
Rotation	Clockwise when seen from the Rear

Hitch System

Type of Sensing	Top Link
Control	Hand Lever
Draft Arms	Swinging with Fixed or Float Position on Lift Arms, Adjustable Lift Link and Levelling Adjustment
Type of Hitch	Three Point, Category II
Lifting Capacity	5500lb (2495kg) at 24in (610mm) Load Centres

MidWestTech | Case 1690 Tractor Operator's Manual | Publication 9-7523 Order the manual at mid-west-tech.com >