WSM

WORKSHOP MANUAL

TRACTOR

B1550・B1550HST
B1750・B1750HST
B2150・B2150HST

Kubota

MidWestTech | Kubota B1550, B1550HST, B1750, B1750HST, B2150, B2150HST Tractor Service Manual | Publication 97897-10226

Order the manual at mid-west-tech.com >

M MECHANISM

CONTENTS

F FEATURES ——— M.F-1

1 ENGINE ——— M.1-1

[1] ENGINE BODY M.1-2
(1) Cylinder Block M.1-2
(2) Cylinder Head M.1-2
(3) Crankshaft M.1-3
(4) Piston and Piston Ring M.1-4
(5) Connecting Rod M.1-5
(6) Camshaft and Fuel Camshaft M.1-5
(7) Rocker Arm Assembly M.1-6
(8) Inlet and Exhaust Valves M.1-6
(9) Valve Timing M.1-6
(10) Flywheel M.1-7
(11) Air Cleaner M.1-7
[2] LUBRICATING SYSTEM M.1-8
(1) Relief Valve M.1-10
(2) Oil Filter Cartridge M.1-10
(3) Oil Switch M.1-11
(4) Oil Pump M.1-11
[3] COOLING SYSTEM M.1-12
(1) Water Pump M.1-13
(3) Thermostat M.1-13
(4) Radiator M.1-14
(5) Radiator Cap M.1-14
[4] FUEL SYSTEM M.1-15
(1) Fuel Filter M.1-16
(2) Fuel Lift Pump M.1-17
(3) Fuel Injection Pump M.1-18
(4) Fuel Injection Nozzle M.1-21
(5) Governor M.1-21

2 CLUTCH ——— M.2-1

[1] DRY TYPE, SINGLE PLATE CLUTCH M.2-1
[2] DRY TYPE, DUAL STAGE CLUTCH M.2-3

3 TRANSMISSION ——— M.3-1

[1] TRAVELING SYSTEM M.3-3
(1) Main Gear Shift Section M.3-3
(2) Hydrostatic Transmission
B1550HST-B1750HST M.3-4
B2150HST M.3-18
(3) Auxiliary Gear Shift Section M.3-32
(4) Front Wheel Drive Section M.3-33
[2] PTO SYSTEM M.3-33
(1) Rear PTO Shift Section M.3-33
(2) Mid PTO Section M.3-35
(3) Front PTO Section M.3-36
(4) One-way Clutch Cam Section M.3-36

4 REAR AXLE ——— M.4-1

[1] DIFFERENTIAL FUNCTIONING M.4-2
[2] DIFFERENTIAL LOCK M.4-3

5 BRAKE ——— M.5-1

6 FRONT AXLE ——— M.6-1

[1] FRONT WHEEL ALIGNMENT M.6-1
[2] STRUCTURE M.6-2
(1) Two Wheel Drive Type M.6-2
(2) Four Wheel Drive Type M.6-3
B1550-B1550HST M.6-3
B1750-B2150-B1750HST-
B2150HST M.6-4
Bi-speed Turn M.6-5

7 STEERING ——— M.7-1

[1] MANUAL STEERING M.7-1
[2] POWER STEERING M.7-2

8 HYDRAULIC SYSTEM ——— M.8-1

[1] HYDRAULIC PUMP M.8-5
[2] CONTROL VALVE M.8-6
[2]-1 OIL FLOW M.8-7
[2]-2 FEEDBACK LINKAGE FOR
POSITION CONTROL M.8-11
[3] HYDRAULIC BLOCK TYPE OUTLET M.8-12
B1550-B1750-B1550HST
B1750HST M.8-12
B2150-B2150HST M.8-15
[4] OIL COOLER M.8-18

9 ELECTRICAL SYSTEM ——— M.9-1

[1] WIRING DIAGRAM AND ELECTRICAL
CIRCUIT M.9-1
[2] STARTING SYSTEM M.9-5
(1) Starter Motor M.9-6

MidWestTech | Kubota B1550, B1550HST, B1750, B1750HST, B2150, B2150HST Tractor Service Ma... Order the manual at mid-west-tech.com >