WSM

WORKSHOP MANUAL
KUBOTA EXCAVATOR

MANUEL D'ENTRETIEN
EXCAVATEUR KUBOTA

WERKSTAT TANLEITUNG
BAGGER KUBOTA

KH-36・51・66・101
41・61・91・151

Kubota

MidWestTech | Kubota KH-36, KH-41, KH-51, KH-61, KH-66, KH-91, KH-101, KH-151 Bagger Service Manual | Publication 97899-60062

Order the manual at mid-west-tech.com >

CONTENTS

[1] SAFETY PRECAUTIONS FOR SERVICING, DISASSEMBLY AND REASSEMBLY ..... I -01
[2] PERIODIC INSPECTION AND SERVICING TABLE ..... I -06
[3] LUBRICATION ..... I -12
[4] TIGHTNESS TORQUE & ADHESIVE ..... I -16
[5] MAJOR DIMENSIONS AND OPERATION SPACE ..... I -20
[6] MACHINE SPECIFICATIONS ..... I -22

TABLE DES MATIERES

[1] MESURES DE SECURITE PENDANT L'ENTRETIEN, LE DEMONTAGE ET LE REMONTAGE I -01
[2] VERIFICATION PERIODIQUE ET TABLEAU DE NORMES D'ENTRETIEN ..... I -06
[3] GRAISSAGE ..... I -12
[4] COUPLE DE SERRAGE ET ADHESIFTS ..... I -16
[5] DIMENSIONS PRINCIPALES ET ESPACE D'UTILISATION ..... I -20
[6] CARACTERISTIQUES DE L'ENGIN ..... I -22

INHALTS

[1] SICHERHEITSVORKEHRUNGEN FÜR WARTUNG, DEMONTAGE UND MONTAGE ..... I -01
[2] TABELLE FÜR PERIODISCHER INSPECTION UND WARTUNG ..... I -06
[3] SCHMIERUNG ..... I -12
[4] ANZUGSMOMENT UND KLEBEMITTEL ..... I -16
[5] HAUPTMASS UND ARBEITSBEREICH ..... I -20
[6] TECHNISCHE DATEN DER MASCHINE ..... I -22

MidWestTech | Kubota KH-36, KH-41, KH-51, KH-61, KH-66, KH-91, KH-101, KH-151 Bagg... Order the manual at mid-west-tech.com >