Service Manual

Hammermaster Rockbreakers

PUBLISHED BY THE
JCB ATTACHMENTS
WATERLOO PARK
BEAMHURST
UTTOXETER ENGLAND
ST14 5PA
PRINTED IN ENGLAND

Publication No. 9803/1300

General Information & Safety	1	Servicing - 570/ 670/770 Range	12
Routine Maintenance	2	Servicing - 70	13
Servicing - 260 Range	3	Servicing - 550	14
Servicing - 360 Range	4	*Servicing - 1050/ 1150	15
Servicing - 460-110	5	*Servicing - 1350/ 1450	16
Servicing - 560	6	Servicing - 1750	17
Servicing - 660	7	*Servicing - 2350/ 2950/ 3850/ 3950	18
Servicing - 760	8	Servicing - 850	19
Servicing - 860	9	*Servicing - 100/ 115	20
Servicing - 960	10	Servicing - 60/ 110	21
Servicing - 160 Range	11	Servicing - 65	22

Issue 13

MidWestTech | JCB Hammermaster 360, 460-110, 560, 660, 760, 860, 960, 160, 260, 570, 6... Order the manual at mid-west-tech.com >

Contents

	Page No.
Hammermaster Identification	1 - 1
Torque Settings	
Hammermaster 360 Range	2 - 1
Hammermaster 460-110	2 - 3
Hammermaster 560	2 - 4
Hammermaster 660	2 - 5
Hammermaster 760	2 - 6
Hammermaster 860	2 - 7
Hammermaster 960	2 - 8
Hammermaster 160 Range	2 - 9
Hammermaster 260 Range	2 - 10
Hammermaster 570	2 - 11
Hammermaster 670	2 - 12
Hammermaster 770	2 - 13
Hammermaster 1050, 1150	2 - 14
Hammermaster 1350, 1450	2 - 15
Hammermaster 1750	2 - 16
Hammermaster 2350/2950/3850/3950	2 - 17
Hammermaster 550	2 - 18
Hammermaster 850	2 - 19
Service Tools	3 - 1
Nord-Lock Washers	3 - 1
Accumulator Charging	3 - 2
Safety Notices	4 - 1
General Safety	5 - 1
Operating Safety	6 - 1
Maintenance Safety	7 - 1
Safety Decals	8 - 1
Lubricants - Health and Safety	9 - 1

Note: Hammermaster 70 - All Service Information relating to this hammer is contained in Section 13. Safety requirements are retained in this section.

* **Note:** Hammermaster 100 and Hammermaster 115 - All Service Information relating to these hammers is contained in Section 20. Safety requirements are retained in this section.

MidWestTech | JCB Hammermaster 360, 460-110, 560, 660, 760, 860, 960, 160, 260, 5... Order the manual at mid-west-tech.com >

Contents **Page No.**

Lubricants
- Hammermaster 360 Range 1 - 1
- Hammermaster 460-110 1 - 3
- Hammermaster 560 1 - 4
- Hammermaster 660 1 - 5
- Hammermaster 760 1 - 6
- Hammermaster 860 1 - 7
- Hammermaster 960 1 - 8
- Hammermaster 160 Range 1 - 9
- Hammermaster 260 Range 1 - 10
- Hammermaster 570 1 - 11
- Hammermaster 670 1 - 12
- Hammermaster 770 1 - 13
- Hammermaster 550 1 - 14
- Hammermaster 1050, 1150 1 - 15
- Hammermaster 1350, 1450 1 - 16
- Hammermaster 1750 1 - 17
- Hammermaster 2350/2950/3850/3950 1 - 18
- Hammermaster 850 1 - 19

Service Schedules 2 - 1

Greasing 3 - 1

Side Plates (Hammermasters 160/160Q/160R/260/260L/260LQ/360/360Q/360-70/460-110)
- Checking Bolt Tightness 3 - 3

Hanger Bracket (Hammermasters 550, 560 to 960 and 570 to 770)
- Checking Bolt/Nut Tightness 3 - 5

Lower Tool Bushing and Tools
- Checking for Excessive Wear 3 - 6
- Checking For and Removing Burrs 3 - 6

Lower Tool Bushing
- Hammermasters 160/160Q/160R/260/260L/260LQ 360/360Q/360-70
  - Removal 3 - 7
  - Replacement 3 - 7
- Hammermaster 460 - 110
  - Removal 3 - 8
  - Replacement 3 - 8
- Hammermasters 560, 660, 760, 860, 960
  - Removal 3 - 8
  - Replacement 3 - 9
- Hammermaster 570, 670 and 770
  - Removal 3 - 10
  - Replacement 3 - 10

Hydraulic Pressure Testing 3 - 11

MidWestTech | JCB Hammermaster 360, 460-110, 560, 660, 760, 860, 960, 160, 260, 5... Order the manual at mid-west-tech.com >

Contents **Page No.**

Lower Tool Bushing
Hammermaster 550
Removal 3 - 14
Replacement 3 - 14
Checking for and Removing Burrs 3 - 14
* Hammermaster 850, 1050, 1150, 1350, 1450, 1750, 2350, 2950, 3850 and 3950
Removal 3 - 15
Replacement 3 - 15
Indexing the Lower Tool Bushing 3 - 15
Wear Limits and Lubricants 3 - 16
* Tool Wear Limits 850, 1050, 1150, 1350, 1450, 1750, 2350, 2950, 3850 and 3950 3 - 16

Wear Limits for Thrust Rings 3 - 17

Maximum Distance between Wear Plates
Large Hammers 3 - 18

Wear Limits for Buffers
Larger Hammers 3 - 18

Accumulator Shield Plugs
Larger Hammers 3 - 19

Note: Hammermaster 70 - All Service information relating to this hammer is contained in Section 13.

* **Note:** Hammermaster 100 and Hammermaster 115 - All Service information relating to these hammers is contained in Section 20.

MidWestTech | JCB Hammermaster 360, 460-110, 560, 660, 760, 860, 960, 160, 260, 5... Order the manual at mid-west-tech.com >