JCB

DRIVETRAIN SYSTEMS

Service Manual

JCB Drivetrain Systems Ltd
Wrexham Industrial Estate
WREXHAM
United Kingdom
LL13 9UF

Tel: (01978) 661140
Fax: (01978) 661863

General Information 1

Care & Safety 2

Routine Maintenance 3

Electrics 4

Transmission 5

Brakes 6

NOTE

All references in this manual to 'Forward' and 'Reverse' assume a front-mounted engine.

SS600 SERIES TRANSMISSION

Publication No. 9803/9020
Issue 8

MidWestTech | JCB SS600 Transmission Drivetrain Service Manual | Publication 9803-9020 Order the manual at mid-west-tech.com >

Service Tools Numerical List

		Page No.
* 4101/0251	Loctite 242	5 - 1
* 4101/0451	Loctite 932	5 - 1
* 4101/0651	Loctite 648	5 - 1
* 4101/0250	Loctite 243	5 - 1
* 4102/0552	Loctite 275	5 - 1
* 4102/1212	Loctite 574 or Permabond A136	5 - 1
* 4102/1951	Loctite 577	5 - 1
* 4104/0251	Activator (Aerosol)	5 - 1
* 4104/0253	Activator (Bottle)	5 - 1
* 4104/1557	Cleaner/Degreaser	5 - 1
* 814/00407	Valve Spring	4 - 2
* 814/00412	Valve Spring	4 - 2
* 814/00417	Valve Spring	4 - 2
* 816/80061	Valve Plug	4 - 2
* 816/80062	Valve Plug	4 - 2
* 816/80063	Valve Plug	4 - 2
* 826/01551	Stake Nut	4 - 6
* 892/00174	Measuring Cup - Pinion Head Bearing	4 - 3
* 892/00179	Bearing Press	4 - 1
* 892/00182	Bearing Pad Driver	4 - 3
* 892/00224	Impulse Extractor Set	4 - 2
* 892/00225	Adapter - Impulse Extractor	4 - 2
892/00295	End Float Setting Tool	4 - 1
892/00301	Flow Test Adapter	4 - 1
892/00302	Flow Test Adapter	4 - 1
892/00304	Flow Test Adapter	4 - 1
892/00333	Heavy Duty Socket	4 - 2
892/00812	Drive Coupling Spanner	4 - 1
892/00817	Heavy Duty Socket	4 - 2
892/00818	Heavy Duty Socket	4 - 2
892/00819	Heavy Duty Socket	4 - 2
892/00822	Splined Bolt Socket	4 - 3
892/00825	End Float Setting Tool	4 - 1
* 892/00916	Clutch Pack Spring Compressor	4 - 3
* 892/00918	Setting Tool Kit	4 - 6
* 892/00920	Flow Test Adapter	4 - 1
* 892/00922	Torque Converter Alignment Tool	4 - 1
* 904/05100	Seal	4 - 6
* 921/52600	Spacer Kit	4 - 6
* 921/52601	Spacer 12.75 mm	4 - 6
* 921/52602	Spacer 12.80 mm	4 - 6
* 921/52603	Spacer 12.85 mm	4 - 6
* 921/52604	Spacer 12.90 mm	4 - 6
* 921/52605	Spacer 12.95 mm	4 - 6
* 921/52606	Spacer 13.00 mm	4 - 6
* 921/52607	Spacer 13.05 mm	4 - 6
* 921/52608	Spacer 13.10 mm	4 - 6
* 921/52609	Spacer 13.15 mm	4 - 6
* 921/52610	Spacer 13.20 mm	4 - 6
* 921/52611	Spacer 13.25 mm	4 - 6
* 921/52612	Spacer 13.30 mm	4 - 6
* 921/52613	Spacer 13.35 mm	4 - 6
* 921/52614	Spacer 13.40 mm	4 - 6
* 921/52615	Spacer 13.45 mm	4 - 6
* 921/52616	Spacer 13.50 mm	4 - 6
* 921/52617	Spacer 13.55 mm	4 - 6
* 921/52618	Spacer 13.60 mm	4 - 6
* 921/52619	Spacer 13.65 mm	4 - 6
* 921/52620	Spacer 13.70 mm	4 - 6
* 921/52621	Spacer 13.75 mm	4 - 6
* 921/52622	Spacer 13.80 mm	4 - 6
* 921/52623	Spacer 13.85 mm	4 - 6
* 921/52624	Spacer 13.90 mm	4 - 6
* 921/52625	Spacer 13.95 mm	4 - 6
* 921/52626	Spacer 14.00 mm	4 - 6
990/00083	End Float Setting Tool	4 - 1
* 992/04000	Torque Multiplier	4 - 3
992/04800	Flange Spanner	4 - 3
* 992/07608	Bearing Adapter	4 - 1
* 992/07609	Bearing Adapter	4 - 1
* 992/07610	Bearing Adapter	4 - 1
* 992/07611	Bearing Adapter	4 - 1
* 992/07612	Bearing Adapter	4 - 1
* 992/07613	Bearing Adapter	4 - 1
993/59300	2/4WD Pressure Test Tool	4 - 2
993/59500	Impulse Extractor Adapter	4 - 2
* 993/70111	Breakback Torque Wrench	4 - 6

MidWestTech | JCB SS600 Transmission Drivetrain Service Manual | Publication 9803... Order the manual at mid-west-tech.com >