JCB

DRIVETRAIN SYSTEMS

Service Manual

JCB Drivetrain Systems Ltd
Wrexham Industrial Estate
WREXHAM
United Kingdom
LL13 9UF

Tel: (01978) 661140
Fax: (01978) 661863

General Information 1

Care & Safety 2

Routine Maintenance 3

Electrics 4

Transmission 5

NOTE

All references in this manual to 'Forward' and 'Reverse' assume a front-mounted engine.

SS700 SERIES TRANSMISSION

Publication No. 9803/9070
Issue 2

MidWestTech | JCB SS700 Transmission Drivetrain Service Manual | Publication 9803-9070 Order the manual at mid-west-tech.com >

Service Tools Numerical List

		Page No.
4101/0251	Loctite 242	5 - 1
4101/0451	Loctite 932	5 - 1
4101/0651	Loctite 648	5 - 1
4101/0250	Loctite 243	5 - 1
4102/0552	Loctite 275	5 - 1
4102/1212	Loctite 574 or Permabond A136	5 - 1
4102/1951	Loctite 577	5 - 1
4104/0251	Activator (Aerosol)	5 - 1
4104/0253	Activator (Bottle)	5 - 1
4104/1557	Cleaner/Degreaser	5 - 1
816/15118	Pressure Test Adapter	4 - 3
816/20008	Adapter	4 - 4
816/20013	Adapter	4 - 4
816/55038	Pressure Test 'T' Adapter	4 - 3
816/55040	Pressure Test 'T' Adapter	4 - 3
826/01551	Stake Nut	4 - 7
829/30405	Spacer 12.625 mm thick	4 - 7
829/30406	Spacer 12.675 mm thick	4 - 7
829/30407	Spacer 12.725 mm thick	4 - 7
829/30408	Spacer 12.775 mm thick	4 - 7
829/30409	Spacer 12.825 mm thick	4 - 7
829/30410	Spacer 12.875 mm thick	4 - 7
829/30411	Spacer 12.925 mm thick	4 - 7
829/30412	Spacer 12.975 mm thick	4 - 7
829/30413	Spacer 13.025 mm thick	4 - 7
829/30414	Spacer 13.075 mm thick	4 - 7
829/30415	Spacer 13.125 mm thick	4 - 7
829/30416	Spacer 13.175 mm thick	4 - 7
829/30417	Spacer 13.225 mm thick	4 - 7
892/00179	Bearing Press	4 - 1
892/00201	Replacement Gauge 0-20 bar	4 - 4
892/00202	Replacement Gauge 0-40 bar	4 - 4
892/00203	Replacement Gauge 0-400 bar	4 - 4
892/00224	Impulse Extractor Set	4 - 1
892/00225	Adapter - Impulse Extractor	4 - 1
892/00253	Pressure Test Kit	4 - 4
892/00254	Replacement Hose	4 - 4
892/00255	Pressure Test Adapter	4 - 3
892/00256	Pressure Test Adapter	4 - 3
892/00257	Pressure Test Adapter	4 - 3
892/00258	Pressure Test Adapter	4 - 3
892/00259	Pressure Test Adapter	4 - 3
892/00260	Pressure Test Adapter	4 - 3
892/00261	Pressure Test Adapter	4 - 3
892/00262	Pressure Test 'T' Adapter	4 - 3
892/00263	Pressure Test 'T' Adapter	4 - 3
892/00264	Pressure Test 'T' Adapter	4 - 3
892/00265	Pressure Test 'T' Adapter	4 - 3
892/00268	Flow Monitoring Unit	4 - 4
892/00269	Sensor Head	4 - 4
892/00270	Load Valve	4 - 4
892/00271	Adapter	4 - 4
892/00272	Adapter	4 - 4
892/00273	Sensor Head 0 - 380 l/m	4 - 4
892/00275	Adapter	4 - 4
892/00276	Adapter	4 - 4
892/00277	Adapter	4 - 4
892/00293	Connector Pipe	4 - 4
892/00294	Connector Pipe	4 - 4
892/00301	Flow Test Adapter	4 - 1
892/00302	Flow Test Adapter	4 - 1
892/00304	Flow Test Adapter	4 - 1
892/00333	Heavy Duty Socket	4 - 1
892/00706	Test Probe	4 - 4
892/00812	Drive Coupling Spanner	4 - 1
892/00817	Heavy Duty Socket	4 - 1
892/00818	Heavy Duty Socket	4 - 1
892/00819	Heavy Duty Socket	4 - 1
892/00822	Splined Bolt Socket	4 - 2
892/00916	2/4WD Clutch Spring Compressor	4 - 2
892/00918	Setting Tool Kit	4 - 7
892/00920	Flow Test Adapter	4 - 1
892/00922	Torque Converter Alignment Tool	4 - 2
892/00966	Test Point	4 - 3
892/01076	Support Plate	4 - 7
892/01077	Lock Screw - Selector Shaft	4 - 3
892/01078	Adjuster - Mainshaft	4 - 3
892/01079	Setting Ring Socket Spanner	4 - 3
892/01080	Setting Ring Socket Spanner	4 - 3
904/05100	Seal	4 - 7
921/52601	Spacer 12.750 mm thick	4 - 7
921/52602	Spacer 12.800 mm thick	4 - 7
921/52603	Spacer 12.850 mm thick	4 - 7
921/52604	Spacer 12.900 mm thick	4 - 7
921/52605	Spacer 12.950 mm thick	4 - 7
921/52606	Spacer 13.000 mm thick	4 - 7
921/52607	Spacer 13.050 mm thick	4 - 7
921/52608	Spacer 13.100 mm thick	4 - 7
921/52609	Spacer 13.150 mm thick	4 - 7
921/52610	Spacer 13.200 mm thick	4 - 7
921/52611	Spacer 13.250 mm thick	4 - 7
921/52626	Spacer 14.000 mm thick	4 - 7
921/52628	Spacer 12.600 mm thick	4 - 7
921/52629	Spacer 12.650 mm thick	4 - 7
921/52630	Spacer 12.700 mm thick	4 - 7
921/53400	Spacer Kit	4 - 7
921/53401	Spacer 13.400 mm thick	4 - 7
921/53402	Spacer 13.425 mm thick	4 - 7
921/53403	Spacer 13.450 mm thick	4 - 7
921/53404	Spacer 13.475 mm thick	4 - 7
921/53405	Spacer 13.500 mm thick	4 - 7
921/53406	Spacer 13.525 mm thick	4 - 7
921/53407	Spacer 13.550 mm thick	4 - 7
921/53408	Spacer 13.575 mm thick	4 - 7
921/53409	Spacer 13.600 mm thick	4 - 7
921/53410	Spacer 13.625 mm thick	4 - 7
921/53411	Spacer 13.650 mm thick	4 - 7
921/53412	Spacer 13.675 mm thick	4 - 7
921/53413	Spacer 13.700 mm thick	4 - 7
921/53414	Spacer 13.725 mm thick	4 - 7
921/53415	Spacer 13.750 mm thick	4 - 7
921/53416	Spacer 13.775 mm thick	4 - 7
921/53417	Spacer 13.800 mm thick	4 - 7
921/53418	Spacer 13.825 mm thick	4 - 7
921/53419	Spacer 13.850 mm thick	4 - 7
921/53420	Spacer 13.875 mm thick	4 - 7
921/53421	Spacer 13.900 mm thick	4 - 7
921/53422	Spacer 13.925 mm thick	4 - 7
921/53423	Spacer 13.950 mm thick	4 - 7
921/53424	Spacer 13.275 mm thick	4 - 7
921/53425	Spacer 13.300 mm thick	4 - 7
921/53426	Spacer 13.325 mm thick	4 - 7
921/53427	Spacer 13.350 mm thick	4 - 7
921/53428	Spacer 13.375 mm thick	4 - 7

MidWestTech | JCB SS700 Transmission Drivetrain Service Manual | Publication 9803... Order the manual at mid-west-tech.com >

Service Tools Numerical List

		Page No.
992/04000	Torque Multiplier	4 - 2
992/07608	Bearing Adapter	4 - 1
992/07609	Bearing Adapter	4 - 1
992/07610	Bearing Adapter	4 - 1
992/07611	Bearing Adapter	4 - 1
992/07612	Bearing Adapter	4 - 1
992/07613	Bearing Adapter	4 - 1
993/59300	2/4WD Clutch Pressure Test Tool	4 - 2
993/59500	Impulse Extractor Adapter	4 - 1
993/69800	Seal Kit	4 - 4
993/70111	Breakback Torque Wrench	4 - 7

MidWestTech | JCB SS700 Transmission Drivetrain Service Manual | Publication 9803... Order the manual at mid-west-tech.com >