Tyler Sprayer (1991-1992)

Parts Catalog

98331TS

CASE IH AGRICULTURE

MidWestTech | Case 1991-1992 Tyler Sprayer Parts Catalog | Publication 98331TS

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-001		CAB
01-002		CAB-GLASS
01-003		CAB-ACCESSORIES
01-004		CONTROLS-CAB INTERIOR
01-005		AIR CONDITIONER
01-006		HEATER KIT
01-007		WIPER MOTOR ASSEMBLY
06-001		HYDRAULIC CYLINDER-AXLE ADJ
06-002		HYDRAULIC CYLINDER - BOOM HEIGHT
06-003		HYDRAULIC CYLINDER (60' AND 75' BOOM) - BOOM INNER FOLD
06-004	01	HYDRAULIC CYLINDER - BOOM INNER FOLD(90' BOOM) R.H.
06-004	02	HYDRAULIC CYLINDER - BOOM INNER FOLD(90' BOOM) L.H.
06-005	01	HYDRAULIC CYLINDER - BOOM OUTER FOLD(90' BOOM), SCREW-ON END GLAND TYPE
06-005	02	HYDRAULIC CYLINDER - BOOM OUTER FOLD(90' BOOM), SPIRAL-WIRE LOCK END GLAND TYPE
06-006		HYDRAULIC CYLINDER - BOOM LEVEL (60' &75')
06-007		HYDRAULIC CYLINDER - BOOM LEVEL (90')
06-008		HYDRAULIC CYLINDER - HITCH
06-009		HYDRAULIC CYLINDER - STEERING
06-010		HYDRAULIC CYLINDER - TIE ROD
04-001		WHEEL & TIRE - TYLER SPRAYER
04-002		POWER WHEEL HUB (AUBURN) - MODEL 6
04-003		POWER WHEEL HUB (AUBURN) - MODEL 7
05-001		HYDRAULIC PLUMBING - BASIC UNIT TYLER SPRAYER
05-002		HYDRAULIC PLUMBING (60' & 75') BOOMS - TYLER SPRAYER, 7-BANK VALVE
05-003		HYDRAULIC PLUMBING - (90') BOOM TYLER SPRAYER
05-004		HYDRAULIC PLUMBING - HYDROSTATIC PUMP TYLER SPRAYER, 7-BANK VALVE
05-005		HYDRAULIC PLUMBING - HYDROSTATIC PUMP, PUMP TO SHIFT BLOCK
05-006		HYDRAULIC PLUMBING - STEERING TYLER SPRAYER, 7-BANK VALVE
05-007		HYDRAULIC PLUMBING - TYLER SPRAYER TOW HITCH
05-008		HYDRAULIC PLUMBING - WHEEL MOTORS TYLER SPRAYER
05-009		HYDRAULIC PLUMBING - WHEEL MOTOR TYLER SPRAYER
05-010		STEEL HYD. TUBES & CLAMPS - TYLER SPRAYER
05-011		HYDROSTATIC PUMP - FILTER ASSEMBLY, 7-BANK VALVE
05-012		VALVE 7-BANK DIRECTIONAL TYLER SPRAYER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-027	WHEEL MOTOR
08-001	LIQUID PLUMBING BOOMS (60') - TYLER SPRAYER
08-002	LIQUID PLUMBING BOOMS (75') - TYLER SPRAYER DICKEY-JOHN
08-003	LIQUID PLUMBING TYLER SPRAYER (90') BOOM
08-004	LIQUID PLUMBING (750 GAL. ELLIPTICAL) TYLER SPRAYER WITH DICKEY-JOHN CONTROLLER
08-005	LIQUID PLUMBING (700 GAL. S.S. TANK) TYLER SPRAYER WITH DICKEY-JOHN CONTROLLER
08-006	LIQUID PLUMBING (750 GAL. SPHERICAL TANK) TYLER SPRAYER WITH DICKEY-JOHN CONTROLLER
08-007	LIQUID PLUMBING (750 GAL. SPHERICAL TANK) TYLER SPRAYER 90' BOOM WITH DICKEY-JOHN CONTROLLER
08-008	LIQUID PUMP #53670 - SEAL AND GEROTOR KITS
10-001	CROP GUARD
10-002	FOAM MARKER - HIGH VOLUME
10-003	FOAM MARKER - HIGH VOLUME (WIRING)
10-004	TOW HITCH ASSEMBLY - TYLER SPRAYER
03-001	LADDER ASSEMBLY
03-002	LADDER ASSEMBLY- R.H. SIDE
03-003	SHOCK LIMITER ASSEMBLY
03-004	STRUT ASSEMBLY FRONT - TYLER SPRAYER
03-005	STRUT ASSEMBLY REAR W/INTEGRAL BRAKE - TYLER SPRAYER
02-001	ENGINE MOUNTS
02-002	ENGINE ASSEMBLY
02-003	AIR CLEANER ASSEMBLY
02-004	BELLY PAN ASSEMBLY
02-005	MANIFOLD-VALVE-SEALS & REPAIR PARTS
02-006	MANIFOLD-PLUMBING TO WHEEL MOTOR POWER WHEEL HUB (AUBURN MODEL 6)
02-007	RADIATOR ASSEMBLY
11-001	CONTROLLER DICKEY-JOHN® CCS/CMS 100 LIQ SYS
11-002	WIRING - BALL VALVE
11-003	WIRING - ELECTRICAL BOOM RELIEF
11-004	WIRING SCHEMATIC - CAB
11-005	WIRING SCHEMATIC - ENGINE
11-006	WIRING SCHEMATIC - VALVE
07-001	BOOM ASSEMBLY (60') TYLER SPRAYER
07-002	BOOM ASSEMBLY (75') TYLER SPRAYER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

07-003	BOOM ASSEMBLY (90') TYLER SPRAYER
07-004	BOOM NOZZLE SPACING (90') TYLER SPRAYER INNER BOOM
07-005	BOOM NOZZLE SPACING (90') TYLER SPRAYER MID-BOOM
07-006	BOOM NOZZLE SPACING (90') TYLER SPRAYER OUTER BOOM
07-007	BOOM ASSEMBLY (90') TYLER SPRAYER SWITCH MOUNTING
09-001	DECALS USED ON TYLER SPRAYER - EXTERIOR DECALS
09-002	INTERIOR DECALS (CAB)

Order the manual at mid-west-tech.com >