Tractors
1290 / 1390

Operator's Manual

9-9202

CASE

MidWestTech | Case 1290, 1390 Tractor Operator's Manual | Publication 9-9202

Order the manual at mid-west-tech.com >

SECTIONS

	Page
TO THE OWNER	5
SAFETY RULES	7
HAND SIGNALS	14
DECALS	16
TRACTOR SERIAL NUMBERS	20
SPECIFICATIONS	22
INSTRUMENTS AND CONTROLS	42
OPERATING	79
MAINTENANCE	111
HIGH CLEARANCE TRACTORS	164

CONTENTS

SPECIFICATIONS

DIESEL ENGINE SPECIFICATIONS	22
GENERAL TRACTOR SPECIFICATIONS	24
FUEL	29
ANTI-FREEZE	29
BRAKE AND CLUTCH FLUID	30
APPROVED LUBRICANTS	31
TYRE SIZES, MAXIMUM LOADS AND PRESSURES	34
TYRE ARRANGEMENTS: 4WD TRACTORS	35
FRONT TREAD WIDTHS (2WD)	36
FRONT TREAD WIDTHS (4WD)	37
REAR TREAD WIDTHS	38
APPROXIMATE MEASUREMENTS	39
TRAVEL SPEED CHARTS–HYDRA-SHIFT	40
TRAVEL SPEED CHARTS–SYNCHROMESH	42

MidWestTech | Case 1290, 1390 Tractor Operator's Manual | Publication 9-9202 Order the manual at mid-west-tech.com >