YANMAR

SERVICE MANUAL

L75AE
L90AE
L100AE

MidWestTech | JCB Yanmar L75AE, L90AE, L100AE Diesel Engine Service Manual | Publi...

Order the manual at mid-west-tech.com >

CONTENTS

1. Specifications **1**
1.1 Specifications 1
1.2 Cross Sectional Views 5

2. Service standard **8**

3. Disassembly and Reassembly **18**
3.1 Tools, Meters and Instruments 18
1. Tools 18
2. Meters, Instruments and Service Accessories 20
3. Instruments 22
3.2 Tightening Torque 23
3.3 Maintenace Schedule 24
3.4 Disassembly Procedures 25
3.5 Reasembly Procedures 29
3.6 Recoil Starter 34

4. Checking and Servicing **37**
4.1 Cylinder Head 37
4.2 Piston and Piston Pin 41
4.3 Connecting Rod 45
4.4 Crankshaft, Flywheel and Main Bearing 49
4.5 Camshaft and Tappet 51
4.6 Timing Gear 52
4.7 Crankcase Cover 53
4.8 Cylinder Sleeve and Cylinder Block 55
4.9 Lubrication System 56
4.10 Fuel System 58
4.11 Speed Control Device 62
4.12 Electrical System 64
1. Wiring Diagram 64
2. Starter Motor 69
3. Generator (Dynamo), Regulator and Rectifier 84
4. Air Heater 89
5. Battery 90
4.13 Adjustment 93

5. Toroubleshooting **95**

6. Test Run **111**

7. Helical Inserting Part for Repair **114**

Appendix 1 Difference Between Parts under Spec. S and D **117**

Appendix 2 Detail of Special Tools **120**

MidWestTech | JCB Yanmar L75AE, L90AE, L100AE Diesel Engine Service Manual |... Order the manual at mid-west-tech.com >