320
Backhoe

Parts Catalog

A1010

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

LOADER

B

Buckets - Loader 11
Bulldozer Blade. 13

C

Conversion Parts - Hose and Fitting Assembly. . . 88
Cylinders - Bucket, Hydraulic 11, 23
Cylinders - Lift, Hydraulic. 11, 19, 21

G

Guard - Radiator, Wheel Tractor. 5

H

Hood - Engine, Wheel Tractor 5
Hydraulics - Basic Loader 15

L

Loader Frame 11
Lift Arm 11

M

Modification Parts 7

P

Pumps - Hydraulic 13, 15, 29, 59, 61, 63, 65
Pump Drive - Hydraulic 13, 15

S

Scarifier 83
Seat - Wheel Tractor 9

V

Valve - Control, Loader Hydraulic. . . . 15, 25, 27, 31

W

Weight Boxes - Rear 85

BACKHOE

B

Boom 39
Buckets - Backhoe 41, 43

C

Conversion Parts - Hose and Fitting Assembly. . . 88
Counterweight - Rear. 87
Cylinder - Boom, Hydraulic 39, 71
Cylinders - Bucket, Hydraulic 41, 75
Cylinder - Crowd, Hydraulic. 39, 73
Cylinders - Stabilizer, Hydraulic 33, 37, 67
Cylinders - Swing, Hydraulic 33, 37, 69

D

Dipper Arm 39

H

Hydraulics - Basic Backhoe. 29, 31
Hydraulics - Boom, Crowd, and Bucket Cylinders 45, 49
Hydraulics - Swing and Stabilizer Cylinder. . . . 53, 55

M

Modification Parts 57
Mounting Parts 33, 37

P

Pumps - Hydraulic 13, 15, 29, 59, 61, 63, 65
Pump Drive - Hydraulic 13, 29

S

Seat - Deluxe 9
Stabilizers 33, 37
Swing Linkage 33, 37

T

Tower. 39
Transfers 87

V

Valve - Control, Hydraulic Backhoe .45, 49, 53, 55, 77
Valve - Flow Control. 45, 49, 83
Valves - Special Relief. 45, 49, 81

W

Weight Boxes - Rear 85

Order the manual at mid-west-tech.com >