W7C
Loader

Parts Catalog

A1114

CASE CONSTRUCTION

MidWestTech | Case W7C Loader Parts Catalog | Publication A1114

Order the manual at mid-west-tech.com >

Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.

Indented Description

Indented parts in the description list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

REF		PART NO.	DESCRIPTION	REQ'D.
	A	55159	CYLINDER ASSY. - rear steering	1
28	A	56208	SOCKET ASSY. - rear cylinder	1
29	A	55956	PLUG - adjusting, socket assy.	1
30	A	55957	SEAT - socket ball	2
31	A	56210	SPRING - socket	1
32	A	56209	SEAT - socket spring	1
33	G	45175	CLAMP ASSY. - socket assy.	1
34	16-	836	HHCS - 1 2" - 20 NF x 2-1 4"	1
35	132-	104	PIN - cotter, 3 16" dia. x 3"	1

Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of the loader are determined by sitting in the operator's seat facing the loader.



690766

Printed in U.S.A.

Issued June, 1969

MidWestTech | Case W7C Loader Parts Catalog | Publication A1114 Order the manual at mid-west-tech.com >

MODEL W7C LOADER
ALPHABETICAL INDEX
- ENGINE SECTION -

A

Air Cleaners - engine, diesel 83
Air Cleaners - engine, gasoline 85
Alternator - electrical 77

B

Balancer - engine, diesel 21
Balancer - engine, gasoline 43
Belt - drive, fan and alternator 55,59
Block - cylinder, diesel 15
Block - cylinder, gasoline 37

C

Camshaft - engine, diesel 13
Camshaft - engine, gasoline 35
Carburetor - engine, gasoline 51
Coil - electrical, gasoline engine 81
Crankshaft - engine, diesel 17
Crankshaft - engine, gasoline 39

D

Distributor - electrical, gasoline engine 79,81
Dipstick - engine oil, diesel 15
Dipstick - engine oil, gasoline 37

E

Electrical System - diesel 55,57,63
Electrical System - gasoline 59-63,81

F

Fan - engine cooling 7
Filter - engine oil, diesel 23
Filter - engine oil, gasoline 45
Filter - fuel, diesel 29
Flywheel - engine, diesel 17
Flywheel - engine, gasoline 39
Fuel Tanks - engine 137

G

Gasket Kits - engine, diesel 25
Gasket Kits - engine, gasoline 47
Gauges - instrument panel 65
Governor - engine, gasoline 49

H

Head - cylinder, diesel 11
Head - cylinder, gasoline 33

I

Ignition System - engine, gasoline 81
Index - basic tractor 3
Index - loader 4,5
Index - numerical 236-257
Injection System - fuel, diesel 27
Injection - fuel, diesel 27

K

Kits - piston and sleeve, diesel engine 19
Kits - piston and sleeve, gasoline engine 41

L

Linkage - throttle control, diesel 89
Linkage - throttle control, gasoline 91

M

Manifold - exhaust 9
Manifold - intake 9
Manifold - water 7
Muffler - exhaust 87

P

Pan - engine oil, diesel 23
Pan - engine oil, gasoline 45
Panel - instrument 65
Pistons - engine, diesel 19
Pistons - engine, gasoline 41
Pump - fuel injection, diesel 31
Pump - engine oil, diesel 21
Pump - engine oil, gasoline 43
Pump - water 7

R

Radiator - engine cooling 125
Rings - piston, diesel 19
Rings - piston, gasoline 41
Rocker Arm - engine, diesel 13
Rocker Arm - engine, gasoline 35
Rod - connecting, diesel 19
Rod - connecting, gasoline 41
Rod - push, diesel 13
Rod - push, gasoline 35
Rotor - distributor, gasoline engine 79

S

Sleeve - engine, diesel 19
Sleeve - engine, gasoline 41
Spark Plug - ignition, gasoline engine 81
Starter - engine, diesel 71
Starter - engine, gasoline 75

T

Thermostat - coolant temperature 7
Timing Gear Cover - engine, diesel 15
Timing Gear Cover - engine, gasoline 37

V

Valve Cover - engine, diesel 11
Valve Cover - engine, gasoline 33
Valve Guides - engine, diesel 13
Valve Guides - engine, gasoline 35
Valves - engine, diesel 13
Valves - engine, gasoline 35
Ventilation - crankcase 53

MidWestTech | Case W7C Loader Parts Catalog | Publication A1114 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

-BASIC TRACTOR SECTION-

A

Accumulator - hydraulic 223
Alternator - electrical 77
Axle - rigid, front 167, 173-177
Axle - steering, rear 169-177

B

Batteries - electrical 63
Battery Cables - electrical 63
Brake - parking, transmission 153
Brake Controls - foot 103
Brake Controls - parking 123
Brake System - Hydrovac, diesel 109
Brake System - Hydrovac, gasoline 113

C

Cab - operator 227
Chassis - tractor 131
Cleaner - air, Hydrovac 121
Clutch - high gear, transmission 153
Clutches - forward, reverse and low gear, transmission 151
Clutch Control - brake 103
Converter - torque 159
Cooling System - converter and transmission . . 145
Counterweights - rear 131
Cylinder - Hydrovac 117
Cylinder - master, brake 115
Cylinder - wheel, brake 115

D

Decals - tractor 237
Differential - tractor 173
Drive Shafts - transmission and axle 179
Drum - brake 177

E

Electrical System - cab 229
Electrical System - tractor, diesel 55
Electrical System - tractor, gasoline 59

F

Fenders - tractor 135
Filter - air, Hydrovac 121
Filter - converter oil 147
Filter - hydraulic oil 139
Floor Plates - tractor 129

G

Gauges - instrument panel 65
Grill - radiator guard 125

H

Heater - cab 231
Horn - tractor 69
Hood - engine 127
Hydraulics - power steering 97

I

Index - engine 2
Index - loader 4,5
Index - numerical 236-257
Instrument Panel - tractor 65

L

Lever - fuel shut-off, diesel 89
Lights - dash 69
Lights - front and rear 69
Lights - stop 69
Lights - turn signal 233,235
Linkage - steering 95

M

Mounts - engine 133
Muffler - exhaust 87

P

Panel - instrument 65
Panels - engine side 127
Pedal - throttle control 89,91
Pedals - brake, Hydrovac 103
Plates - floor 129
Platform - operator compartment 129
Pump - charging, torque converter 163
Pump - power steering 101
Pump - vacuum, Hydrovac 121

R

Radiator - engine cooling 125
Reservoir - power steering 101

S

Seat - operator 129
Shaft - input, transmission 151
Shaft - output, transmission 155
Shift Controls - transmission 141
Shift-Out - rear axle 165
Shutter - radiator 125
Side Panels - engine 127
Starter - electrical, diesel 71
Starter - electrical, gasoline 75
Steering Cylinder - hydraulic 99
Steering Gear - tractor 93
Steering Hydraulics - tractor 97
Steering Wheel - tractor 95

T

Tank - fuel 137
Tank - hydraulic oil 139
Tank - reserve, Hydrovac 111,113
Transmission Controls - tractor 141

U

Universal Joints - drive shaft 179

V

Valve - accumulator 225
Valve - check, Hydrovac 121
Valve - clutch control 123
Valve - control, transmission 157
Valve - power steering cylinder 99
Valve - regulating, torque converter 165

W

Wheels - drive 177

Printed in U.S.A.

Issued April, 1969

MidWestTech | Case W7C Loader Parts Catalog | Publication A1114

Order the manual at mid-west-tech.com >