W8C Loader

Parts Catalog

A1120

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.


Indented Description

Indented parts in the description list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

REF		PART NO.	DESCRIPTION	REQ'D.
	A	55159	CYLINDER ASSY. - rear steering	1
28	A	56208	SOCKET ASSY. - rear cylinder	1
29	A	55956	PLUG - adjusting, socket assy.	1
30	A	55957	SEAT - socket ball	2
31	A	56210	SPRING - socket	1
32	A	56209	SEAT - socket spring	1
33	G	45175	CLAMP ASSY. - socket assy.	1
34	16-	836	HHCS - 1 2" - 20 NF x 2-1/4"	1
35	132-	104	PIN - cotter, 3/16" dia. x 3"	1

Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of the loader are determined by sitting in the operator's seat facing the loader.



Printed in U.S.A.

Issued August, 1971

MidWestTech | Case W8C Loader Parts Catalog | Publication A1120 Order the manual at mid-west-tech.com >

MODEL W8C LOADER
ALPHABETICAL INDEX
- ENGINE SECTION -

A

Air Cleaners - engine, diesel 91
Air Cleaners - engine, gasoline 93
Alternator - electrical, diesel engine 65
Alternator - electrical, gasoline engine 67

B

Belt - drive, fan and alternator 69,77
Block - cylinder, diesel 17
Block - cylinder, gasoline 37

C

Camshaft - engine, diesel 15
Camshaft - engine, gasoline 35
Carburetor - engine, gasoline 49,49B
Coil - electrical, gasoline engine 61
Crankshaft - engine, diesel 19
Crankshaft - engine, gasoline 39

D

Distributor - electrical, gasoline engine 61,63
Dipstick - engine oil, diesel 17
Dipstick - engine oil, gasoline 37

E

Electrical System - diesel 69-75,85
Electrical System - gasoline 77-85

F

Fan - engine cooling 7
Filter - engine oil, diesel 23
Filter - engine oil, gasoline 43
Filter - fuel, diesel 29
Flywheel - engine, diesel 19
Flywheel - engine, gasoline 39
Fuel Tank - diesel engine 143
Fuel Tank - gas engine 145

G

Gasket Kits - engine, diesel 25
Gasket Kits - engine, gasoline 45
Gauges - instrument panel, diesel engine 73
Gauges - instrument panel, gasoline engine 81
Governor - engine, gasoline 47

H

Head - cylinder, diesel 13
Head - cylinder, gasoline 33

I

Ignition System - engine, gasoline 61
Index - basic tractor 3
Index - loader 4,5
Index - numerical 262
Injection System - fuel, diesel 27
Injector - fuel, diesel 27

K

Kits - piston and sleeve, diesel engine 21
Kits - piston and sleeve, gasoline engine 41

L

Linkage - throttle control, diesel 95
Linkage - throttle control, gasoline 97

M

Manifold - exhaust, diesel engine 9
Manifold - exhaust, gasoline engine 11
Manifold - intake, diesel engine 9
Manifold - intake, gasoline engine 11
Manifold - water 7
Muffler - exhaust, diesel engine 9
Muffler - exhaust, gasoline engine 11

P

Pan - engine oil, diesel 23
Pan - engine oil, gasoline 43
Panel - instrument 73,81
Pistons - engine, diesel 21
Pistons - engine, gasoline 41
Pump - fuel injection, diesel 31
Pump - engine oil, diesel 23
Pump - engine oil, gasoline 43
Pump - water 7

R

Radiator - engine cooling 131
Rings - piston, diesel 21
Rings - piston, gasoline 41
Rocker Arm - engine, diesel 15
Rocker Arm - engine, gasoline 35
Rod - connecting, diesel 21
Rod - connecting, gasoline 41
Rod - push, diesel 15
Rod - push, gasoline 35
Rotor - distributor, gasoline engine 63

S

Sleeve - engine, diesel 21
Sleeve - engine, gasoline 41
Solenoid - starter 59
Spark Plug - ignition, gasoline engine 61
Starter - engine, diesel 51,53
Starter - engine, gasoline 55,57

T

Thermostat - coolant temperature 7
Timing Gear Cover - engine, diesel 17
Timing Gear Cover - engine, gasoline 37

V

Valve Cover - engine, diesel 13
Valve Cover - engine, gasoline 33
Valve Guides - engine, diesel 15
Valve Guides - engine, gasoline 35
Valves - engine, diesel 15
Valves - engine, gasoline 35
Ventilation - crankcase 11

MidWestTech | Case W8C Loader Parts Catalog | Publication A1120 Order the manual at mid-west-tech.com >

MODEL W8C LOADER
ALPHABETICAL INDEX
- BASIC TRACTOR SECTION -

A

Accumulator - hydraulic 249
Alternator - electrical, diesel engine 65
Alternator - electrical, gasoline engine 67
Axle - rigid, front 175-181
Axle - steering, rear 183-191

B

Batteries - electrical 65
Battery Cables - electrical 65
Brake - parking, transmission 161
Brake Controls - foot 109
Brake Controls - parking 129
Brake System - Hydrovac, diesel 117,119
Brake System - Hydrovac, gasoline 121,121B

C

Cab - operator 253
Chassis - tractor 137
Cleaner - air, Hydrovac 127
Clutch - high gear, transmission 161
Clutches - forward, reverse and low gear, transmission 159
Clutch Control - brake 109
Converter - torque 167,169
Cooling System - converter and transmission .. 153
Counterweights - rear 139
Cylinder - Hydrovac 123,125
Cylinder - master, brake 111
Cylinder - wheel, brake (Front Axle) 177
Cylinder - wheel, brake (Rear Axle) 187

D

Decals - tractor 261
Differential - tractor, front axle 179,181
Differential - tractor, rear axle 189,191
Drive Shafts - transmission and axle 195
Drum - brake, front axle 177
Drum - brake, rear axle 187

E

Electrical System - cab 255
Electrical System - tractor, diesel 69-75,85
Electrical System - tractor, gasoline 77-85

F

Fenders - tractor 141
Filter - air, Hydrovac 127
Filter - converter oil 155
Filter - hydraulic oil 147
Floor Plates - tractor 135

G

Gauges - instrument panel, diesel engine 73
Gauges - instrument panel, gasoline engine 81
Grille - radiator guard 131

H

Heater - cab 257
Horn - tractor 89
Hood - engine 133
Hydraulics - power steering 103

I

Index - engine 2
Index - loader 4,5
Index - numerical 262
Instrument Panel - tractor 73,81

L

Lever - fuel shut-off, diesel 95
Lights - dash 89
Lights - front and rear 87
Lights - stop 87
Lights - turn signal 259
Linkage - steering 101

M

Mounts - engine 137
Muffler - exhaust, diesel engine 9
Muffler - exhaust, gasoline engine 11

P

Panel - instrument 73,81
Panels - engine side 133
Pedal - throttle control 95,97
Pedals - brake, Hydrovac 109
Plates - floor 135
Platform - operator compartment 135
Pump - charging, torque converter 171
Pump - power steering 107
Pump - vacuum, Hydrovac 127

R

Radiator - engine cooling 131
Reservoir - power steering 107

S

Seat - operator 135
Shaft - input, transmission 159
Shaft - output, transmission 163
Shift Controls - transmission 149,151
Shift-Out - rear axle 163
Shutter - radiator 131
Side Panels - engine 133
Starter - electrical, diesel 51,53
Starter - electrical, gasoline 55,57
Steering Cylinder - hydraulic 105
Steering Gear - tractor 99
Steering Hydraulics - tractor 103
Steering Wheel - tractor 99

T

Tank - fuel, diesel engine 143
Tank - fuel, gasoline engine 145
Tank - hydraulic oil 147
Tank - reserve, Hydrovac 117,121
Transmission Controls - tractor 149,151

U

Universal Joints - drive shaft 195

V

Valve - accumulator 251
Valve - check, Hydrovac 127
Valve - clutch control 129
Valve - control, transmission 165
Valve - power steering cylinder 105
Valve - regulating, torque converter 173

W

Wheels - drive 193

Printed in U.S.A.

691342 Issued August, 1971

MidWestTech | Case W8C Loader Parts Catalog | Publication A1120

Order the manual at mid-west-tech.com >