Models 644 and 646 Compact Wheel Loaders

Parts Catalog

A1281

CASE CONSTRUCTION

MidWestTech | Case 644, 646 Compact Wheel Loader Parts Catalog | Publication A1281

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

This parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.

Indented Description

Indented parts in the descriptive list are a part of the preceding assembly or sub-assembly.

The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

REF.	PART NO.	DESCRIPTION	REQ'D
	A 55159	CYLINDER ASSY - rear steering	1
28	A 56208	SOCKET ASSY - rear cylinder	1
29	A 55956	PLUG - adjusting, socket assy	1
30	A 55957	SEAT - socket ball	2
31	A 56210	SPRING - socket	1
32	A 56209	SEAT - socket spring	1
33	G 45175	CLAMP ASSY - socket assy	1
	16- 836	BOLT - 1/2" x 2-1/4" N.F. hex.	1
34	132- 104	PIN - cotter, 3/16" x 3"	1
35	A 55889	STUD - ball, socket & cylinder	2
36	13- 410	BOLT - 1/4" x 5/8" N.C., hex.	4
37	92- 4	LOCKWASHER - 1/4" SAE	4

Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of this machine are determined by standing at the rear of the unit and facing in the direction of forward travel.

Order the manual at mid-west-tech.com >

KOHLER ENGINE SECTION

	Page
ir Cleaner	39
attery	89
elt, Starter-Generator	35
reather, Crankcase	27
amshaft	27
arburetor	41-43
onnecting Rod	29
rankshaft	29
ylinder Block	31
ylinder Head	31
lectrical System	89-91
ngine Block & Attaching Parts	31
xchanger, Heat	59
xhaust System	25
an	25
Filter, Breather	27
Flywheel	31
Fuel Pump	41-43
Fuel Strainer	43
Fuel System	43
Gasket Kits	33
Governor	37
Muffler	25
Oil Pan	31
Piston	29
PTO Clutch	43-45
Spark Plug	89
Starter-Generator	85-87
Tank, Fuel	43
Throttle Linkage	37
Valves	27

ONAN ENGINE SECTION

	Page
ir Cleaner	5
lower Housing	19
amshaft	11
arburetor	5-7
rankshaft	11
lectrical - engine	21
ngine Block & Attaching Parts	13-15
xhaust System	25
ilter - oil	17
Flywheel	11
Fuel Pump	9
Governor	19
Motor - starter	23
Oil Base	17
Oil Pump	17
Piston & Rods	11
Points - breaker contact	21
Valves	13-15

BASIC TRACTOR SECTION

	Page
xle, Front	51
xle, Rear	57
affles & Shrouds	35
akes	53
ucket & Arms	55
ontrol-Speed, Hydraulic	65
cals	95
ectrical System	89-91-93
nders	49
ame	47
ame, Lift Rods and Arms for LT-26 Three Point Hitch	103
27 Hitch Adapter	105
ille	47
tch	97
od	47
draulics - Tractor	59-61
Coupling, Pump Drive	75-77
Hoses, Lines & Fittings	59-61
Motor, Hydraulic Drive	79
Pump	75-77
Valve, Control, Tractor	69-71
Valve Control Linkage	65
Hydraulics - Bucket	63
Cylinder, Arms	63-81
Cylinder, Bucket	63-81
Hoses, Lines & Fittings	63
Valve - Bucket Control	63-73
Valve Control Linkage, Bucket	67
Hydraulic Connections & Components for LT-26 Three Point Hitch	105
Hydraulic PTO Kit Lt-16 & LT-17	99
Hydraulic PTO Valve LT-16 & LT-17	101
Implement Lift, Hydraulic	83
Instruments, Electrical	89
Lever - Range Selector	49
Model D10 Wheel Weights	97
PTO Clutch	45
Seat, Operator's	49
Steering Wheel & Gear	51
Tail Lamp	89
Tool Box	45
Transmission	57
Weight Box	97
Wheels, Front & Rear	53

Order the manual at mid-west-tech.com >