W24B
Loader

S/N 9120798 And After

Parts Catalog

Bur A1307

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

001		REVISION RECORD LOG
004		SERIAL NUMBER LOCATIONS
010		WATER MANIFOLD AND THERMOSTAT, (504BD) AND (504BDT) DIESEL
012		WATER PUMP, (504BD) AND (504BDT) DIESEL ENGINES
014		OIL FILTER AND COOLER, (504BD) AND (504BDT) DIESEL ENGINES
016		MANIFOLDS, (504BD) NATURALLY ASPIRATED ENGINE, INTAKE
018		MANIFOLDS, (504BDT) ALTITUDE COMPENSATING ENGINE, INTAKE
020		TURBO-CHARGER SYSTEM, (504BDT) ALTITUDE COMPENSATNG ENGINE
022		TURBO-CHARGER CONVERSION KIT, TO CONVERT A NATURALLY
024		CYLINDER HEAD AND COVER, 504BD AND 504BDT DIESEL ENGINES
026		CYLINDER HEAD AND COVER, (504BD) AND (504BDT) DIESEL ENGINES
028		CAMSHAFT, (504BD AND (504BDT) DIESEL ENGINES
030		CYLINDER BLOCK, (504BD) AND (504BDT) DIESEL ENGINES, BLOCK
032		CRANKSHAFT AND FLYWHEEL, (504BD) AND (504BDT) DIESEL ENGINES
034		FLYWHEEL HOUSING, (504BD) AND (504BDT) DIESEL ENGINES
036		PISTONS AND SLEEVES, WITH 5.189" TO 5.194" FIRE DAM DIAMETER
037A		PISTONS AND SLEEVES, WITH 5.092" TO 5.097" FIRE DAM DIAMETER
038		OIL PUMP, (504BD) AND (504BDT) DIESEL ENGINES, OIL PAN
040		ENGINE GASKET KITS, 504BD AND 504BDT DIESEL ENGINE, VALVE
041A		ENGINE GASKET KITS, 504BD AND 504BDT DIESEL ENGINE, CYLINDER
042		TIMING GEAR COVER, (504BD) AND (504BDT) DIESEL ENGINES
044		ENGINE MOUNTS
046		RADIATOR FAN AND FAN BELTS
048		AIR CLEANER AND RELATED PARTS
050		EXHAUST SYSTEM
052		ACCELERATOR AND LINKAGE
054		FUEL TANK AND RELATED PARTS
056		FUEL TANK AND SENDING UNIT, LATE PRODUCTION, EARLY
058		L52634 FUEL PUMP
060		FUEL INJECTION SYSTEM, (504BD) AND (504BDT) DIESEL ENGINES
062		FUEL FILTER SYSTEM, (504BD) AND (504BDT) DIESEL ENGINES
064		INJECTION PUMP DRIVE, (504BD) AND (504BDT) DIESEL ENGINES
066		INJECTION PUMP
068		INJECTION NOZZLES, FOR ALTITUDE COMPENSATING ENGINES, FOR
070		L72955 ALTERNATOR, 65 AMP - 24 VOLT
072		L59901 ALTERNATOR, 40 AMP - 24 VOLT
074		L78103 ALTERNATOR, 40 AMP - 24 VOLT
076		R26137 STARTER
078		R26137 STARTER
080		A42376 SOLENOID
082		ELECTRICAL SYSTEM, INSTRUMENT PANELS AND TACHOMETER
084		ELECTRICAL SYSTEM, INSTRUMENT CLUSTER
086		ELECTRICAL SYSTEM, FRONT HARNESS
088		ELECTRICAL SYSTEM, REAR HARNESS
092		ELECTRICAL SYSTEM, BATTERY, STARTER AND BATTERY CABLES
094		ALTERNATOR MOUNTING PARTS, L72955 ALTERNATOR - 65 AMP
094	1	ALTERNATOR - 40 AMP
096		ELECTRICAL SYSTEM, OPERATORS COMPARTMENT
098		ELECTRICAL SYSTEM, AUXILIARY STEERING
100		D71479 AUXILIARY STEERING MOTOR
102		LIGHTS, INSTRUMENT PANEL LIGHT, FRONT HEAD LIGHT, FRONT
104		TURN SIGNAL AND FLASHER LIGHT
106		ROTATING BEACON AND RELATED PARTS, USED ON MODELS WITH CAB
108		ROTATING BEACON
110		CAB WIPERS, FRONT WIPER - INCLUDED IN CAB, REAR WIPER -

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

112		D71529 BLOWER
112	1	L35259 AND F93455 WIPERS
114		BACKUP ALARM
115A		COLD START SYSTEM, SEE ITEMS 1 AND 4 FOR IDENTIFICATION
116		COLD START SYSTEM
118		STEERING CONTROL VALVE AND RELATED PARTS
120		STEERING CONTROL VALVE
122		STEERING HYDRAULIC CIRCUITS - PUMP TO RESERVOIR, MODELS
124		AUXILIARY STEERING HYDRAULIC CIRCUITS
126		L70813 AUXILIARY STEERING PUMP AND MOTOR
128		STEERING HYDRAULIC CIRCUIT, STEERING CONTROL VALVE TO
130		G34300 AND G34301 STEERING CYLINDERS, TUBE OR GLAND IS
131A		G101274 AND G101275 STEERING CYLINDERS, TUBE IS STAMPED WITH
132		L71667 LOADER AND STEERING PUMP
134		TRANSMISSION CONTROL PARTS
138		TRANSMISSION MOUNTING PARTS, DIPSTICK AND OIL FILTER
140		TRANSMISSION HYDRAULIC SYSTEM
142		TRANSMISSION, FRONT COVER, INPUT SHAFT AND TORQUE CONVERTER
144		TRANSMISSION, TORQUE CONVERTER HOUSING, GEARS AND
148		TRANSMISSION, TURBINE DRIVEN GEARS AND FREEWHEEL UNIT
150		TRANSMISSION, FORWARD CLUTCH AND PLANETARY
152		TRANSMISSION, REVERSE CLUTCH AND PLANETARY
154		TRANSMISSION, HIGH RANGE CLUTCH AND TRANSFER GEAR
156		TRANSMISSION, AXLE OUTPUT SHAFT AND PARKING BRAKE
158		TRANSMISSION, CHARGING PUMP, TRANSMISSION CONTROL VALVES
162		TRANSMISSION OVERHAUL KIT
164		FRONT AXLE DRIVE SHAFT, (AXLE END), L47724 DRIVE SHAFT
166		REAR AXLE DRIVE SHAFT
168		FRONT AXLE DRIVE SHAFT, (TRANSMISSION END)
170		AXLE ASSEMBLIES
172		RIMS AND TIRES, USED ON MODESL WITH 17.50 X 25 - 12 PLY
174		AXLE PLANETARY
176		AXLE DIFFERENTIAL, PINION BEARINGS AND COMPANION FLANGE
178		FRONT AXLE DIFFERENTIAL, PINION, RING GEAR AND DIFFERENTIAL
180		REAR AXLE DIFFERENTIAL, PINION, RING GEAR AND DIFFERENTIAL
182		FRONT AND REAR AXLE BRAKES
184		BRAKE SYSTEM, AIR COMPRESSOR TO RESERVOIR
186		L57774 AIR COMPRESSOR, TU-FLO-400 CAST IRON CRANKCASE
190		GOVERNOR - AIR COMPRESOR
192		ALCOHOL EVAPORATOR
194		BRAKE SYSTEM, RESERVOIR TO TREADLES, REAR MASTER CYLINDER
195A		BRAKE SYSTEM, TREADLE TO FRONT MASTER CYLINDER AND RESERVOIR
195C		BRAKE SYSTEM, RESERVOIR TO TREADLES AND MASTER CYLINDERS
195E		BRAKE SYSTEM, TREADLE TO CLUTCH CUTOUT AND HYDRAULIC
196		BRAKE SYSTEM, BRAKE MASTER CYLINDERS TO WHEEL CYLINDERS
198		BRAKE SYSTEM, TREADLE TO HORN
200		BRAKE SYSTEM, EMERGENCY BRAKE VALVE TO SAFETY CHAMBER
201A		L52178 EMERGENCY BRAKE VALVE
202		L73042 TREADLE AND BRAKE VALVE
204		BRAKE CYLINDER
206		L48127 CHAMBER - PARKING BRAKE
208		L48128 DOUBLE CHECK VALVE AND STOP LIGHT SWITCH
208	1	L48129 PRESSURE REGULATOR VALVE
210		L12647 HORN VALVE, L13530 PRESSURE PROTECTION VALVE
212		L76560 HORN, L50225 HORN

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

214		HYDRAULIC RESERVOIR AND RELATED PARTS
216		BASIC HYDRAULIC CIRCUIT, PUMP TO RESERVOIR
218		LOADER HYDRAULIC CIRCUIT, PUMP TO LOADER VALVE
220		LOADER LIFT HYDRAULIC CIRCUIT
222		LOADER BUCKET TILT HYDRAULIC CIRCUIT
224		4-IN-1 BUCKET HYDRAULIC CIRCUIT
226		G34738 AND G34739 LOADER LIFT CYLINDERS, G101430 AND G101431
228		G34303 AND G101725 LOADER BUCKET TILT CYLINDER, GLAND OR
230		LOADER CONTROL VALVE (2 SPOOL)
232		LOADER CONTROL VALVE (3 SPOOL)
234		D63369 TILT SPOOL
236		D71226 TILT SPOOL
238		D63370 AND D71227 LIFT SPOOL
240		4-IN-1 BUCKET CLAM SPOOLS, MAIN RELIEF VALVE
242		CHECK VALVE, SECONDARY RELIEF VALVE, REGENERATION CHECK
244		L32633 SECONDARY RELIEF VALVE
246		LOADER CONTROL VALVE AND LEVERS (2 SPOOL)
248		LOADER CONTROL VALVE AND LEVERS (3 SPOOL)
249A		LOADER BUCKET HEIGHT CONTROL
250		LOADER BUCKET RETURN TO DIG
252		LOADER LIFT FRAME AND RELATED PARTS
254		LOADER BUCKETS, 2-1/2 CU YD BUCKET - 96 IN WIDE (1.9 CU
256		4-IN-1 BUCKET, BUCKET TEETH
258		G34316 CLAM CYLINDER, GLAND IS STAMPED WITH CYLINDER PART
259A		G101281 CLAM CYLINDER, GLAND OR TUBE IS STAMPED WITH
260		REAR FRAME AND TRUNNION, COUNTERWEIGHT
262		GRILLE AND HOOD
264		REAR FENDERS AND SIDE PANELS
266		FRONT FRAME AND FENDERS
268		FRONT AND REAR FRAME GUARDS, EARLY PRODUCTION
268	1	LATE PRODUCTION
270		SEAT AND MOUNTING PARTS
272		SUSPENSION SEAT
276		CAB MOUNTING
278		CAB CLOSURE PARTS
279A		CAB FILTER AND LATCHES
280		NOISE CONTROL PADS, USED BEFORE CAB SN 27750
281A		NOISE CONTROL PADS, USED CAB SN 27750 AND AFTER
282		CAB DOORS
284		CAB GLASS AND MOLDING
286		HEATER AND AIR CONDITIONING PLENUMS AND RELATED PARTS, USED
287A		HEATER AND AIR CONDITIONING PLENUMS AND RELATED PARTS, USED
288		HEATER LINES, BEFORE TRACTOR SN 9126838, TRACTOR SN 9126838
290		AIR CONDITIONING CIRCUIT
292		AIR CONDITIONING COMPRESSOR
294		ROPS CANOPY
296		DECALS
298		SLOW MOVING VEHICLE EMBLEM

Order the manual at mid-west-tech.com >